

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Intex](#) /

› [Intex Ultra XTR Rectangular Tubular Pool Kit Instruction Manual](#)

Intex 26364GN

Intex Ultra XTR Rectangular Tubular Pool Kit

INSTRUCTION MANUAL

1. SAFETY INFORMATION

Before assembling, installing, or using this product, please read and understand all instructions carefully. Failure to follow these instructions can result in serious injury or death.

Important Safety Warning:

Ensure the pool is correctly assembled and regularly check the structure to prevent accidents. Adult supervision is required at all times when children are in or near the pool.

- Never leave children unattended in or around the pool.
- Install fencing or approved barrier around the pool to prevent unsupervised access.
- Keep rescue equipment readily accessible.
- Do not dive or jump into the pool.
- Empty and store the pool properly during off-season to prevent water accumulation.

2. PRODUCT OVERVIEW

The Intex Ultra XTR Rectangular Tubular Pool Kit is designed for durability and ease of use, providing a robust and spacious swimming experience. It features a triple-layer liner for enhanced resistance and an improved structure for stability.



Image: The Intex Ultra XTR Rectangular Pool, showcasing its robust frame and spacious design.

Key Features:

- **Resistance:** Triple-layer liner for superior durability.
- **Quality:** Enhanced liner and structure for long-lasting performance.
- **Hydroaeration Installation:** Easy assembly with robust metal tubes.
- **Dimensions:** Approximately 7.32 x 3.66 x 1.32 meters (L x W x H).
- **Ground Dimensions:** 7.87 x 4.22 meters (L x W).
- **Swimming Surface Dimensions:** 7.03 x 3.30 meters (L x W).
- **Capacity:** 31,805 Liters.
- **Included Components:** Sand filter pump (4m³/h), shut-off valves, safety ladder with removable steps, ground cloth, and pool cover.

3. SETUP INSTRUCTIONS

Proper site preparation and assembly are crucial for the stability and longevity of your Intex pool.

3.1 Site Preparation:

1. Choose a firm, level surface free of sharp objects, debris, or excessive slopes.
2. Ensure the chosen area is large enough to accommodate the pool's ground dimensions (7.87m x 4.22m) plus additional space for access and maintenance.
3. Avoid setting up the pool under overhead power lines or near trees that may drop leaves or debris.
4. Lay down the included ground cloth to protect the pool liner.



Image: The Intex pool set up in a garden, illustrating the required space and surrounding area.

3.2 Assembly Steps:

- 1. Unpack Components:** Carefully unpack all parts and verify against the parts list in your separate assembly guide.
- 2. Position Liner:** Lay out the pool liner in the desired location on the prepared ground cloth. Ensure it is spread out smoothly without wrinkles.
- 3. Assemble Frame:** Insert the metal tubes into the liner sleeves and connect them according to the detailed instructions provided in the separate assembly manual. Ensure all connections are secure and locked into place.
- 4. Install Filter Pump:** Connect the sand filter pump (SF80220RC-2, 4700 l/h) and shut-off valves as per the pump's specific instructions. Ensure all hoses are securely fastened to prevent leaks.
- 5. Install Safety Ladder:** Assemble and position the safety ladder with removable steps. Ensure it is stable and securely placed against the pool wall.
- 6. Fill Pool:** Begin filling the pool with water. As the water level rises, smooth out any remaining wrinkles in the liner from the center outwards.



Image: A family enjoying the Intex pool, demonstrating the pool's capacity and recreational use.

4. OPERATING INSTRUCTIONS

Once assembled and filled, your Intex pool is ready for use. Follow these guidelines for optimal operation.

4.1 Water Filling and Level:

- Fill the pool to the recommended water level, typically indicated by a fill line on the liner or approximately 6 inches from the top edge.
- The pool has a capacity of 31,805 liters. Filling time will vary based on water pressure.

4.2 Filtration System:

- The included sand filter pump has a flow rate of 4 m³/h (4700 l/h).
- Operate the filter pump daily to ensure proper water circulation and filtration. The duration of operation depends on pool usage and environmental conditions, typically 4-6 hours per day.
- Refer to the separate sand filter pump manual for detailed operating instructions, backwashing, and maintenance procedures.



Image: Children enjoying water activities in the Intex pool, highlighting its suitability for family recreation.

4.3 Pool Access:

- Always use the provided safety ladder for entering and exiting the pool.
- Remove the ladder steps when the pool is not in use to prevent unsupervised access, especially by young children.

5. MAINTENANCE

Regular maintenance is essential to keep your pool clean, safe, and extend its lifespan.

5.1 Water Chemistry:

- Test pool water regularly (daily or every other day) for pH, chlorine, and alkalinity levels.
- Adjust chemical levels as needed to maintain a balanced and sanitized pool environment.
- Consult a pool chemical guide for appropriate dosages and application methods.

5.2 Cleaning:

- Skim the surface daily to remove leaves and debris.
- Brush the pool walls and floor weekly to prevent algae growth and remove dirt.
- Vacuum the pool floor as needed to remove settled debris.
- Clean the filter pump's skimmer basket and pump strainer regularly.

5.3 Structural Integrity:

- Periodically inspect the pool frame, connections, and liner for any signs of wear, damage, or corrosion.
- Ensure all frame components are securely connected.
- Check for any leaks in the liner or connections and address them promptly.




Image: The Intex pool positioned in a beautiful outdoor landscape, emphasizing its aesthetic integration.

5.4 Winterization/Storage:

- At the end of the swimming season, thoroughly clean and dry all pool components.
- Disassemble the pool frame and liner according to the reverse of the assembly instructions.
- Store all parts in a dry, protected area, away from extreme temperatures and pests.

6. TROUBLESHOOTING

This section provides solutions to common issues you might encounter with your Intex pool.

Problem	Possible Cause	Solution
Water is cloudy or green.	Insufficient filtration, improper chemical balance, algae growth.	Run filter pump longer. Test and adjust water chemistry (chlorine, pH). Shock treat the pool with appropriate chemicals. Brush pool walls and vacuum.

Problem	Possible Cause	Solution
Filter pump not working.	Power issue, clogged filter, air in system, motor malfunction.	Check power connection and circuit breaker. Clean or replace filter media (sand). Bleed air from the system. Consult the pump manual or contact customer support if motor issue persists.
Water level dropping.	Evaporation, leak in liner or connections.	Normal evaporation occurs, especially in warm weather. Inspect liner for punctures and connections for loose fittings. Use a patch kit for small liner holes. Tighten hose clamps.
Pool frame unstable.	Uneven ground, improper assembly, damaged frame components.	Ensure pool is on a perfectly level surface. Re-check all frame connections and ensure they are fully engaged. Inspect metal tubes for bends or damage.

7. SPECIFICATIONS

Detailed technical specifications for the Intex Ultra XTR Rectangular Tubular Pool Kit.

Feature	Value
Product Dimensions (L x W x H)	7.32m x 3.66m x 1.32m
Ground Dimensions (L x W)	7.87m x 4.22m
Swimming Surface Dimensions (L x W)	7.03m x 3.30m
Model Number	26364GN
Height	132 centimeters
Length	732 centimeters
Width	366 centimeters
Item Weight	162.3 Kilograms
Material Type	Polyvinyl Chloride (PVC)
Capacity	31805 Liters
Color	Grey
Included Components	Sand filter SF80220RC-2 (4700 l/h, GS), safety ladder with removable steps (max. load 136 kg), ground protection sheet PE 75 g/m ² , polyethylene cover.

Feature	Value
Assembly Required	No (refers to the kit being complete, but assembly is required for setup)




Image: Technical diagram showing the approximate dimensions of the Intex Ultra XTR pool.

8. WARRANTY AND SUPPORT

For specific warranty information and customer support, please refer to the documentation included with your product or contact Intex directly.

- **Return Policy:** This product typically has a 30-day return policy from the date of purchase.
- **Manufacturer Support:** For technical assistance, missing parts, or warranty claims, please visit the official Intex website or contact their customer service department.
- You can also visit the [Intex Brand Store on Amazon](#) for more product information and related items.



Découvrez ce produit en réalité augmentée

Image: Scan this QR code to discover the product in augmented reality. [Access AR Experience](#)

© 2024 Intex. All rights reserved. This manual is for informational purposes only.