

Intex 26792UK

Intex Prism Frame Rectangular Pool Set User Manual

Model: 26792UK

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Intex 16 Ft. X 8 Ft. X 42 Inch Prism Frame Rectangular Pool Set. Please read all instructions carefully before setup, operation, and maintenance. Proper installation and adherence to safety guidelines are crucial for a safe and enjoyable swimming experience.

The Intex Prism Frame Pool is designed for above-ground use and offers a robust and stable structure for family recreation. It includes a filter pump, pool ladder, ground cloth, and pool cover for a complete setup.

SAFETY INFORMATION

- Always supervise children in and around the pool.
- Do not dive or jump into the pool.
- Ensure the pool is set up on a level, stable surface.
- Keep electrical components away from water.
- Regularly inspect the pool for damage or leaks.
- Follow all local regulations regarding pool safety and fencing.
- Do not allow rough play or running around the pool area.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Pool Liner (Rectangular Prism Frame)
- Metal Frame Components (Pipes and Connectors)
- Filter Pump System
- Pool Ladder
- Ground Cloth
- Pool Cover




Image: Overview of the Intex Prism Frame Rectangular Pool Set, illustrating its dimensions (16ft x 8ft x 42in) and the various components included in the set, such as the pump & filter, removable ladder, debris cover, and ground cloth.

SETUP

1. Site Preparation

Choose a firm, level area free of sharp objects, debris, and overhead power lines. The ground should be compacted and able to support the weight of the filled pool. Avoid setting up on slopes or soft ground. Ensure adequate drainage around

the pool area.

2. Ground Cloth Placement

Spread the ground cloth evenly on the prepared site. This protects the pool liner from punctures and provides a clean base.

3. Pool Assembly

1. Unfold the pool liner and lay it out on the ground cloth. Ensure the drain plug is facing the desired drainage area.
2. Assemble the metal frame components according to the diagrams in the separate assembly guide. Connect the horizontal beams and vertical legs, ensuring all pins and connectors are securely locked.
3. Thread the horizontal beams through the sleeves on the top edge of the pool liner.
4. Attach the vertical legs to the horizontal beams and the base of the pool liner.
5. Ensure all frame parts are fully inserted and aligned.



Image: The Intex Prism Frame Rectangular Pool fully assembled, showcasing its sturdy metal frame and grey exterior liner, ready for water filling. This image provides a clear view of the pool's structure.

4. Filling the Pool

Begin filling the pool with water. As the water level rises, gently smooth out any wrinkles in the bottom of the liner. Fill the pool to the recommended fill line, typically indicated on the inside of the liner or in the separate assembly guide.

5. Filter Pump and Ladder Installation

Install the filter pump system and pool ladder according to their respective instruction manuals. Ensure all connections are tight and the pump is placed on a stable surface away from the pool edge.

OPERATING THE POOL

Water Treatment

Maintain proper water chemistry by regularly testing pH and chlorine levels. Add appropriate pool chemicals as needed to

ensure clean and safe swimming water. Consult a pool supply professional for specific chemical recommendations for your region.

Filter Pump Operation

Operate the filter pump daily to circulate and filter the pool water. The duration of operation depends on pool size, usage, and environmental conditions. Refer to the filter pump manual for detailed operating instructions and filter cartridge replacement schedules.



Image: Close-up view of the Hydro Aeration Technology outlet within the pool, demonstrating the release of aerated water bubbles, which aids in water circulation and clarity.




Image: Detailed view of the Hydro Aeration Technology valve and its connection to the pool's filtration system, showing the external components responsible for water aeration.

MAINTENANCE

Daily Maintenance

- Skim debris from the water surface using a pool net.
- Check and adjust water chemistry (pH, chlorine) as needed.
- Run the filter pump for recommended hours.

Weekly Maintenance

- Vacuum the pool bottom to remove settled debris.
- Clean the filter cartridge or backwash the sand filter (if applicable).
- Inspect the pool liner and frame for any signs of wear or damage.

Seasonal Maintenance (Winterization/Storage)

Before storing the pool for the off-season, completely drain the water using the drain plug. Clean and thoroughly dry all components to prevent mold and mildew. Disassemble the frame and liner, storing them in a dry, protected area away

from extreme temperatures and pests.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Water is cloudy	Insufficient filtration, improper chemical balance, high organic load.	Run filter longer, test and adjust chemicals (chlorine, pH), shock treat the pool.
Pump not running	Power issue, clogged impeller, motor malfunction.	Check power connection, clear debris from impeller, consult pump manual or qualified technician.
Pool is leaking	Puncture in liner, loose hose connection, faulty drain plug.	Locate and patch the leak, tighten all connections, ensure drain plug is secure.
Frame instability	Uneven ground, improper assembly, damaged frame component.	Ensure pool is on level ground, re-check all frame connections, replace damaged parts.

SPECIFICATIONS

Feature	Detail
Model Number	26792UK
Dimensions (L x W x H)	16 ft. x 8 ft. x 42 inch (488 x 244 x 107 cm)
Material	Alloy Steel, Metal (Frame); Durable PVC (Liner)
Shape	Rectangular
Included Components	Pool Ladder, Filter Pump, Ground Cloth, Pool Cover
Power Source (Pump)	AC
Item Weight	85.75 kg

WARRANTY AND SUPPORT

For warranty information, technical support, or to order replacement parts, please contact Intex customer service. Refer to the contact details provided in the original product packaging or visit the official Intex website. Keep your proof of purchase for warranty claims.

Manufacturer: Intex

© 2024 Intex. All rights reserved.

This manual is for informational purposes only. Intex reserves the right to make product improvements without prior notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question