

[Manuals.plus](#) /

> [Intex](#) /

> Intex Magnetic LED Pool-Wall Light Instruction Manual

Intex 28698

Intex Magnetic LED Pool-Wall Light

Model: 28698 | Brand: Intex

INTRODUCTION

Thank you for purchasing the Intex Magnetic LED Pool-Wall Light. This innovative lighting solution is designed to provide illumination for your above-ground pool without the need for complicated wiring or cutting into the pool liner. Its magnetic design allows for easy installation and repositioning. Please read this manual thoroughly before installation and use to ensure safe and optimal performance.

SAFETY INFORMATION

- Always disconnect the light from the power source before performing any maintenance or cleaning.
- Ensure the power outlet is protected by a Ground Fault Circuit Interrupter (GFCI) or Residual Current Device (RCD).
- Do not operate the light if the power cord or plug is damaged.
- Keep children away from the electrical components.
- This product is designed for use with above-ground pools only. Do not use in in-ground pools or for other purposes.
- Do not attempt to open or modify the light unit. This will void the warranty and may pose a safety risk.
- Ensure the magnetic connection is secure before operating the light.

PACKAGE CONTENTS

Verify that all components are present:

- One magnetic Intex 230V LED lamp (consisting of an inner and outer unit)
- Power adapter with cable

SETUP AND INSTALLATION

Follow these steps to install your Intex Magnetic LED Pool-Wall Light:

1. **Unpack Components:** Carefully remove all items from the packaging.
2. **Separate Light Units:** The light consists of two magnetic units: one for inside the pool and one for outside. Gently pull them apart.
3. **Position Outer Unit:** Place the outer light unit (the one with the power cord) on the outside of the pool wall, ensuring it is at the desired height and location.
4. **Position Inner Unit:** Align the inner light unit on the inside of the pool wall, directly opposite the outer unit. The strong magnets will hold the two units securely through the pool liner.
5. **Connect Power:** Connect the power cable from the outer light unit to the power adapter. Then, plug the power adapter into a suitable 230V electrical outlet. Ensure the outlet is dry and protected from water.



Figure 1: Proper installation of the Intex Magnetic LED Pool-Wall Light on an above-ground pool wall. The outer unit is placed on the exterior, and the inner unit is magnetically attached on the interior.

Your browser does not support the video tag.

Video 1: Demonstration of the 230V Magnetic LED Pool-Wall Light setup and connection. This video shows the components and how to connect the power supply.

OPERATING INSTRUCTIONS

The Intex Magnetic LED Pool-Wall Light features controls directly on the outer unit. There are typically two separate buttons to control the inner and outer lights independently.

- **Power On/Off:** Press the respective button on the outer unit to turn the inner or outer light on. Press again to cycle through modes or turn off.
- **Color Modes:** Repeatedly press the button to cycle through various color modes, including white light and color-changing sequences.
- **Important Note:** This light does not retain its last setting if power is disconnected. It will need to be manually turned on and set to the desired color mode each time power is restored. It is not designed for use with external timers or remote controls that cut power.

Your browser does not support the video tag.

Video 2: A closer look at the Intex Magnetic LED Pool-Wall Light, demonstrating its features and operation.

MAINTENANCE

To ensure the longevity and optimal performance of your light:

- **Cleaning:** Periodically wipe down the outer unit with a damp cloth. For the inner unit, use a soft brush or cloth to remove any algae or debris. Do not use abrasive cleaners.
- **Storage:** During off-season or when not in use for extended periods, disconnect the light from power, clean both units, and store them in a dry, cool place away from direct sunlight.
- **Cable Inspection:** Regularly inspect the power cable and plug for any signs of damage, fraying, or corrosion. If damage is found, discontinue use immediately and contact customer support.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power to the unit.	Check if the power adapter is securely plugged into a working outlet. Ensure the outlet has power.
Light turns off unexpectedly.	Loose connection or power interruption.	Check all cable connections. Ensure the magnetic units are securely attached to the pool wall.
Light is dim or flickering.	Insufficient power or unit malfunction.	Ensure the power adapter is correctly connected. If the problem persists, the unit may require replacement.
Cannot control light with external timer/remote.	Product design limitation.	The light requires manual activation after power interruption and does not save its last state. This is a design feature.

SPECIFICATIONS

Feature	Detail
Model Number	28698

Feature	Detail
Part Number	6941057413969
Brand	Intex
Color	Color Change
Material	Magnet
Power Source	Corded Electric
Weight	6.45 Kilograms
Batteries Required	1 12V Battery (for internal components, not user replaceable)
First Available on Amazon.de	July 8, 2018

WARRANTY AND SUPPORT

For warranty information, technical support, or to purchase replacement parts, please contact Intex customer service. Refer to the contact details provided with your product packaging or visit the official Intex website. Keep your proof of purchase for warranty claims.