



[Manuals.plus](#) /

> [Intex](#) /

> Intex Whale Spray Pool User Manual

Intex 57440NP

Intex Whale Spray Pool Instruction Manual

Model: 57440NP

Brand: Intex

IMPORTANT SAFETY INFORMATION

WARNING: Children can drown in very small amounts of water. Always empty the pool when not in use. Constant adult supervision is required. Never leave children unattended in or near the pool. Do not install the paddling pool on concrete, asphalt, or any other hard surfaces. Always place the pool on a soft, level surface.

This product is intended for outdoor use only. Keep children within arm's reach. Ensure the area around the pool is clear of obstacles and hazards.



Image: Children and an adult enjoying the Intex Whale Spray Pool, demonstrating the need for constant supervision.

PRODUCT OVERVIEW

The Intex Whale Spray Pool is a fun and engaging inflatable pool designed for children. It features a unique whale design with a built-in sprayer that attaches to a standard garden hose, providing a continuous water spray for added enjoyment. The pool is constructed from durable 11ga (0.28mm) vinyl and includes two air chambers for stability.

- **Approx. Inflated Size:** 201 cm x 196 cm x 91 cm (79.13"L x 77.17"W x 35.83"H)
- **Water Capacity:** 53 gallons (200 L) at 18 cm (7 inches) wall height
- **Material:** Durable 11ga (0.28mm) Vinyl
- **Features:** Built-in sprayer, two air chambers with double valves, practical drain plug
- **Included:** Repair patches



Image: The Intex Whale Spray Pool, showcasing its full inflated form and the water spray feature.

SETUP AND ASSEMBLY

1. **Choose a Location:** Select a flat, level, and soft surface for the pool. Ensure there are no sharp objects, rocks, or debris that could puncture the vinyl. Avoid concrete, asphalt, or other hard surfaces.
2. **Unfold the Pool:** Carefully unfold the pool and lay it flat in your chosen location.
3. **Inflate the Air Chambers:** The pool has two air chambers. Locate the double valves on each chamber. Use an air pump (not included) to inflate each chamber until it is firm to the touch but not overinflated. Overinflation can cause damage. Ensure both valves are securely closed after inflation.
4. **Connect the Sprayer:** Locate the spray nozzle connection point, typically on the whale's tail or fin. Attach a standard garden hose to this connection point. Ensure the connection is secure to prevent leaks.



Image: A detailed view of the hose connection point on the Intex Whale Spray Pool, where a garden hose attaches for the spray feature.

OPERATION

1. **Fill with Water:** Begin filling the pool with water. The recommended water level is 18 cm (7 inches) from the wall height, which corresponds to approximately 53 gallons (200 L). Do not overfill.
2. **Activate Sprayer:** Once the pool is filled, turn on the water supply to the garden hose connected to the sprayer. Water will begin to spray from the whale's tail/fin.
3. **Supervision:** Always ensure constant adult supervision when children are in or near the pool. Never leave children unattended.
4. **Drain Plug:** The practical drain plug is located at the bottom of the pool for easy water removal.

MAINTENANCE

- **Emptying the Pool:** When not in use, or for cleaning, always empty the pool completely. Locate the drain plug at the bottom of the pool, open it, and allow the water to drain.
- **Cleaning:** Clean the pool regularly with mild soap and water. Rinse thoroughly and allow to air dry completely before folding and storing. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Ensure the pool is completely dry before deflating and folding. Store in a cool, dry place away from direct sunlight and extreme temperatures. Protect from rodents and insects.
- **Repairing Punctures:** If a small puncture occurs, use the included repair patches. Clean and dry the affected area thoroughly. Apply the patch firmly over the hole, ensuring no air bubbles. Allow sufficient time for the patch to bond before re-inflating.



Image: A close-up view of the practical drain plug located at the bottom of the Intex Whale Spray Pool, designed for easy water drainage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Pool deflates quickly.	Puncture or loose valve cap.	Locate the leak (use soapy water), clean and dry the area, and apply a repair patch. Ensure valve caps are tightly closed.
Sprayer not working or weak.	Hose not connected properly, low water pressure, or kink in hose.	Check hose connection for tightness. Ensure water supply is fully open. Straighten any kinks in the garden hose.
Water not draining.	Drain plug not fully open or obstructed.	Ensure the drain plug is fully removed or opened. Check for any debris blocking the drain hole.

SPECIFICATIONS

- **Model Number:** 57440NP
- **Brand:** Intex
- **Product Dimensions (Inflated):** 201 cm L x 196 cm W x 91 cm H (79.13"L x 77.17"W x 35.83"H)
- **Shape:** Whale
- **Material:** Vinyl (11ga / 0.28mm)
- **Water Capacity:** 200 Liters (53 Gallons) at 18 cm (7 inches) wall height
- **Age Range:** Kid
- **Occupancy:** 1 (recommended)
- **Special Features:** Built-In Sprayer, Drain Hole
- **Assembly Required:** Yes
- **Estimated Assembly Time:** 1 Hour
- **Included Components:** Repair patches
- **Item Weight:** Approximately 1.1 Grams (0.039 ounces) -*Note: This weight seems unusually low for the product, likely a data entry error for packaging weight.*
- **Maximum Weight Recommendation:** 20 Kilograms

WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact Intex customer service directly. Keep your proof of purchase for any warranty claims.

You can typically find contact information on the product packaging or by visiting the official Intex website. [Visit Intex Official Website](#)

