

[Manuals.plus](#) /

› [Easytry123](#) /

› Easytry123 Replacement Remote Control User Manual

Easytry123 Easytry1407

Easytry123 Replacement Remote Control User Manual

Model: Easytry1407

INTRODUCTION

This manual provides comprehensive instructions for the proper use and care of your Easytry123 Replacement Remote Control. This infrared replacement remote is designed to operate various Fujitsu Room Air Conditioner models, including ASH12LSACW, ASYG09LLC, RS09UA, RSG09LKC, RSG12LKC, ASYG12LLC, ASY35U, ASY25UA, ASY35UA, and AST9USACW. Please ensure your original remote matches the appearance of this replacement for full compatibility.

SETUP

Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Figure 1: Rear view of the remote control with the battery cover removed, illustrating the battery compartment and polarity markings. The label indicates "REMOTE CONTROL UNIT MODEL: AR-JE4" and "BATTERY: AAA/R03/LR03x2".

Important: Do not mix old and new batteries. Do not mix different types of batteries (e.g., alkaline and rechargeable) together. Remove batteries if the remote will not be used for an extended period.

OPERATING INSTRUCTIONS

This section details the functions of the buttons on your replacement remote control.



Figure 2: Front view of the remote control displaying its LCD screen and various control buttons for air conditioner functions.

- **START/STOP Button** (Orange): Press to turn the air conditioner ON or OFF.
- **MODE Control Buttons** (Under "MASTER CONTROL"):
 - **AUTO:** Automatically selects the operating mode based on room temperature.

- **COOL:** For cooling operation.
- **DRY:** For dehumidification.
- **FAN:** For fan-only operation without heating or cooling.
- **HEAT:** For heating operation.
- **SET TEMP. Buttons** (Up/Down Arrows): Adjust the desired temperature setting.
- **FAN CONTROL Buttons** (Under "FAN CONTROL"):
 - **AUTO:** Fan speed adjusts automatically.
 - **HIGH, MED, LOW:** Manually select fan speed.
 - **QUIET:** For low noise operation.
- **COIL DRY Button:** Activates the coil dry function to prevent mold growth.
- **SLEEP Button:** Activates sleep mode for comfortable night operation.
- **TEST RUN Button:** For service or diagnostic purposes.
- **SET Button:** Used to confirm settings, often in conjunction with timer functions.
- **SWING Button:** Controls the vertical swing of the air outlet louvers.
- **ACL Button:** Likely a reset button, often requiring a pointed object to press.
- **TIMER Buttons:**
 - **OFF:** Sets the off-timer.
 - **ON:** Sets the on-timer.
 - **SET:** Confirms timer settings.
 - **CANCEL:** Cancels active timer settings.

Note: Not all functions may be supported by every air conditioner model. Compatibility depends on the original remote's features.

MAINTENANCE

Cleaning the Remote Control

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water and a mild detergent, then wipe dry immediately.
- Do not use volatile liquids such as benzene, alcohol, or paint thinner, as they may damage the surface or internal components.

Battery Replacement

Replace batteries when the remote's range decreases or the display becomes dim. Refer to the "Battery Installation" section under Setup for detailed steps.

TROUBLESHOOTING

- **Remote not responding:**
 - Check if batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new ones.

- Ensure there are no obstructions between the remote control and the air conditioner's receiver.
- Confirm the remote is pointed directly at the air conditioner's indoor unit.

- **Some functions not working:**

- This replacement remote may not support all functions of your original air conditioner remote if your original had unique features not present on this standard replacement.
- Verify that your air conditioner model is listed as compatible.

- **Short operating range:**

- Batteries may be low; replace them.
- Ensure the remote's infrared emitter and the air conditioner's receiver are clean and unobstructed.

SPECIFICATIONS

Model Number	Easytry1407
Brand	Easytry123
Connectivity Technology	Infrared
Controller Type	Button Control
Power Source	2 x AAA Batteries (not included)
Color	Grey
Manufacturer	Easytry123
Country of Origin	China

WARRANTY INFORMATION

This product is typically covered by a standard manufacturer's warranty against defects in materials and workmanship. Please refer to the seller's return policy or contact the manufacturer directly for specific warranty terms and conditions. Keep your purchase receipt as proof of purchase.

SUPPORT

For any questions, concerns, or technical assistance regarding your Easytry123 Replacement Remote Control, please contact the seller or manufacturer through the platform where the product was purchased. When contacting support, please provide your product model number (Easytry1407) and a detailed description of the issue. You may also refer to the product listing on Amazon for additional information or frequently asked questions[Product Link](#)

