

## Easytry123 Easytry1406

# Instruction Manual for Easytry123 Replacement Remote Control

Model: Easytry1406

## INTRODUCTION

This manual provides essential information for the proper use and maintenance of your Easytry123 replacement infrared remote control, model Easytry1406. This remote is designed as a direct replacement for various Fujitsu Room Air Conditioner models, including AST12ASJCW, AST12LSACW, AR-JE4, AR-WS, ASYG12LLCA, AST9ASJCW, AST9LSACW, AST12USACW, and AST9FMBD.

It is crucial to ensure that your original remote control visually matches the replacement remote shown in this manual for full compatibility. While designed as a replacement, some advanced functions present on your original remote may not be fully replicated. This remote operates using infrared technology.

## SETUP

### Battery Installation

The remote control requires two (2) AAA batteries for operation. Please follow the steps below to install the batteries correctly:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Incorrect battery polarity can prevent the remote from functioning.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.

**Important:** Do not mix old and new batteries. Do not mix different types of batteries (e.g., alkaline and rechargeable) together. Remove batteries if the remote control will not be used for an extended period to prevent leakage.



Figure 1: Rear view of the remote control with the battery compartment open, illustrating where to insert AAA batteries.

## Initial Use

Once batteries are installed, the remote control is ready for use. Point the remote directly at the infrared receiver on your Fujitsu air conditioner unit. Ensure there are no obstructions between the remote and the air conditioner.

## OPERATING INSTRUCTIONS

This section outlines the basic functions and operation of your replacement remote control. Button layouts may vary slightly from your original remote, but core functions are typically labeled clearly.



Figure 2: Front view of the remote control, displaying the LCD screen and control buttons.

## Power On/Off

- Press the **START/STOP** button (often orange or prominently marked) to turn the air conditioner unit

ON or OFF.

## Mode Selection

Use the **MODE** button (or similar labeled button like AUTO, COOL, DRY, HEAT, FAN) to cycle through the available operating modes:

- **AUTO:** The unit automatically selects the operating mode (cooling, heating, or fan) based on the room temperature.
- **COOL:** Provides cooling operation.
- **DRY:** Dehumidifies the room.
- **HEAT:** Provides heating operation (if supported by your AC unit).
- **FAN:** Circulates air without cooling or heating.

## Temperature Adjustment

- Use the **TEMP ▲** (Up) and **TEMP ▼** (Down) buttons to increase or decrease the desired room temperature.

## Fan Speed Control

Press the **FAN CONTROL** button (or similar labeled button like FAN SPEED) to adjust the fan speed.

Options typically include:

- **AUTO:** Fan speed adjusts automatically.
- **HIGH:** Maximum fan speed.
- **MED:** Medium fan speed.
- **LOW:** Minimum fan speed.
- **QUIET:** Ultra-low fan speed for quiet operation.

## Timer Function

The timer function allows you to set the air conditioner to turn on or off automatically after a set period.

- Press the **TIMER ON** or **TIMER OFF** button.
- Use the temperature adjustment buttons (▲/▼) to set the desired time.
- Press **SET** to confirm the timer setting.
- To cancel a timer, press the **CANCEL** button.

## Swing Function

- Press the **SWING** button to activate or deactivate the automatic louver swing function, which helps distribute air evenly.

## Sleep Mode

- Press the **SLEEP** button to activate sleep mode, which typically adjusts temperature and fan speed for comfortable sleep and energy saving.

## MAINTENANCE

---

### Cleaning the Remote Control

To maintain the remote control's appearance and functionality:

- Wipe the surface of the remote control with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water and a mild detergent, then wipe dry immediately.
- Do not use volatile liquids such as benzene, alcohol, or paint thinner, as they may damage the surface or internal components.

## Battery Replacement

Replace the batteries when the remote control's range decreases or if the display becomes dim or unresponsive. Refer to the "Battery Installation" section under Setup for detailed steps.

## TROUBLESHOOTING

If you experience issues with your remote control, please refer to the following common solutions:

Problem	Possible Cause	Solution
Remote control not working.	Dead or incorrectly installed batteries.	Replace batteries with new AAA batteries, ensuring correct polarity.
Remote control range is poor.	Weak batteries; Obstruction between remote and AC unit.	Replace batteries. Ensure clear line of sight to the AC unit's infrared receiver.
AC unit does not respond to certain buttons.	Function not supported by this replacement remote or specific AC model.	Verify if the function was available on your original remote. This replacement may not support all advanced features. Ensure your AC model is listed as compatible.
Remote display is dim or blank.	Low battery power.	Replace batteries.

If the issue persists after trying these solutions, please ensure your original remote control matches the appearance of this replacement. If your model is not explicitly listed as compatible, the remote may not function correctly.

## SPECIFICATIONS

**Model Number:** Easytry1406

**Brand:** Easytry123

**Compatible Devices:** Fujitsu Room Air Conditioners (specific models listed in Introduction)

**Connectivity Technology:** Infrared (IR)

**Power Source:** 2 x AAA Batteries (not included)

**Color:** Grey

**Special Feature:** Replacement remote, ergonomic design.

## WARRANTY AND SUPPORT

This product is an aftermarket replacement remote control. Specific warranty information is not provided with this manual. For any operational issues or compatibility concerns not addressed in this manual, it is recommended to contact the seller or refer to the product listing where you purchased the item for support details.

Please note that this replacement remote may not offer all the exact same functions as your original remote. If you have doubts about compatibility, it is advised to contact the seller before purchase.