

[Manuals.plus](#) /

> [Skyworth](#) /

> Skyworth 81 cm (32 Inches) HD Ready LED Smart TV 32 M20 User Manual

## Skyworth 32 M20

# Skyworth 81 cm (32 Inches) HD Ready LED Smart TV 32 M20

## USER MANUAL

### Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your Skyworth 32 M20 HD Ready LED Smart TV. Please read this manual thoroughly before using your television to ensure safe and optimal performance. Keep this manual for future reference.

### Setup

Follow these steps to set up your new Skyworth Smart TV.


#### 1. Unpacking

Carefully remove the TV and all accessories from the packaging. Retain the packaging materials for future transport or service needs.

#### 2. Attaching the Stand or Wall Mounting

If using the included stand, align the stand with the designated slots on the bottom of the TV and secure it with the provided screws. Ensure the stand is stable before placing the TV on a flat, sturdy surface.

If wall mounting, refer to the instructions provided with your wall mount kit. Ensure the wall mount is compatible with VESA standards for a 32-inch TV and is securely installed on a suitable wall structure.






Side view of the Skyworth 32 M20 Smart TV, illustrating its slim profile and potential side port locations.

### 3. Connecting Cables

Connect the power cord to the TV's power input and then to a wall outlet. Connect your external devices (e.g., set-top box, gaming console, Blu-ray player) to the appropriate ports on the TV.

- **HDMI:** For high-definition audio and video. Your TV has 2 HDMI ports.
- **USB:** For connecting USB storage devices. Your TV has 2 USB ports.
- **Antenna/Cable:** Connect your antenna or cable TV feed.
- **Ethernet (LAN):** For a wired internet connection.



Rear view of the Skyworth 32 M20 Smart TV, highlighting the various input and output ports for connectivity.

### 4. Initial Power On

Press the power button on the TV or the remote control. Follow the on-screen instructions to complete the initial setup, including language selection, network connection (Wi-Fi or Ethernet), and channel scanning.

## Operating

Learn how to navigate and use the features of your Skyworth Smart TV.

### 1. Remote Control Overview

The remote control allows you to access all TV functions. Familiarize yourself with the buttons for power, volume, channel, input source, smart TV navigation, and menu access.

### 2. Basic Navigation

Use the arrow keys and OK button on your remote to navigate through menus and select options. The 'Back' or 'Return' button will take you to the previous screen, and the 'Home' button will bring you to the main Smart TV interface.



The Skyworth 32 M20 Smart TV displaying its intuitive smart interface with various application tiles.

### 3. Smart TV Features

Your Skyworth 32 M20 runs on an Android-based operating system and features built-in Wi-Fi. You can connect to the internet to browse websites, stream content, and download applications from the app store.

- **Wi-Fi Connectivity:** Access network settings to connect to your home Wi-Fi network.
- **Browser:** Use the integrated web browser to surf the internet.
- **Apps:** Download and install various applications for entertainment, news, and more.
- **Mobile Mirroring:** Connect your mobile device to mirror its screen content on the TV.





A close-up of the Skyworth 32 M20 Smart TV screen, showing a grid of various application icons available on the smart platform.

## 4. Picture and Sound Settings

Access the TV's settings menu to adjust picture modes (e.g., Standard, Dynamic, Movie), brightness, contrast, color, and sharpness. For audio, you can select sound modes (e.g., Standard, Music, Movie) and adjust bass, treble, and balance. The TV features 20 Watts sound output with Surround audio mode.

## Maintenance

Proper care will extend the life of your television.

### 1. Cleaning the Screen

Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, use a screen-cleaning solution specifically designed for electronics, applied to the cloth, not directly to the screen.

### 2. Cleaning the Body

Use a soft, dry cloth to clean the TV's frame and stand. Avoid using abrasive cleaners or solvents.

### 3. Software Updates

Periodically check for software updates through the TV's settings menu to ensure optimal performance and access to the latest features. Follow the on-screen prompts for any available updates.

## Troubleshooting

This section addresses common issues you might encounter with your TV.

- **No Power:** Ensure the power cord is securely plugged into both the TV and a working electrical outlet. Try a different outlet.
- **No Picture/No Sound:** Check that the correct input source is selected. Verify all cable connections (HDMI, antenna, etc.) are secure.
- **Remote Control Not Working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.
- **Network Connection Issues:** For Wi-Fi, ensure your router is on and within range. For wired connections, check the Ethernet cable. Try restarting your router and the TV.
- **Cannot Adjust Color/Contrast:** Some users have reported limited control over color brightness and contrast. Ensure you are in a picture mode that allows for manual adjustments. If the issue persists, consult the warranty and support section.

## Specifications

Key technical specifications for the Skyworth 32 M20 Smart TV.

Feature	Specification
Model Name	32 M20
Screen Size	32 Inches (81 cm)
Resolution	HD Ready (1366 x 768 pixels)
Display Technology	LED, IPS LED panel
Refresh Rate	60 Hz
Operating System	Android
Connectivity	2 x HDMI, 2 x USB, Wi-Fi, Ethernet (LAN)
Audio Output	20 Watts, Surround Sound
Mounting Type	Wall Mount
Viewing Angle	178 Degrees

## Warranty and Support

Your Skyworth 32 M20 Smart TV comes with a brand warranty. For specific warranty terms, conditions, and duration, please refer to the warranty card included with your product or contact Skyworth customer support directly. Keep your purchase receipt as proof of purchase.

For technical assistance, service requests, or further inquiries, please contact Skyworth's official customer support channels. Contact information can typically be found on the manufacturer's website or in the product packaging.