

[Manuals.plus](#) /

> [Invicta](#) /

> Invicta Men's Pro Diver Quartz Watch Model 26970 Instruction Manual

Invicta 26970

Invicta Men's Pro Diver Quartz Watch Model 26970 Instruction Manual

This manual provides detailed instructions for the proper use and care of your Invicta Pro Diver Quartz Watch.

INTRODUCTION

The Invicta Pro Diver watch is designed for reliable timekeeping and performance, suitable for various activities including professional marine use and surface water sports. This timepiece features a durable stainless steel construction, a precise Japanese quartz movement, and water resistance up to 200 meters. Adherence to these instructions will ensure the longevity and optimal performance of your watch.

SETUP

Unboxing

Carefully remove your watch from its packaging. Inspect the watch for any visible damage or manufacturing defects before initial use.




Image: Invicta Pro Diver Quartz Watch, Model 26970, presented in its original packaging.

Adjusting the Watch Band

The stainless steel band is adjustable by adding or removing links to achieve a comfortable and secure fit. For proper adjustment, it is highly recommended to have this procedure performed by a qualified jeweler or watch technician. Improper adjustment can damage the band pins or the watch itself.





Image: Close-up view of the watch's stainless steel band, highlighting the removable links and pins for size adjustment.

Setting Time and Date

Your watch features a screw-down crown for enhanced water resistance. Follow these steps to set the time and date:

1. To access the crown, unscrew it by turning it counter-clockwise until it releases and springs out.
2. **Setting the Time:** Pull the crown out to the **second position**. Rotate the crown to move the hour and minute hands to the desired time.
3. **Setting the Date:** Push the crown in slightly to the **first position**. Rotate the crown to adjust the date. *Avoid setting the date between 9 PM and 3 AM*, as this can interfere with the automatic date change mechanism and potentially damage the movement.
4. Once the time and date are set, push the crown back in completely and screw it clockwise firmly against the watch case. This ensures the watch maintains its water resistance.




Image: Detailed view of the watch's crown and the magnified date window on the dial.

OPERATING YOUR WATCH

Uni-directional Bezel

The watch is equipped with a uni-directional rotating bezel. This feature is useful for timing events, such as dive times or elapsed minutes. To use, rotate the bezel counter-clockwise until the zero marker (triangle) aligns with the minute hand. The minute hand will then indicate the elapsed time on the bezel's scale.



Weight 140g/0.31lb

Band Width
20mm/0.79in

Strap Length
180mm/7in

Dial Diameter
40mm/1.57in



Dial Thickness 12.5 mm/0.49 in



Movement Japanese Quartz



Band Material Stainless Steel

Image: Close-up of the watch's black uni-directional bezel with minute markers.

Luminous Hands and Hour Markers

The watch's hands and hour markers are treated with luminous material to provide visibility in low-light conditions. Exposure to natural or artificial light will charge the luminescence, allowing them to glow in the dark.

Water Resistance

This Invicta Pro Diver watch is water resistant to 200 meters (660 feet). This rating makes it suitable for professional marine activity, surface water sports, and diving. **Crucially, always ensure the screw-down crown is fully secured and tightened against the watch case before exposing the watch to water.** Failure to do so will compromise the water resistance and may lead to internal damage.

Deep Water Resistant

200 Meters / 660 Feet



Image: The Invicta Pro Diver watch partially submerged in water, illustrating its water-resistant capabilities.

MAINTENANCE

Cleaning

To maintain the appearance and hygiene of your watch, regularly clean it with a soft, damp cloth. For the stainless steel case and band, a mild soap solution can be used, followed by thorough rinsing with fresh water and careful drying with a soft, lint-free cloth. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the watch's finish or seals.

Battery Replacement

The watch is powered by a Japanese quartz movement that requires an SR626SW battery. When the battery life

expires, the watch hands may stop or exhibit irregular movement. It is recommended to have the battery replaced by an authorized service center to ensure the correct battery type is installed and the watch's water resistance is properly resealed.

Crystal Care

The watch features a Flame Fusion crystal, which offers enhanced scratch resistance. While durable, it is not entirely scratch-proof. Avoid unnecessary impacts or contact with abrasive materials to prevent scratches or damage to the crystal surface.

TROUBLESHOOTING

- **Watch Not Keeping Time:** If your watch is not keeping accurate time or has stopped, first ensure the crown is fully pushed in and screwed down. If the issue persists, the battery may need replacement.
- **Moisture or Water Inside the Watch:** If you observe any moisture or water condensation inside the watch, immediately take it to an authorized service center. This indicates a compromised water seal, which requires immediate attention to prevent further damage to the internal components.
- **Band Discomfort or Damage:** If the watch band causes discomfort, irritation, or shows signs of damage, have it inspected by a professional. Ensure the band is not too tight or too loose.

SPECIFICATIONS

Feature	Detail
Case Diameter	40mm
Case Thickness	12.5mm
Dial Color	Black
Movement Type	Japanese Quartz (PC32 Caliber)
Battery	SR626SW
Band Material	Stainless Steel
Band Length	180mm
Band Width	20mm
Crystal Type	Flame Fusion
Crown Type	Screw-down
Bezel	Uni-directional Stainless Steel with Black Top Ring
Water Resistance Depth	200 Meters (660 Feet)
Watch Weight	140 grams
Additional Features	Luminous Hands and Hour Markers, Magnified Date Window

WARRANTY AND SUPPORT

Limited Warranty

Your Invicta watch is covered by a limited warranty. Please refer to the specific warranty information and registration details provided in the documentation included with your watch. This document outlines the terms, conditions, and duration of your warranty coverage.

Customer Support

For any questions, technical assistance, service requests, or general support regarding your Invicta watch, please visit the official Invicta website or contact their customer service department directly. Contact information can typically be found on the manufacturer's website or in your warranty booklet.

OFFICIAL PRODUCT VIDEO

Video: A general promotional video showcasing various Invicta watches. For specific operational instructions for Model 26970, please refer to the sections above.