

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Skyworth](#) /

› [Skyworth 49 M20 Full HD LED Smart TV User Manual](#)

Skyworth 49 M20

Skyworth 49 M20 Full HD LED Smart TV User Manual

Model: 49 M20

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Skyworth 49 M20 Full HD LED Smart TV. Please read it thoroughly before using the product and retain it for future reference.



Figure 1: Front view of the Skyworth 49 M20 Full HD LED Smart TV.

SETUP AND INSTALLATION

Unpacking the TV

Carefully remove all components from the packaging. Ensure all items listed below are present.

What's in the Box:

- 1 LED TV
- 1 Table Top Stand
- 1 Wall Mount Bracket
- 1 User Manual
- 1 Warranty Card
- 1 Remote Control
- 2 AAA Batteries
- 1 Power Cable / Power Supply Adapter

Your browser does not support the video tag.

Video 1: Unboxing and initial overview of the Skyworth 49 M20 Smart TV.

Stand Installation

If using the table-top stand, attach it securely to the base of the TV using the provided screws. Refer to the diagram for correct orientation.

Wall Mounting

For wall mounting, use the included wall mount bracket. It is recommended to seek professional assistance for wall mounting to ensure safety and proper installation. Contact Skyworth at **18001210108** for installation services.





Figure 2: Side view of the TV, illustrating the slim design and stand attachment points.

CONNECTIVITY

Your Skyworth 49 M20 TV offers various ports for connecting external devices.

Available Ports:

- **3 HDMI Ports:** For connecting set-top boxes, Blu-Ray players, gaming consoles, and other HDMI-enabled devices.
- **2 USB Ports:** For connecting hard drives, USB flash drives, and other USB devices to play media files.
- **1 VGA Port:** For connecting laptops or desktop computers.




Figure 3: Rear panel of the TV, highlighting the various input and output ports.



Figure 4: Detailed view of the connectivity ports including HDMI, USB, and VGA.

OPERATING YOUR SMART TV

Powering On/Off

Connect the power cable to the TV and a power outlet. Press the power button on the remote control or on the TV to turn it on or off.

Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup process, including language selection, network connection, and channel scanning.

Smart TV Features

The Skyworth 49 M20 is an Android-based Smart TV with built-in Wi-Fi, offering access to a variety of applications and online content.

- **Built-in Wi-Fi:** Connect to your home network for internet access.
- **Netrange App Store:** Download and install applications for movies, music, games, and more.
- **Install APK:** Allows installation of additional applications via APK files.
- **Sky Share:** Share media files (videos, pictures) from your mobile phone to the TV.
- **Home Network:** Access media content from other devices on your home network.
- **Supported Internet Services:** Includes Twitter and YouTube.



Figure 5: The Smart TV home screen interface, showing various app icons.





Figure 6: The Netrange App Store interface, displaying available applications.

Your browser does not support the video tag.

Video 2: Overview of the Skyworth Full HD IPS Smart LED TV features, including display, smart functions, and connectivity.

DISPLAY AND AUDIO

Display Technology

The TV features a 49-inch Full HD (1920x1080p) IPS LED panel with a 60 Hz refresh rate. The IPS technology provides a wide 178-degree viewing angle, ensuring consistent picture quality from various positions.

Audio System

Equipped with 20 Watts output and down-firing speakers, the TV delivers clear audio. DTS Sound technology enhances the audio experience.

TECHNICAL SPECIFICATIONS

Feature	Detail
Model	49 M20
Screen Size	49 Inches (124.5 cm)
Display Technology	IPS LED Panel
Resolution	Full HD (1920 x 1080p)
Refresh Rate	60 Hertz
Viewing Angle	178 Degrees
Operating System	Android
Processor	ARM Quad Core Processor
GPU	Dual Core 3D GPU
RAM	512MB
ROM	4GB
Connectivity	3 HDMI, 2 USB, 1 VGA, Built-in Wi-Fi
Audio Output	20 Watts
Sound Technology	DTS Sound, Down Firing Speakers
Product Dimensions (LxWxH)	111.1 x 27.1 x 68.9 cm
Item Weight	16 kg
Batteries	2 AAA batteries (included for remote)



TV FEATURES

Screen	49 inches Full HD (1920x1080p)
Connectivity ports	3 HDMI ports 2 USB ports 1 VGA Port
Display	IPS LED panel 60 Hertz
Sound	20 Watts, with DTS Surround Sound
Smart TV	Yes, with Built-in WiFi (AOSP)
Warranty*	Yes, Brand Warranty

*Please check warranty information box below for details on warranty

Figure 7: Summary of key TV features including screen size, connectivity, display, sound, and smart TV capabilities.

TROUBLESHOOTING

This section addresses common issues you might encounter with your TV. For more complex problems, please contact customer support.

No Power

- Ensure the power cable is securely connected to both the TV and a working power outlet.
- Check if the power outlet is functioning by plugging in another device.
- Verify that the power indicator light on the TV is on.

No Picture/Sound

- Confirm the correct input source is selected (e.g., HDMI 1, AV).
- Check all cable connections (HDMI, AV, etc.) between the TV and external devices.
- Ensure the volume is not muted or set too low.

Wi-Fi Connection Issues

- Restart your Wi-Fi router and the TV.
- Ensure the TV is within range of your Wi-Fi router.
- Verify the Wi-Fi password entered is correct.

Remote Control Not Working

- Replace the AAA batteries in the remote control.
- Ensure there are no obstructions between the remote control and the TV's IR sensor.

CARE AND MAINTENANCE

Cleaning the Screen

Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Avoid using harsh chemicals or abrasive materials.

General Cleaning

Wipe the TV's frame and stand with a soft, dry cloth. Do not spray cleaning liquids directly onto the TV.

Ventilation

Ensure adequate ventilation around the TV to prevent overheating. Do not block the ventilation openings on the back of the TV.

WARRANTY AND SUPPORT

Warranty Information

Your Skyworth 49 M20 TV comes with a **2-year standard manufacturer warranty** from Skyworth. Please retain your purchase invoice for warranty claims.

Customer Support

For installation, wall mounting, product demonstration, or any service-related queries, please contact Skyworth directly at **18001210108**. Provide the product's model name (49 M20) and seller's details from your invoice.

This product is eligible for replacement/refund within 10 days of delivery in case of any product defects, damage, or features not matching the description provided.