

**Manuals+**

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VIZIO](#) /

› [VIZIO SB362An-F6 36-inch 2.1 Channel Soundbar with Built-in Dual Subwoofers User Manual](#)

**VIZIO SB362An-F6**

# VIZIO SB362An-F6 36-inch 2.1 Channel Soundbar with Built-in Dual Subwoofers User Manual

Model: SB362An-F6 | Brand: VIZIO

## INTRODUCTION

This manual provides essential information for the safe and efficient operation of your VIZIO SB362An-F6 36-inch 2.1 Channel Soundbar with Built-in Dual Subwoofers. Please read these instructions thoroughly before use and retain them for future reference.



*Figure 1: Front view of the VIZIO SB362An-F6 Soundbar.*

## WHAT'S IN THE BOX

Verify that all components are present in the packaging:

- VIZIO SB362An-F6 36-inch 2.1 Channel Soundbar
- Remote Control (requires 2 AAA batteries, not included)
- Power Cord
- Optical Cable
- 3.5mm to 3.5mm Audio Cable (Auxiliary Cable)
- USB Cable
- Wall Mounting Brackets (2)
- Mounting Guide



Figure 2: Top view of the soundbar with integrated controls.

## SETUP

### Placement Options

The soundbar can be placed in two orientations: laid flat or upright. This allows for sound projection either upward or forward, depending on your preference and room acoustics.

- **Flat Placement:** Position the soundbar horizontally on a flat surface, such as a TV stand or shelf, directly below your television.
- **Upright Placement:** The soundbar can also be positioned vertically. Ensure stability in this orientation.
- **Wall Mounting:** Utilize the included brackets and mounting guide to securely attach the soundbar to a wall.



Figure 3: Side view of the soundbar, highlighting its trapezoid contour.

### Connecting the Soundbar

1. **Power Connection:** Connect the power cord to the soundbar's power input and then to a wall outlet.
2. **Audio Connection (Choose One):**
  - **Optical Cable:** For optimal digital audio quality, connect one end of the optical cable to the soundbar's OPTICAL input and the other end to your TV's OPTICAL OUT port.
  - **Auxiliary Cable:** Connect one end of the 3.5mm audio cable to the soundbar's AUX input and the other end to your TV's 3.5mm audio output or headphone jack.
  - **USB Cable:** Connect the USB cable to the soundbar's USB port and to a compatible USB audio source.
3. **Bluetooth Pairing:** To stream audio wirelessly from a mobile device, activate Bluetooth on your device and select the VIZIO soundbar from the list of available devices. Refer to your device's manual for specific pairing instructions.

## OPERATING INSTRUCTIONS

The soundbar features intuitive controls for an enhanced audio experience.

### Remote Control Functions

Use the included remote control to access all soundbar functions. Ensure batteries are correctly installed.



Figure 4: VIZIO Soundbar remote control.

- **Power:** Turns the soundbar on or off.
- **Input:** Cycles through available audio inputs (Optical, Aux, USB, Bluetooth).
- **Volume (+/-):** Adjusts the master volume level.
- **Mute:** Mutes or unmutes the audio.
- **EQ Modes:** Switch between preset equalizer modes (e.g., Music, Movie) to optimize audio for different content types.
- **Bass/Treble:** Adjust bass and treble levels to customize your sound.
- **Bluetooth Pairing:** Initiates Bluetooth pairing mode.

## Integrated Controls

Basic controls are also available on the soundbar itself, typically located on the top or side panel.

- **Power Button:** Turns the soundbar on or off.
- **Input Button:** Cycles through audio inputs.
- **Volume Buttons:** Adjusts the master volume.



Figure 5: Internal view highlighting the integrated dual subwoofers for enhanced bass.

## MAINTENANCE

To ensure the longevity and optimal performance of your soundbar, follow these simple maintenance guidelines:

- **Cleaning:** Gently wipe the soundbar's surface with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, as they may damage the finish.
- **Ventilation:** Ensure that the soundbar's vents are not obstructed to prevent overheating.
- **Storage:** If storing the soundbar for an extended period, disconnect it from power and store it in a cool, dry place.

## TROUBLESHOOTING

If you encounter issues with your VIZIO soundbar, refer to the following common solutions:

Problem	Solution
No Power	Ensure the power cord is securely connected to both the soundbar and a working electrical outlet.

Problem	Solution
No Sound	Verify the correct input source is selected on the soundbar. Check all audio cable connections (Optical, Aux, USB). Ensure the soundbar and TV are not muted and volume is up.
Bluetooth Disconnection	Ensure your Bluetooth device is within range (approx. 30 feet) and not connected to another device. Try re-pairing the device.
Poor Sound Quality	Adjust EQ modes, bass, and treble settings. Ensure audio cables are not damaged. For optical connections, check the cable for kinks or damage.

## SPECIFICATIONS

- **Model Name:** Vizio 36" 2.1-Channel Sound Bar
- **Model Number:** SB362AN-F6
- **Speaker Type:** Soundbar, Subwoofer (Built-in Dual Subwoofers)
- **Surround Sound Channel Configuration:** 2.1
- **Speaker Maximum Output Power:** 150 Watts
- **Connectivity Technology:** Auxiliary, Optical, USB, Bluetooth, Wi-Fi
- **Control Method:** Remote
- **Item Weight:** 7.5 Pounds
- **Material:** Metal, Plastic
- **Mounting Type:** Wall Mount
- **UPC:** 845226016653

## WARRANTY AND SUPPORT

Your VIZIO SB362An-F6 Soundbar comes with a **One-Year Warranty** from the date of purchase. For detailed warranty information, technical support, or service inquiries, please refer to the official VIZIO support channels or visit their website.

## PRODUCT OVERVIEW VIDEO

Your browser does not support the video tag.

*This video provides a general overview of the VIZIO Soundbar. Please refer to the official product specifications in this manual for exact features and connectivity options of the SB362An-F6 model.*