

## Fakir Ext 2500 Pump Nozzle L

# Fakir Ext 2500 Carpet Cleaner Pump Nozzle L Installation and Maintenance Guide

## 1. INTRODUCTION

This manual provides essential instructions for the proper installation, use, and maintenance of the Fakir Ext 2500 Carpet Cleaner Pump Nozzle L. This L-shaped nozzle is a critical component designed to ensure efficient spray distribution for effective carpet cleaning. Please read this guide thoroughly before attempting any installation or maintenance procedures to ensure safe and optimal performance.

## 2. SAFETY INSTRUCTIONS

- Always disconnect the Fakir Ext 2500 Carpet Cleaner from the power supply before installing, removing, or cleaning the pump nozzle.
- Ensure the carpet cleaner is completely depressurized and cooled down before handling any parts.
- Wear appropriate personal protective equipment, such as gloves, if handling cleaning solutions or if you have sensitive skin.
- Keep small parts, including the nozzle, out of reach of children.
- If the nozzle is damaged or cracked, do not attempt to repair it; replace it with a genuine Fakir replacement part.

## 3. INSTALLATION GUIDE

Follow these steps to correctly install or replace the pump nozzle on your Fakir Ext 2500 Carpet Cleaner.

1. **Preparation:** Ensure the carpet cleaner is turned off, unplugged, and any remaining water or cleaning solution has been drained from the tanks.
2. **Locate Nozzle Connection:** Identify the nozzle connection point on the spray head or wand of your Fakir Ext 2500. This is typically where the spray solution exits.
3. **Remove Old Nozzle (if applicable):** If replacing an existing nozzle, carefully unscrew or unclip the old nozzle. Note its orientation for correct installation of the new one.
4. **Attach New Nozzle:** Align the threaded end of the new Fakir Ext 2500 Pump Nozzle L with the connection point. Gently screw it in clockwise until it is finger-tight. Do not overtighten, as this can damage the threads or the nozzle itself.

5. **Secure Connection:** Ensure the nozzle is firmly seated and oriented correctly to direct the spray downwards onto the carpet surface.
6. **Test:** Reconnect the carpet cleaner to power, fill the solution tank, and perform a brief test spray in an inconspicuous area to confirm proper function and absence of leaks.



**Image 1:** The Fakir Ext 2500 Carpet Cleaner L-shaped Pump Nozzle. This image displays the black, L-shaped plastic component with a threaded end for attachment to the carpet cleaner's spray mechanism and an angled outlet for solution dispersion. The design facilitates precise application of cleaning solution.

## 4. CARE AND MAINTENANCE

---

Regular cleaning and maintenance will extend the life of your pump nozzle and ensure consistent performance.

- **After Each Use:** Flush the nozzle with clean water to remove any residual cleaning solution or debris that could cause blockages.
- **Deep Cleaning:** If blockages occur, carefully remove the nozzle from the carpet cleaner. Use a small, soft brush (like a toothbrush) or a thin wire to clear any obstructions from the spray opening. Do not use sharp objects that could damage the nozzle.
- **Storage:** Store the nozzle in a clean, dry place when not in use, preferably attached to the carpet cleaner or in its designated accessory storage.
- **Inspection:** Periodically inspect the nozzle for signs of wear, cracks, or damage. Replace if necessary to maintain optimal spray performance.

## 5. TROUBLESHOOTING

If you experience issues with the pump nozzle, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No spray or weak spray	Nozzle clogged; solution tank empty; pump malfunction.	Clean the nozzle as described in Section 4. Ensure solution tank is filled. Check the main unit's pump (refer to the main carpet cleaner manual).
Leaking from nozzle connection	Nozzle not tightened properly; damaged O-ring/seal; cracked nozzle.	Ensure the nozzle is securely tightened. Inspect for damaged seals and replace if necessary. If the nozzle is cracked, replace the entire nozzle.
Uneven spray pattern	Partial blockage in the nozzle.	Perform a deep clean of the nozzle to remove any partial obstructions.

## 6. SPECIFICATIONS

**Brand:** Fakir  
**Model Compatibility:** Fakir Ext 2500 Carpet Cleaner  
**Part Type:** Pump Nozzle (L-shaped)  
**Material:** Durable Plastic  
**ASIN:** B07FD9YM5D  
**First Available Date:** July 10, 2018