

Easytry123 Easytry1608

Remote Control Instruction Manual

Model: Easytry1608

1. INTRODUCTION

This manual provides essential information for the use and maintenance of your Easytry123 replacement remote control, model Easytry1608. This remote is designed as a direct infrared replacement for various Danby AC Air Conditioner models, including R09/BGCE, DAC7006DE, DAC7077EE, DAC8006DE, DAC8007EE, DAC10007EE, and DAC9006DE.

Please ensure your original remote control matches the appearance of the remote shown in this manual for proper compatibility. This replacement remote may not offer all functions present on your original unit.



Figure 1: Front view of the Easytry123 replacement remote control, showing buttons and LCD screen.

2. PRODUCT FEATURES

- Infrared (IR) replacement remote control.
- Designed to replace original remotes for specified Danby AC models.
- Ergonomic design for comfortable handling.
- Requires 2 AAA batteries for operation.

3. SETUP

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage.



Figure 2: Back view of the remote control, highlighting the battery compartment.

3.2 Initial Use

This remote control is an infrared replacement and typically does not require pairing. Once batteries are installed, point the remote directly at your Danby AC unit and press the power button to test functionality. If the AC unit responds, the remote is ready for use.

4. OPERATING INSTRUCTIONS

The remote control features various buttons for controlling your air conditioner. Below is a general guide to common functions. Button labels may vary slightly based on the specific remote version, but their positions are generally consistent.

Power Button (Red, central): Turns the air conditioner ON or OFF.

Mode Button: Cycles through operating modes such as Cool, Heat, Fan, Dry, Auto.

Swing Button: Activates or deactivates the automatic louver swing function.

ION Button: Activates the ionizer function (if available on your AC unit).

Follow Me Button: Activates the "Follow Me" function, where the remote acts as a thermostat sensor.

Sleep Button: Activates the sleep mode for quiet operation and energy saving during sleep.

Temperature Adjustment Buttons (Up/Down Arrows): Adjusts the desired temperature setting.

Fan Speed Button (FLÄKT): Adjusts the fan speed (e.g., Low, Medium, High, Auto).

Timer Button: Sets the timer for automatic ON/OFF operation.

Cancel Button (AVBRYT): Cancels the currently set timer or other functions.

Clock Button (KLOCKA): Sets the current time on the remote's display.

Reset Button (RESET): Resets the remote to default settings (often a small recessed button requiring a pin).

For detailed operation of specific AC unit features, please refer to your Danby Air Conditioner's original user manual.

5. MAINTENANCE

5.1 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these may damage the remote's surface or internal components.

5.2 Battery Replacement

Replace batteries when the remote's range decreases, the display becomes dim, or the air conditioner no longer responds reliably to commands. Always replace both batteries simultaneously with new AAA batteries of the same type.

6. TROUBLESHOOTING

- **Remote not responding:**

- Check if batteries are inserted correctly with correct polarity.
- Replace old batteries with new ones.
- Ensure there are no obstructions between the remote and the AC unit's infrared receiver.
- Confirm the remote is pointed directly at the AC unit.

- **Limited range:**

- Replace batteries.
- Ensure no strong light sources (like direct sunlight) are interfering with the IR signal.

- **Certain functions not working:**

- This replacement remote may not support all advanced functions of your original AC unit. Refer to the original AC unit manual for specific feature compatibility.
- Ensure your AC unit model is listed as compatible with this remote.

7. SPECIFICATIONS

Model Number	Easytry1608
Compatible Devices	Danby AC Air Conditioners (R09/BGCE, DAC7006DE, DAC7077EE, DAC8006DE, DAC8007EE, DAC10007EE, DAC9006DE, 2335509358)
Power Source	2 x AAA Batteries (not included)
Connectivity Technology	Infrared (IR)

Color	Grey
Manufacturer	Easytry123

8. WARRANTY AND SUPPORT

This product is typically covered by a standard return policy. For specific details regarding returns or replacements, please refer to the purchase platform's return policy (e.g., Amazon's 30-day return policy). As this is a replacement part, direct manufacturer warranty information may not be explicitly provided. For any issues or inquiries not covered in this manual, please contact the seller directly through the platform where the purchase was made. Provide your order number and a clear description of the issue for prompt assistance.