

[Manuals.plus](#) /

› [PRIME-LINE](#) /

› Prime-Line MP56500 Adjustable Toilet Tank Lever Instruction Manual

## PRIME-LINE MP56500

# Prime-Line MP56500 Adjustable Toilet Tank Lever

Model: MP56500

## INTRODUCTION

The Prime-Line MP56500 Toilet Tank Lever is designed to provide a reliable and adjustable flushing solution for your toilet. Constructed from durable plastic with a white handle and a zinc-plated rod, this lever offers corrosion resistance and a long service life. Its adjustable design ensures compatibility with most toilet tanks, including those designed for Fluidmaster Sure-Fit models. This manual will guide you through the installation, operation, maintenance, and troubleshooting of your new toilet tank lever.



Image: Prime-Line MP56500 Adjustable Toilet Tank Lever.

## INSTALLATION INSTRUCTIONS

Follow these steps to install your Prime-Line MP56500 Adjustable Toilet Tank Lever:

1. **Prepare the Toilet:** Turn off the water supply to the toilet at the shut-off valve located near the base of the toilet. Flush the toilet to empty the tank.
2. **Remove Old Lever:** Remove the toilet tank lid. Disconnect the flapper chain from the existing flush lever arm. Unscrew the mounting nut that secures the old lever to the toilet tank. Remove the old lever.
3. **Insert New Lever:** Insert the new Prime-Line MP56500 lever through the hole in the toilet tank. Ensure the handle is on the outside and the lever arm is inside the tank.
4. **Secure the Lever:** Thread the plastic mounting nut onto the lever shaft from inside the tank and tighten it by hand until snug. Do not overtighten.
5. **Adjust Lever Arm:** The lever arm is adjustable. If necessary, slide the arm to the desired length to ensure proper clearance and function within your tank.
6. **Connect Flapper Chain:** Attach the flapper chain to one of the holes at the end of the lever arm. Adjust the chain length so there is a small amount of slack when the flapper is closed. Too much slack will result in a weak flush; too little slack may prevent the flapper from sealing properly.
7. **Test and Finish:** Turn the water supply back on. Allow the tank to fill. Test the flush several times to ensure proper operation. Replace the toilet tank lid.

Your browser does not support the video tag.

Video: Product Overview and Installation Guide for the Prime-Line Toilet Tank Lever. This video demonstrates the features and ease of installation for the MP56500 model.

## OPERATING INSTRUCTIONS

To operate the Prime-Line MP56500 Toilet Tank Lever, simply press down on the white handle located on the exterior of the toilet tank. This action will lift the flapper inside the tank, allowing water to flow into the bowl and initiate a flush. Release the handle once the flush cycle begins. The lever is designed to return to its original position automatically.

## MAINTENANCE

Regular maintenance helps ensure the longevity and proper function of your toilet tank lever:

- **Cleaning:** Clean the exterior handle with a soft cloth and mild, non-abrasive cleaner. Avoid harsh chemicals that could damage the plastic finish.
- **Check Connections:** Periodically check the mounting nut inside the tank to ensure it remains hand-tight. Also, inspect the flapper chain for any signs of wear or incorrect tension.
- **Lubrication:** No lubrication is typically required for this plastic lever. If the lever feels stiff, ensure no components are binding or obstructed.

## TROUBLESHOOTING

If you encounter issues with your toilet tank lever, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Handle sticks or does not return	Mounting nut too tight; lever arm binding; debris.	Loosen mounting nut slightly. Check for obstructions around the lever arm. Clean any debris.
Toilet runs continuously	Flapper chain too short; flapper not sealing.	Adjust flapper chain to have slight slack. Ensure flapper is properly seated.
Weak or incomplete flush	Flapper chain too long; lever arm not lifting flapper high enough.	Shorten flapper chain. Ensure lever arm is adjusted to provide full lift.
No flush when handle is pressed	Flapper chain disconnected or broken.	Reconnect or replace flapper chain.

## PRODUCT SPECIFICATIONS

Specification	Detail
Model Number	MP56500
Brand	PRIME-LINE
Material	Plastic (Handle), Zinc Plated (Rod)
Color	White (Handle)
Product Dimensions (L x W)	4.53"L x 1"W
Item Weight	0.03 Kilograms
Handle Type	Lever
Handle Compatibility	Universal (Fits most tanks, including Fluidmaster Sure-Fit)
Installation	Easy to Install, Nuts and Bolts Mechanism
Indoor/Outdoor Usage	Indoor

## WARRANTY AND SUPPORT

Prime-Line products are manufactured to high-quality standards. For specific warranty information regarding your MP56500 Toilet Tank Lever, please refer to the packaging or visit the official Prime-Line website. If you require technical assistance, have questions about installation, or need to report a defect, please contact Prime-Line customer support directly. Contact information can typically be found on the product packaging or on the manufacturer's website.