

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Walker Edison](#) /
- › [Walker Edison Richmond Modern Farmhouse Sliding Barn Door TV Stand \(AZ58SBDRO\) - Instruction Manual](#)

Walker Edison AZ58SBDRO

Walker Edison Richmond Modern Farmhouse Sliding Barn Door TV Stand (AZ58SBDRO)

Model: AZ58SBDRO | Brand: Walker Edison

1. Product Overview

The Walker Edison Richmond Modern Farmhouse Sliding Barn Door TV Stand is designed to accommodate TVs up to 65 inches. It features a rustic oak finish, sliding barn doors, and adjustable shelving for versatile storage. The unit includes six cord management ports to help keep cables organized.

PRODUCT DIMENSIONS

- Overall Dimensions: 28" H x 15.75" D x 58" L
- Cabinet Dimensions: 23.25" H x 13.25" D x 15.25" L
- Top Surface Weight Capacity: Up to 150 lbs
- Shelf Weight Capacity: Up to 30 lbs each




Image: Detailed dimensions of the TV stand, illustrating its size and capacity for various TV sizes.

KEY FEATURES

- Sliding barn doors for flexible storage and display options.
- Three adjustable shelves for customizable organization.
- Six cord management ports to maintain a tidy appearance.
- Constructed from high-grade MDF for durability.

2. Setup and Assembly

This TV stand ships ready-to-assemble and includes step-by-step instructions. For optimal assembly, it is recommended to have two people due to the package weight and size of components. Allow approximately 3-5 hours for assembly.

PREPARATION

PREPARATION

- Clear a large, open workspace to accommodate all parts and tools.
- Unpack all components and verify against the parts list. Alphabetizing parts can simplify the process.
- Ensure all necessary tools are available. A Phillips head screwdriver is required; an Allen wrench and dowels/glue are provided.
- While power tools can expedite assembly, use them with caution on a low torque setting to prevent damage.

ASSEMBLY STEPS

1. Follow the provided step-by-step instructions carefully.
2. Pay close attention to instructions regarding the use of glue for dowels to ensure structural integrity.
3. Assemble the main frame of the TV stand first, ensuring all connections are secure.
4. Install the adjustable shelves according to your desired height.
5. Attach the sliding barn door hardware and doors, ensuring smooth operation.
6. Place the top surface securely.



Image: The fully assembled TV stand, showcasing its rustic oak finish and closed barn doors.

3. Operating Instructions

The Walker Edison Richmond TV Stand offers flexible usage options for organizing your media and decor.

SLIDING BARN DOORS

The two barn-style doors slide smoothly along the top track, allowing you to cover either the central shelving area or the side compartments. This feature enables you to customize the display of your items or conceal electronics and clutter as needed.



Image: A close-up view of the sliding barn door and its hardware, highlighting the smooth operation.



Image: The TV stand with its barn doors open, showing the central shelving for media devices or decor.

ADJUSTABLE SHELVING

The three interior shelves are adjustable, allowing you to customize the height to fit various media devices, books, or decorative items. Simply remove the shelf pins and reposition the shelf to the desired level.



Image: An interior view of the TV stand, demonstrating the adjustable shelving and storage capacity.

CORD MANAGEMENT

Utilize the six cord management ports located on the back panel of the unit to route and organize cables from your electronic devices. This helps to keep wires tidy and out of sight, contributing to a cleaner aesthetic.

4. Maintenance and Care

Proper care will ensure the longevity and appearance of your TV stand.

CLEANING INSTRUCTIONS

- Wipe with a dry cloth to remove dust and debris.
- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- For spills, blot immediately with a clean, dry cloth.

GENERAL CARE

- Avoid placing hot items directly on the surface; use coasters or protective pads.
- Keep the unit away from direct sunlight and heat sources to prevent warping or fading.
- Regularly check and tighten any loose hardware to maintain stability.

5. Troubleshooting

COMMON ISSUES AND SOLUTIONS

- **Doors coming off track:** If a sliding door comes off its track, carefully lift the door and realign the rollers with the track. Ensure the track is free of obstructions.
- **Wobbly unit:** Check all screws and fasteners to ensure they are securely tightened. If the unit is on an uneven surface, use shims to stabilize it.
- **Missing parts:** Refer to the parts list in your assembly manual. Contact customer support if any essential components are missing.
- **Difficulty sliding doors:** Ensure the track is clean and free of debris. Check that the doors are properly aligned and not obstructed by items inside the compartments.

6. Specifications

Feature	Detail
Brand	Walker Edison
Model Number	AZ58SBDRO
Color	Rustic Oak
Style	Modern Farmhouse
Material	Metal, Wood (High-grade MDF)
Product Dimensions	16 x 58 x 28 inches (D x L x H)
Item Weight	87 pounds
Number of Shelves	3 (adjustable)
TV Size Support	Up to 65 inches
Cord Management	6 ports
Assembly Required	Yes, step-by-step instructions included

7. Warranty and Support

WARRANTY INFORMATION

This product is covered by a 30-day limited manufacturer's warranty. Please retain your proof of purchase for any

warranty claims.

CUSTOMER SUPPORT

For assistance with assembly, missing parts, or any other product-related inquiries, please contact Walker Edison customer support. Refer to the contact information provided in your product packaging or visit the official Walker Edison website.

8. Product Visuals and Demonstrations


PRODUCT IMAGES



Overall view of the Walker Edison Richmond TV Stand in Rustic Oak, featuring its modern farmhouse design.



The TV stand integrated into a living room, demonstrating its aesthetic appeal and functionality.



A detailed view of the TV stand's top surface, showing the quality of the rustic oak finish.



The TV stand supporting a large television, illustrating its robust design and suitability for modern media setups.

OFFICIAL PRODUCT VIDEOS

Your browser does not support the video tag.

Video: A detailed overview of the TV stand's features, including its construction and design elements.

Your browser does not support the video tag.

Video: A demonstration of the TV stand's storage capabilities, highlighting how various items can be organized.

Your browser does not support the video tag.

Video: A long-term review of the TV stand, discussing its durability and performance over several years.

Your browser does not support the video tag.

Video: A user's perspective on the TV stand, showcasing its aesthetic appeal and practical use in a home setting.

Your browser does not support the video tag.

Video: A review focusing on the white variant of the TV stand, demonstrating the sliding barn door functionality and storage.

Your browser does not support the video tag.

Video: A review after five years of use, providing insights into the product's long-term performance and resilience.