



Manuals.plus /

› Samsonite /

› Samsonite Winfield 3 DLX Hardside Expandable Luggage - 20-Inch Carry-On Instruction Manual

Samsonite Winfield 3 DLX 20-Inch Carry-On

Samsonite Winfield 3 DLX Hardside Expandable Luggage - 20-Inch Carry-On Instruction Manual

Model: Winfield 3 DLX 20-Inch Carry-On

INTRODUCTION

The Samsonite Winfield 3 DLX Hardside Expandable Luggage is designed for efficient and secure travel. This 20-inch carry-on model features a durable polycarbonate shell, multi-directional spinner wheels, an integrated TSA lock, and an expandable design to accommodate your packing needs. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your luggage.

KEY FEATURES

- **20" SPINNER LUGGAGE:** Maximizes packing power and meets most carry-on size restrictions for domestic travel.
- **100% Polycarbonate Shell:** Scratch-resistant and durable hardside construction.
- **FOUR, MULTI-DIRECTIONAL OVERSIZED SPINNER WHEELS:** Re-engineered for effortless mobility and smooth gliding.
- **SELF RETRACTING Carry Handles:** Maintain a low profile when not in use, located on top and side.
- **SIDE-MOUNTED TSA LOCKS:** Integrated combination lock deters theft and allows TSA agents access without damage.
- **Expandable Design:** Provides additional packing capacity when needed.
- **Reversible Packing Divider:** Helps organize belongings efficiently.
- **Abundance of Zippered Pockets:** Multiple compartments for organized storage.

SETUP AND FIRST USE

Setting the TSA Combination Lock

Your Samsonite luggage comes with an integrated TSA-approved combination lock. The default combination is usually 0-0-0. To set your personal combination:

1. Ensure the lock is set to the default combination (0-0-0) or the last combination you set.
2. Locate the small reset button (often recessed and requires a pen or paperclip to press).
3. Press and hold the reset button until you hear a click or feel it release.
4. While holding the reset button, set your desired 3-digit combination by turning the dials.
5. Release the reset button. Your new combination is now set. Test it by scrambling the numbers and then entering your new combination to open the lock.



Image: Close-up of the Samsonite TSA combination lock on the side of the luggage. The lock features three customizable dials and a keyhole for TSA access. The zipper pulls are inserted into the lock mechanism.



Image: Detailed view of the TSA lock mechanism with zipper pulls inserted, showing the combination dials and the TSA keyhole. This ensures secure closure of the main compartment.

OPERATING INSTRUCTIONS

Using the Spinner Wheels

The four multi-directional spinner wheels allow for 360-degree upright rolling, reducing strain on your arm and shoulder. Simply push or pull the luggage in any direction. For rougher terrain, you can tilt the luggage and pull it on two wheels.



Image: Close-up of the multi-directional spinner wheels on the Samsonite luggage, highlighting their robust design for smooth movement.

Extending and Retracting the Pull Handle

The ergonomic pull handle extends and retracts smoothly. Press the button on the top of the handle to extend or retract it to your desired height for comfortable maneuvering.



Image: Rear view of the Samsonite luggage with the pull handle extended, showing the handle's two-bar design and comfortable grip.



Image: Close-up of the top carry handle and the retractable pull handle mechanism, illustrating how the handle can be extended for rolling or retracted for storage.

Utilizing Carry Handles

The luggage features self-retracting carry handles on the top and side. These handles lie flat when not in use, maintaining a sleek profile. Use them for lifting the luggage into overhead bins or onto luggage racks.

Expanding the Luggage

To expand the luggage for additional packing space, locate the expansion zipper around the perimeter of the main compartment. Unzip it to reveal an extra 1.5 to 2 inches of depth.

Your browser does not support the video tag.

Video: Demonstrates the expansion feature of the Samsonite Winfield 3 DLX luggage. The video shows how to unzip the expansion zipper to increase the packing capacity of the suitcase.

Internal Organization

The interior features a reversible packing divider and multiple zippered pockets to help keep your belongings organized. Use the cross-straps in the main compartment to secure your clothes and prevent shifting during transit. The zippered mesh compartment on the other side is ideal for smaller items or separating laundry.



Image: Interior view of the Samsonite luggage, displaying the spacious main compartment with adjustable cross-straps and a zippered mesh divider for organized packing.

Your browser does not support the video tag.

Video: Provides a detailed look inside the Samsonite Winfield 3 DLX luggage, showcasing the interior organization, including the packing divider, zippered pockets, and spinner wheels.

MAINTENANCE

- **Cleaning the Shell:** Wipe the polycarbonate shell with a soft, damp cloth and mild soap. Avoid abrasive cleaners that could scratch the surface.
- **Cleaning the Interior:** Spot clean the interior lining with a damp cloth and mild detergent. Allow to air dry completely before closing.
- **Wheel Care:** Periodically check the spinner wheels for debris. Clean any dirt or hair that may impede smooth rolling.
- **Zipper Maintenance:** Keep zippers clean and free of obstructions. If a zipper becomes stiff, apply a small amount of zipper lubricant or wax.
- **Storage:** Store your luggage in a cool, dry place away from direct sunlight when not in use.

TROUBLESHOOTING

- **Lock Not Opening:** Ensure you are using the correct 3-digit combination. If you forget your combination, contact Samsonite customer support for assistance.
- **Wheels Sticking:** Check for any debris (hair, lint, dirt) caught in the wheel mechanism. Clean thoroughly. If the issue persists, the wheels may require professional servicing.
- **Handle Not Extending/Retracting:** Ensure no items inside the luggage are obstructing the handle mechanism. Apply gentle pressure while pressing the release button.
- **Zipper Snagging:** Avoid overpacking the luggage. If a zipper snags, gently pull the fabric away from the zipper teeth and try to move the slider. Do not force it.

SPECIFICATIONS

Packing Dimensions	20.0" x 14.25" x 9.5"
Overall Dimensions	22.5" x 14.5" x 9.5"
Weight	6.97 lbs.
Material	Polycarbonate (PC)
Wheel Type	Spinner (4 multi-directional wheels)
Lock Type	Combination Lock (TSA-approved)
Color	Silver
Storage Volume	2707.5 Cubic Inches

WARRANTY AND SUPPORT

Warranty Information

This Samsonite Winfield 3 DLX luggage comes with a **10-YEAR LIMITED WARRANTY** against defects in materials and workmanship. Samsonite products are rigorously tested to ensure they meet stringent quality standards. For warranty claims or detailed terms and conditions, please refer to the warranty card included with your purchase or visit the official Samsonite website.

Customer Support

For further assistance, product inquiries, or troubleshooting not covered in this manual, please contact Samsonite customer support. Contact information can typically be found on the Samsonite website or on the product packaging.