

[Manuals.plus](#) /

> [FocalTop](#) /

> FocalTop AC Power Cable Cord Instruction Manual for LG TV Models 60PA6500, 60PA6550, 60PB6900, 60PK550

## FocalTop AC Power Cable Cord

# FocalTop AC Power Cable Cord Instruction Manual

For LG TV Models: 60PA6500, 60PA6550, 60PB6900, 60PK550

## 1. INTRODUCTION

This manual provides essential information for the safe and effective use of your FocalTop AC Power Cable Cord. This cable is designed as a replacement or spare power cord for specific LG TV models. Please read these instructions carefully before installation and use.

## 2. PRODUCT OVERVIEW

### 2.1. Product Components

The FocalTop AC Power Cable Cord consists of a standard two-prong (Type B) male plug on one end and a C7 (figure-8) female connector on the other. This design ensures compatibility with the specified LG TV models.



*A black AC power cable, coiled, showing both the two-prong male plug and the C7 female connector.*

## 2.2. Key Features

- **Length:** 5 feet (approximately 1.5 meters)
- **Connector Type:** Male-to-Female
- **Plug Format:** Type B (US standard 2-prong)
- **Compatibility:** Specifically designed for LG TV models 60PA6500, 60PA6550, 60PB6900, 60PK550.

## 3. SETUP

### 3.1. Installation Instructions

Follow these steps to properly connect your AC Power Cable Cord:

1. **Power Off:** Ensure your LG TV and any connected devices are powered off and unplugged from the wall outlet before proceeding.
2. **Locate Port:** Identify the power input port on your LG TV. This is typically a two-pin (figure-8) receptacle.
3. **Connect to TV:** Connect the female (figure-8) end of the FocalTop AC Power Cable Cord firmly into the power input port of your LG TV.
4. **Connect to Wall:** Plug the male (two-prong) end of the FocalTop AC Power Cable Cord into a standard, grounded 120V AC wall outlet.
5. **Power On:** Once securely connected, you may power on your LG TV.

## 4. OPERATING INSTRUCTIONS

### 4.1. Usage

Once properly connected to both the LG TV and a live wall outlet, the power cable will supply electrical current to your television. No further operational steps are required for the cable itself. The cable functions passively to transmit power.

Always ensure the cable is not kinked, pinched, or placed under heavy objects to prevent damage and ensure safe operation.

---

## 5. MAINTENANCE

### 5.1. Care and Storage

- **Cleaning:** Keep the cable clean and free from dust. Use a dry, soft cloth for cleaning.
- **Environment:** Avoid exposing the cable to extreme temperatures, direct sunlight, or excessive moisture.
- **Storage:** When not in use or for storage, coil the cable loosely. Do not wrap it tightly around objects or bend it sharply, as this can damage the internal wires.
- **Inspection:** Regularly inspect the cable for any signs of damage, such as frayed insulation, cuts, or bent/corroded prongs. Discontinue use immediately if any damage is observed and replace the cable.

---

## 6. TROUBLESHOOTING

### 6.1. Common Issues

Issue	Possible Cause	Solution
TV does not power on	Cable not fully connected	Ensure both ends of the cable are securely plugged into the TV and the wall outlet.
TV does not power on	Wall outlet not active	Test the wall outlet with another known working device or check the circuit breaker.
TV does not power on	Damaged cable	Inspect the cable for visible damage (frays, cuts, bent prongs). If damaged, replace the cable immediately.

---

## 7. SPECIFICATIONS

### 7.1. Technical Details

- **Brand:** FocalTop
  - **Product Type:** AC Power Cable Cord
  - **Length:** 5 Feet (approx. 1.5 meters)
  - **Connector Type (TV End):** C7 (Figure-8) Female
  - **Connector Type (Wall End):** NEMA 1-15P (Type B) Male, 2-prong
  - **Compatibility:** LG TV models 60PA6500, 60PA6550, 60PB6900, 60PK550
-

## **8. WARRANTY AND SUPPORT**

### **8.1. Warranty Information**

For specific warranty details and customer support regarding your FocalTop AC Power Cable Cord, please refer to the information provided by your retailer at the time of purchase or contact FocalTop directly through their official customer service channels. Keep your purchase receipt as proof of purchase.