



Manuals.plus /

- › AY /
- › AY Portable Bluetooth Speaker User Manual

AY 0

AY Portable Bluetooth Speaker User Manual

Model: 0 | Brand: AY

1. INTRODUCTION

Thank you for choosing the AY Portable Bluetooth Speaker. This speaker is designed to deliver powerful stereo sound with rich bass, featuring IPX7 waterproofing, True Wireless Stereo (TWS) functionality, and a built-in microphone for hands-free calling. Its durable and portable design makes it ideal for various indoor and outdoor activities, offering up to 24 hours of playtime.

2. WHAT'S IN THE BOX

- 1 x AY Portable Bluetooth Speaker
- 1 x Micro USB Charging Cable
- 1 x 3.5mm Audio Cable (AUX-in)
- 1 x Durable Wrist Strap
- 1 x User Manual (this document)
- 1 x Feedback Card

3. PRODUCT OVERVIEW

The AY Portable Bluetooth Speaker features a robust design with intuitive controls. Familiarize yourself with the speaker's components and button functions for optimal use.



Figure 3.1: AY Portable Bluetooth Speaker. This image displays the speaker's sleek black design with water droplets, highlighting its waterproof capability.

Controls and Indicators:

Power Button: Press and hold to power on/off. Short press to play/pause.

Volume Up (+): Short press to increase volume. Long press for next track.

Volume Down (-): Short press to decrease volume. Long press for previous track.

Bluetooth/TWS Button: Short press to enter Bluetooth pairing mode. Long press to initiate TWS pairing.

LED Indicator: Displays power, charging, and Bluetooth status.

Charging Port: Micro USB input for charging.

AUX-in Port: 3.5mm audio input for wired connections.

4. SETUP

4.1 Initial Charging

Before first use, fully charge the speaker. Connect the Micro USB charging cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The LED indicator will show charging status and turn off when fully charged. A full charge takes approximately 4 hours.

4.2 Power On/Off

- To power on: Press and hold the Power button for 2-3 seconds until you hear an audible prompt and the LED indicator lights up.
- To power off: Press and hold the Power button for 2-3 seconds until you hear an audible prompt and the LED indicator turns off.

5. OPERATING INSTRUCTIONS

5.1 Bluetooth Pairing (Single Speaker)

1. Ensure the speaker is powered on and the LED indicator is blinking blue, indicating it's in pairing mode.
2. On your Bluetooth-enabled device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "AY Speaker" or "AY-SPK" in the list of available devices.
4. Select "AY Speaker" to connect. Once connected, the LED indicator will turn solid blue, and you will hear a confirmation sound.

BLUETOOTH 5.0

Connection is more stable and faster than others



Compact size,
Loud Stereo Sound



IPX7 Waterproof



Hi-Fi Bluetooth v5.0



3.5mm Audio Cable



24H Long Playtime



AY Speaker
Manufacturer

Figure 5.1: Bluetooth 5.0 Connectivity. This image shows the speaker connected via Bluetooth to a smartphone, demonstrating stable and fast connection.

5.2 True Wireless Stereo (TWS) Pairing (Two Speakers)

The TWS function allows you to pair two AY Portable Bluetooth Speakers together for a true stereo sound experience.

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), long press the Bluetooth/TWS button until you hear a prompt indicating TWS pairing mode.
3. The two speakers will automatically search for and connect to each other. Once connected, you will hear a confirmation sound, and the LED indicators on both speakers will change to a solid blue.
4. Now, on your Bluetooth-enabled device, search for "AY Speaker" (only one will appear) and connect. Both speakers will now play audio in stereo.

AY WIRELESS DUAL STEREO PAIR

Pair 2 speakers via a single device 60W, Powerful all-around bass



Figure 5.2: True Wireless Stereo Setup. This image illustrates two speakers paired together for an enhanced audio experience.

Your browser does not support the video tag.

Video 5.1: Product Features Overview. This video demonstrates the speaker's Bluetooth connectivity, TWS pairing, IPX7 waterproofing, and hands-free calling capabilities.

5.3 Auxiliary (AUX) Connection

For non-Bluetooth devices, use the included 3.5mm audio cable.

1. Connect one end of the 3.5mm audio cable to the AUX-in port on the speaker.
2. Connect the other end to the audio output jack of your device.
3. The speaker will automatically switch to AUX mode.

5.4 Hands-Free Calling

When connected via Bluetooth, the speaker's built-in microphone allows for hands-free calls.

- To answer an incoming call: Short press the Power button.
- To end a call: Short press the Power button.

- To reject an incoming call: Long press the Power button.

5.5 Playback Controls

- Play/Pause: Short press the Power button.
- Next Track: Long press the Volume Up (+) button.
- Previous Track: Long press the Volume Down (-) button.
- Volume Up: Short press the Volume Up (+) button.
- Volume Down: Short press the Volume Down (-) button.

6. MAINTENANCE

6.1 Waterproofing (IPX7)

The speaker is IPX7 waterproof, meaning it can withstand full immersion in water up to 1 meter (3.3 feet) for 30 minutes. Ensure the charging port cover is securely closed before exposing the speaker to water.

WATERPROOF IPX7

Washed directly, Full waterproof,
no longer worry sand, dust, snow, rain!



Figure 6.1: IPX7 Waterproofing. This image demonstrates the speaker's ability to be submerged in water without damage.

6.2 Cleaning and Storage

- Clean the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Store the speaker in a cool, dry place away from extreme temperatures and direct sunlight.
- If not used for extended periods, charge the speaker at least once every three months to maintain battery health.

7. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|------------------------------------|--|---|
| Speaker does not power on. | Low battery. | Charge the speaker fully. |
| Cannot pair with Bluetooth device. | Speaker not in pairing mode; device Bluetooth off; too far from speaker. | Ensure speaker is in pairing mode (blinking blue LED). Turn device Bluetooth off/on. Move device closer to speaker (within 48ft). |
| No sound or distorted sound. | Volume too low; incorrect input mode; TWS not properly paired. | Increase volume on both speaker and device. Check if in correct mode (Bluetooth/AUX). Re-pair TWS speakers if applicable. |
| TWS pairing fails. | Speakers too far apart; one speaker already connected to a device. | Ensure speakers are close to each other. Disconnect any existing Bluetooth connections before TWS pairing. |

8. SPECIFICATIONS

| Feature | Detail |
|-----------------------------------|---|
| Brand | AY |
| Model Name | IPX7 |
| Speaker Type | Outdoor |
| Connectivity Technology | Bluetooth, Auxiliary, USB |
| Wireless Communication Technology | Bluetooth V5.0 |
| Bluetooth Range | Up to 48 Feet |
| Speaker Maximum Output Power | 30 Watts |
| Audio Output Mode | Stereo |
| Water Resistance Level | IPX7 Waterproof |
| Battery Capacity | 5000mAh (approx. 24 hours playtime at 50% volume) |
| Charging Time | Approx. 4 hours |
| Built-in Microphone | Yes, with noise/wind reduction |
| Product Dimensions | 3"D x 7"W x 3"H |
| Item Weight | 1.18 pounds (18.8 Ounces) |
| Control Method | Touch |

9. WARRANTY AND SUPPORT

The AY Portable Bluetooth Speaker comes with a limited warranty. For detailed warranty information or technical support, please refer to the feedback card included in your package or contact AY customer service through the retailer's platform where you purchased the product. Please retain your proof of purchase for warranty claims.