Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FEICE FM121

FEICE Men's Bauhaus Automatic Watch FM121 Instruction Manual

Model: FM121

1. Product Overview

The FEICE Men's Bauhaus Automatic Watch FM121 is a mechanical wristwatch designed with Bauhaus aesthetics. It features an automatic self-wind movement, a 41mm dial with two sub-dials, Arabic numeral markers, and a calendar function. The watch is constructed with a 2.5D domed mirror for clarity and scratch resistance, and a transparent case back to view the movement.





Image 1: Front view of the FEICE FM121 Bauhaus Automatic Watch.

Key Features:

- **Automatic Self-Wind Movement:** No battery required; powered by wrist movement. Can also be manually wound.
- **2.5D Domed Mirror:** Double-coated for 99.6% transparency, enhancing dial clarity and scratch resistance.
- **Functions:** Month display (upper sub-dial), 24-hour display (lower sub-dial), date and week calendar window at 3 o'clock.
- **Water Resistance:** Water resistant to 3 ATM (30 meters), suitable for splashes and rain, but not for bathing, swimming, or diving.

2. Setup and Initial Winding

Your FEICE FM121 watch is an automatic mechanical timepiece. It does not require a battery but relies on the motion of your wrist to wind the mainspring. For initial use or after the watch has stopped, manual winding is recommended.

Manual Winding:

1. Ensure the crown is in its normal operating position (pushed in).
2. Rotate the crown clockwise approximately 30-40 times. This will provide sufficient power reserve to start the watch.
3. Once wound, the watch will begin to operate. Continuous wear will maintain the power reserve. A full wind can power the watch for up to 35 hours.



Image 2: Detail of the watch crown and pushers for setting functions.

3. Operating Instructions

The FM121 watch features multiple functions controlled by the crown and pushers.

Setting the Time:

1. Pull the crown out to the furthest position (Position 2).
2. Rotate the crown to adjust the hour and minute hands to the correct time.
3. Push the crown back into Position 0 to start the watch.

Setting the Date and Day of the Week:

1. Pull the crown out to the first position (Position 1).
2. Rotate the crown clockwise to adjust the date.
3. Rotate the crown counter-clockwise to adjust the day of the week.

4. Push the crown back into Position 0.
5. *Note: Avoid setting the date or day between 9 PM and 3 AM, as this can damage the movement. If adjustment is needed during this period, first set the time outside this range, adjust the date/day, then reset the time.*

Using the Sub-Dials:

- **Upper Sub-dial:** Displays the month. This typically advances automatically with the date mechanism.
- **Lower Sub-dial:** Displays 24-hour time, automatically following the main hour hand.

4. Maintenance and Care

Proper care will ensure the longevity and performance of your FEICE FM121 watch.

Water Resistance:

The watch is water resistant to 3 ATM (30 meters). This means it can withstand splashes of water and rain. It is **not** suitable for showering, bathing, swimming, diving, or any activities involving prolonged water immersion or high-pressure water exposure.



Image 3: Visual representation of the watch's 30-meter water resistance.

General Care:

- Clean the watch case and strap regularly with a soft, dry cloth.
- Avoid exposing the watch to extreme temperatures, strong magnetic fields, or harsh chemicals.
- If the watch comes into contact with saltwater, rinse it gently with fresh water and dry thoroughly.
- Store the watch in a cool, dry place when not in use.

5. Troubleshooting

If you encounter issues with your FEICE FM121 watch, refer to the following common solutions:

Watch Not Running or Stopping Frequently:

- **Insufficient Power Reserve:** As an automatic watch, it requires motion to wind. If not worn for an extended period, it may stop. Manually wind the watch by rotating the crown clockwise 30-40 times.
- **Lack of Movement:** If your daily activity is insufficient to keep the watch wound, consider manually winding it daily or using a watch winder.

Date/Day Not Changing Correctly:

- Ensure the time is set correctly, especially the AM/PM cycle, as the date change mechanism is linked to the 24-hour cycle.
- Avoid manual date/day adjustments between 9 PM and 3 AM. If you did, the mechanism might be temporarily misaligned. Allow it to cycle naturally for a day or two.

Condensation Inside the Watch:

- Small amounts of condensation that disappear quickly are usually normal due to temperature changes.
- If condensation persists or appears as large droplets, this indicates a breach in water resistance. Seek professional service immediately to prevent damage to the movement.

For issues not covered here, please contact FEICE customer support.

6. Specifications

FEICE FM121 Watch Specifications

Feature	Detail
Model Name	FM121
Movement Type	Automatic Mechanical
Case Material	Stainless Steel
Case Diameter	41 Millimeters
Case Thickness	12.5 Millimeters
Band Material	Leather (Black)
Band Width	20 Millimeters
Band Length	240 Millimeters
Dial Color	White
Display Type	Analog
Crystal Type	2.5D Domed Mirror (High strength mineral mirror)
Water Resistance Depth	30 Meters (3 ATM)
Clasp Type	Push Button Foldover Clasp With Safety
Functions	Month display, 24-hour display, Date, Weekday




Image 4: Detailed specifications and dimensions of the FEICE FM121 watch.

7. Warranty and Support

FEICE provides a limited warranty for this product. For specific warranty details, please refer to the documentation included with your purchase or contact FEICE customer support.

Return Policy:

This product is eligible for a refund or replacement within 30 days of purchase, subject to the seller's return policy.

Protection Plans:

Extended protection plans are available for purchase:

- 2-Year Protection Plan: $24.99
- 3-Year Protection Plan: $33.99
- Complete Protect: $16.99/month (covers all eligible past and future purchases)

8. Product Video

Your browser does not support the video tag.

Video 1: Official product video showcasing the FEICE FM121 Bauhaus Design Dress Watch features and aesthetics.

© 2026 FEICE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07FKKGKQP

More documents and user manuals: **https://manuals.plus/**