SALAV 533f619d-654d-488d-9395-040b2cf38b49

SALAV Duo Press Handheld Garment Steamer

User Manual

Important Safety Instructions

Please read all instructions carefully before using the SALAV Duo Press Handheld Garment Steamer. Keep this manual for future reference.

- Always unplug the steamer from the electrical outlet when filling with water, emptying, or when not in use.
- Do not operate the steamer with a damaged cord or plug, or if the appliance has been dropped or damaged.
- To avoid the risk of electric shock, do not immerse the steamer in water or other liquids.
- Use the steamer only for its intended use as described in this manual.
- Always ensure the water tank is securely closed before operating.
- Keep the steam nozzle away from your body and hands when operating, as steam is hot and can cause burns.
- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. (Proposition 65 Warning)

Product Overview

The SALAV Duo Press Handheld Garment Steamer is designed for quick and efficient wrinkle removal and garment freshening. Its compact and lightweight design makes it ideal for both home use and travel. The steamer features dual functionality, allowing for both horizontal and vertical steaming.



Figure 1: Front view of the SALAV Duo Press Handheld Garment Steamer, showcasing its ergonomic design and steam nozzle.

Key features include:

- Powerful steam output for quick wrinkle removal.
- Dual functionality: Use horizontally for pressing or vertically for steaming.
- Compact and portable design for easy storage and travel.
- Fast heat-up time, ready in approximately 50 seconds.
- Versatile compatibility with a wide range of fabrics.

Setup

1. **Unpack:** Carefully remove the steamer and all accessories from the packaging.
2. **Fill Water Tank:** Locate the water tank cap, open it, and fill the tank with distilled water. The capacity is 150 milliliters. Do not overfill. Close the cap securely.
3. **Power Connection:** Plug the steamer into a standard electrical outlet. Ensure the voltage matches the product's requirements (230 Volts).
4. **Heat Up:** The steamer will begin to heat up. It typically takes approximately 50 seconds to reach operating temperature.

Operating Instructions

General Steaming

1. Ensure the water tank is filled and the steamer is plugged in and heated.
2. Hold the steamer upright for vertical steaming or lay it flat for horizontal pressing.
3. Press the steam button to release steam. Move the steamer slowly over the fabric, allowing the steam to penetrate and relax the fibers.
4. For stubborn wrinkles, pass the steamer over the area multiple times.
5. Always test on an inconspicuous area of the fabric first, especially for delicate materials.

Fabric Compatibility

The SALAV Duo Press is suitable for a wide range of fabrics, including cotton, linen, silk, wool, and synthetic blends. Exercise caution with very delicate fabrics and always refer to the garment's care label.

Maintenance

Cleaning the Steamer

- Always unplug the steamer and allow it to cool completely before cleaning.
- Empty any remaining water from the tank after each use to prevent mineral buildup.
- Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners.

Descaling (Recommended Monthly)

- Mix a solution of 50% white vinegar and 50% water.
- Pour the solution into the water tank.
- Plug in the steamer and allow it to heat up. Run the steamer until half of the solution has been used.
- Unplug and let it cool for 30 minutes. Repeat the steaming process with the remaining solution.
- Empty the tank and rinse thoroughly with fresh water. Run a tank of fresh water through the steamer to flush out any remaining vinegar.

Storage

Store the steamer in a cool, dry place. Ensure the water tank is empty before storing.

Troubleshooting

Problem	Possible Cause	Solution
No steam or low steam output.	Water tank is empty; Steamer not heated sufficiently; Mineral buildup.	Refill water tank; Allow more time to heat up (approx. 50 seconds); Perform descaling procedure.
Water leaking from nozzle.	Overfilled water tank; Steamer not fully heated; Mineral buildup.	Do not overfill tank; Allow steamer to fully heat before use; Perform descaling procedure.
Steamer not turning on.	Not plugged in; Power outlet issue; Damaged cord/plug.	Ensure plug is fully inserted; Test outlet with another appliance; Do not use if cord/plug is damaged, contact support.

Specifications

Feature	Detail
Brand	SALAV
Model Number	533f619d-654d-488d-9395-040b2cf38b49
ASIN	B07FKQYH76
Wattage	1150 watts
Voltage	230 Volts
Heat Time	Approx. 50 seconds
Water Tank Capacity	150 Milliliters
Product Dimensions	20 x 12 x 9 inches
Item Weight	3 pounds
UPC	850002007503

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official SALAV website. You may also contact the seller directly for assistance.

Protection plans are available for purchase separately to extend coverage beyond the standard warranty. Please check with your retailer for details on available protection plans.

© 2023 SALAV. All rights reserved.