

Naviforce NF9050

Naviforce NF9050 Analog-Digital Watch Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the Naviforce NF9050 Analog-Digital Silver Dial Men's Watch. Please read carefully to understand its features, setup, operation, and maintenance to ensure proper use and longevity of your timepiece.

PRODUCT FEATURES

- **Movement:** Japanese quartz movement with both analog and digital displays for precise and accurate timekeeping.
- **Display:** Features day, date, and time display.
- **Multi-functionality:** Includes alarm, stopwatch (1/100 chronograph), snooze, hourly chime, and auto date.
- **Illumination:** Stable LED display with EL backlight and luminous hands/hour markers for visibility in low light conditions.
- **Dual Time:** Capability to display two different time zones simultaneously.
- **Durability:** Equipped with a plating wear-resistant stainless steel case and high transparent mineral glass for scratch resistance.
- **Band:** Flexible stainless steel watch band with a secure push-button clasp closure.
- **Water Resistance:** Water resistant to 3 ATM (30 meters), suitable for daily use such as hand washing, rain, or splashes. Not recommended for swimming, diving, or showering.

WATCH COMPONENTS

Familiarize yourself with the main components of your Naviforce NF9050 watch:



Image 1: Front view of the Naviforce NF9050 watch, showing the silver dial, analog hands, digital display, and control buttons on the side.

- **Crown (A):** Used for setting analog time.
- **Button B (Top Left):** Typically used for mode selection or backlight.
- **Button C (Bottom Left):** Often used for adjusting settings or changing display.
- **Button D (Top Right):** Commonly used for starting/stopping functions (e.g., stopwatch) or confirming settings.
- **Button E (Bottom Right):** Often used for resetting functions or advancing settings.
- **Digital Display:** Shows digital time, date, and other functions.
- **Analog Hands:** Hour, minute, and second hands for analog time display.



Image 2: Back view of the Naviforce NF9050 watch, displaying the stainless steel caseback with brand engravings and model information.

SETUP

1. Setting Analog Time

1. Pull out the crown (A) to the first click position.
2. Rotate the crown to adjust the hour and minute hands to the desired time.
3. Push the crown back into its normal position to start the analog time.

2. Setting Digital Time and Date

1. Press Button B repeatedly to cycle through modes until the digital time display starts flashing (usually the seconds).
2. Press Button C to select the item you wish to adjust (seconds, hour, minute, month, date, day).
3. Press Button D to increase the selected value. Hold Button D for faster adjustment.
4. Once all settings are correct, press Button B to exit the setting mode.

3. Battery Activation

Your watch comes with two Lithium Ion batteries pre-installed. If the watch is not running, ensure any plastic battery stopper (if present) has been removed. If the watch still does not function, the battery may need replacement.

OPERATING INSTRUCTIONS

1. Mode Selection

Press Button B to cycle through the different digital modes: Time Display, Alarm, Stopwatch, and Dual Time.

2. EL Backlight

In any mode, press Button B (or a dedicated backlight button if present, typically top-left) to illuminate the digital display for a few seconds.

3. Alarm Function

1. Navigate to the Alarm mode by pressing Button B.
2. Press Button C to select the hour or minute to set.
3. Press Button D to adjust the selected value.
4. Press Button B to confirm and exit.
5. To activate/deactivate the alarm, press Button D while in Alarm mode. An alarm icon will appear/disappear.

4. Stopwatch (Chronograph)

1. Navigate to the Stopwatch mode by pressing Button B.
2. Press Button D to start the stopwatch.
3. Press Button D again to stop the stopwatch.
4. Press Button E to reset the stopwatch to zero.
5. For split time, press Button E while the stopwatch is running to display the split time. Press Button E again to return to running time.

5. Dual Time Display

1. Navigate to the Dual Time mode by pressing Button B.
2. Press Button C to select the hour or minute to set for the second time zone.
3. Press Button D to adjust the selected value.
4. Press Button B to confirm and exit.

MAINTENANCE

- **Cleaning:** Wipe the watch case and band regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by drying.
- **Water Resistance:** While the watch is water resistant to 3 ATM, avoid exposing it to hot water, steam, or direct high-pressure water jets. Do not operate buttons underwater. Ensure the crown is fully pushed in at all times.
- **Battery Replacement:** When the digital display dims or the watch stops, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and water resistance.
- **Storage:** Store your watch in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields.

- **Chemicals:** Avoid contact with solvents, detergents, perfumes, and cosmetics, as these can damage the watch case, band, or seals.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Analog hands do not move or are incorrect.	Crown is pulled out; battery low; mechanical issue.	Push crown in fully. If still not working, replace battery or seek professional repair.
Digital display is blank or dim.	Battery low or depleted.	Replace the battery.
Digital time is incorrect.	Incorrectly set.	Refer to "Setting Digital Time and Date" section to reset.
Water inside the watch.	Crown not fully pushed in; seals compromised; exceeding water resistance limits.	Immediately take the watch to a professional for inspection and repair to prevent further damage.

SPECIFICATIONS

Brand	Naviforce
Model Number	NF9050
Movement Type	Quartz
Display Type	Analog-Digital
Case Material	Metal
Case Diameter	45 Millimeters
Band Material	Metal
Band Color	Black
Dial Color	Silver
Dial Glass Material	Mineral Glass
Water Resistance Depth	30 Meters (3 ATM)
Clasp Type	Push Button Deployment Clasp
Item Weight	160 g
Batteries	2 Lithium Ion batteries (included)
Special Features	Alarm, Chronograph, Dual Time, Glow In The Dark, Water Resistant, Waterproof

WARRANTY INFORMATION

The Naviforce NF9050 watch comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear of the case, glass, or band. Please retain your proof of purchase for warranty claims.

SUPPORT

For further assistance, technical support, or warranty claims, please contact Naviforce customer service through their official website or the retailer where the watch was purchased. Provide your model number (NF9050) and proof of purchase for efficient service.

You can visit the official Naviforce store for more information: [Naviforce Store](#)