

Calor SV8054C0

Calor Express Anti Calc SV8054C0 Steam Generator Iron User Manual

Model: SV8054C0

1. INTRODUCTION

Thank you for choosing the Calor Express Anti Calc SV8054C0 Steam Generator Iron. This appliance is designed to provide efficient and effortless ironing for all types of fabrics. Please read this manual carefully before first use and keep it for future reference.

The Express Anti-Calc steam generator iron combines an exclusive scale collector and exceptional steam power suitable for all fabrics, for quick and easy results. The removable scale collector allows for effortless maintenance and extends steam performance with optimal efficiency. A continuous steam output of 120 g/min and a pump pressure of 6.5 bars enable faster ironing, while the 420 g/min steam boost tackles even the most stubborn creases. This powerful steam generator iron features the glide and performance of the Durilium Airglide soleplate, combined with advanced functionalities for maximum user comfort.

2. IMPORTANT SAFETY INSTRUCTIONS

- Always ensure the voltage indicated on the appliance corresponds to your mains voltage.
- Do not leave the iron unattended while it is connected to the mains.
- Keep the appliance out of reach of children and persons with reduced physical, sensory or mental capabilities.
- Never immerse the appliance, power cord, or plug in water or any other liquid.
- Do not touch the hot soleplate or steam.
- Unplug the appliance before filling the water tank, cleaning, or performing any maintenance.
- Use only tap water. Do not use scented water, water from tumble dryers, or distilled water as it may damage the appliance.

- Place the iron on a stable, heat-resistant surface when not in use.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

3. PACKAGE CONTENTS

Upon unpacking, please ensure all items are present and in good condition:

- Calor Express Anti Calc SV8054C0 Steam Generator Iron
- User Manual (this document)

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your steam generator iron:



Image: Calor Express Anti Calc SV8054C0 Steam Generator Iron. This image shows the complete steam generator iron unit,

including the base station with water tank and the iron itself, connected by a steam hose and electrical cord.

1. Iron with Durilium Airglide soleplate
2. Steam hose
3. Water tank (removable)
4. Base unit
5. Control panel / Indicator lights
6. Removable scale collector
7. Power cord storage

5. SETUP

5.1. Unpacking

Remove all packaging materials and stickers from the appliance. Keep packaging for storage or disposal according to local regulations.

5.2. Filling the Water Tank

1. Ensure the appliance is unplugged from the mains.
2. Remove the water tank from the base unit.
3. Fill the tank with clean tap water up to the MAX level indicator. Do not overfill.
4. Reinsert the water tank firmly into the base unit until it clicks into place.

5.3. Initial Use

Before first use, it is recommended to iron an old cloth for a few minutes to remove any manufacturing residues from the soleplate.

6. OPERATING INSTRUCTIONS

6.1. Powering On and Heating

1. Place the steam generator iron on a stable ironing board.
2. Plug the power cord into a grounded electrical outlet.
3. Press the ON/OFF button. The indicator light will flash, indicating the appliance is heating up.
4. Once the light stops flashing and remains solid, the iron is ready for use. This usually takes a few minutes.

6.2. Ironing without Temperature Adjustment

This appliance features a "No Settings" technology, providing an optimal steam/temperature combination for all ironable fabrics without manual adjustment. This prevents burning delicate garments.

6.3. Using Steam

- **Continuous Steam:** Press and hold the steam trigger located under the iron handle. Release to stop steam.
- **Steam Boost (Pressing Function):** For stubborn creases, press the steam boost button (often located on top of the handle) for a powerful burst of steam (up to 420 g/min).

- **Vertical Steaming:** Hold the iron vertically a few centimeters from the fabric. Press the steam trigger or steam boost button to remove creases from hanging garments, curtains, etc.

6.4. Dry Ironing

If you wish to iron without steam, simply do not press the steam trigger. The iron will function as a dry iron.

6.5. After Ironing

1. Press the ON/OFF button to turn off the appliance.
2. Unplug the power cord from the electrical outlet.
3. Allow the iron to cool down completely before storing.
4. Store the iron on its base unit, ensuring the steam hose and power cord are neatly stored (if applicable).

7. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and extends the lifespan of your appliance.

7.1. Cleaning the Soleplate

If the soleplate becomes dirty, clean it with a damp cloth and a non-abrasive cleaner. Do not use metallic pads or abrasive cleaning agents.

7.2. Emptying the Water Tank

After each use, or before storing for an extended period, empty any remaining water from the tank. Ensure the appliance is cool and unplugged.

7.3. Descaling (Anti-Calc Collector)

Your Calor Express Anti Calc SV8054C0 is equipped with an exclusive removable scale collector for easy maintenance and long-lasting steam performance. The appliance will typically indicate when it's time to clean the collector (e.g., with a dedicated indicator light).

1. Ensure the appliance is completely cool and unplugged.
2. Locate the scale collector, usually at the front or side of the base unit.
3. Twist or pull the collector to remove it (refer to specific diagrams in your printed manual if available).
4. Rinse the collector thoroughly under running water to remove all scale deposits.
5. Reinsert the clean collector firmly into its housing until it locks into place.

Note: Do not use chemical descaling products in the water tank or on the appliance, as they may damage it.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No steam is coming out.	Water tank is empty. Appliance not heated up. Steam trigger not pressed.	Fill the water tank. Wait for the indicator light to stop flashing. Press the steam trigger.
Water droplets are coming from the soleplate.	Iron not hot enough. Steam used too frequently.	Wait for the iron to reach operating temperature. Allow a few seconds between steam bursts.
Scale particles are coming from the soleplate.	Scale collector needs cleaning.	Clean the removable scale collector as described in section 7.3.
The iron is not heating up.	Appliance not plugged in. ON/OFF button not pressed.	Check power connection. Press the ON/OFF button.

9. TECHNICAL SPECIFICATIONS

Brand: Calor

Model Number: SV8054C0

Color: White/Purple

Product Dimensions (L x W x H): 24.9 x 21.1 x 35.15 cm

Item Weight: 3.96 Kilograms

Power: 2800 Watts

Pump Pressure: Up to 6.5 bars

Continuous Steam Output: 120 g/min

Steam Boost (Pressing Function): 420 g/min

Soleplate Material: Durilium Airglide

Water Tank: Removable

Special Features: Steam Control, Lightweight, Scale Prevention (Removable Scale Collector), No Temperature Settings

Automatic Shut-off Function: No

Recommended Use: Ironing

Country of Origin: Made in France

10. WARRANTY AND SUPPORT

10.1. Warranty Information

This product is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase or visit the official Calor website for detailed terms and conditions. Keep your proof of purchase for warranty claims.

10.2. Customer Support

For technical assistance, spare parts, or service, please contact Calor customer support. Contact details can typically be found on the official Calor website or in the warranty documentation.

You can visit the Calor brand store for more information:[Calor Official Store](#)