

## Mamas & Papas 756036300

# Mamas & Papas Welcome to The World Musical Cot/Cotbed Mobile Instruction Manual

Model: 756036300

## 1. INTRODUCTION

---

Thank you for choosing the Mamas & Papas Welcome to The World Musical Cot/Cotbed Mobile. This mobile is designed to create a soothing and engaging environment for your baby, featuring a relaxing lullaby and soft felt shapes. Please read this instruction manual carefully before assembly and use, and retain it for future reference.

## 2. SAFETY INFORMATION

---

**WARNING:** Possible entanglement injury. Keep out of baby's reach. Remove mobile from cot or cotbed when baby begins to push up on hands and knees or reaches 5 months of age, whichever comes first. This product is not a toy. Do not allow children to play with it.

- Always ensure the mobile is securely attached to the cot/cotbed according to the instructions.
- Regularly check all parts for wear and tear. Discontinue use if any part is damaged.
- Do not add additional strings or straps to the mobile.
- Keep all packaging materials away from children to avoid suffocation hazards.
- This mobile is suitable for babies aged 0 to 5 months approximately.

## 3. PACKAGE CONTENTS

---

Ensure all components are present before assembly:

- 1 x Musical Mobile Arm and Mechanism
- 1 x Mobile Ring with Felt Cloud and Star Decorations

## 4. SETUP AND ASSEMBLY

---

Follow these steps to assemble and attach your musical mobile:

1. **Attach the Mobile Arm:** Securely fasten the mobile arm to the side rail of your cot or cotbed. Ensure the clamp is tightened firmly to prevent movement. The arm should be positioned so the mobile hangs centrally over the cot, but out of the baby's reach.
2. **Attach the Mobile Ring:** Carefully hook the mobile ring, with its attached felt decorations, onto the hook at the end of the mobile arm. Ensure it is securely suspended.
3. **Positioning:** Adjust the mobile arm if necessary to ensure the mobile is at an appropriate height and distance from your baby. It should be visually stimulating but not within reach.



Image 1: The Mamas & Papas Welcome to The World Musical Mobile securely attached to a cot. The white mobile arm extends over the cot, suspending a grey ring from which felt clouds, stars, and moons hang. This image demonstrates the mobile's appearance when installed.



Image 2: A close-up view of the Mamas & Papas Welcome to The World Musical Mobile. It features a white mobile arm, a grey fabric-wrapped ring, and hanging felt decorations including white clouds, yellow stars, and grey crescent moons. This image highlights the design details of the mobile.

## 5. OPERATING INSTRUCTIONS

The Mamas & Papas Musical Mobile operates via a wind-up mechanism:

- 1. Wind-Up Mechanism:** Locate the winding key on the musical mechanism unit, typically found at the top of the mobile arm.
- 2. Activate Music and Movement:** Gently turn the winding key clockwise until you feel a slight resistance. Do not over-wind. The mobile will begin to rotate slowly, and a soothing lullaby will play.
- 3. Duration:** The music and rotation will continue for a set period until the mechanism unwinds. There is no

separate control to stop the music or rotation independently; they operate together.

The gentle rotation and soft music are designed to help soothe your baby to sleep and provide visual stimulation.

## 6. MAINTENANCE AND CARE

To ensure the longevity and hygiene of your mobile, follow these care instructions:

- **Cleaning:** Wipe the plastic mobile arm and musical unit with a damp cloth and mild soap. Do not immerse in water.
- **Felt Decorations:** The felt clouds, stars, and moons can be spot cleaned with a damp cloth. Do not machine wash or tumble dry.
- **Storage:** When not in use, store the mobile in a clean, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the mobile for any loose parts, frayed fabric, or damage to the winding mechanism.

## 7. TROUBLESHOOTING

If you encounter any issues with your musical mobile, please refer to the following:

- **Mobile Not Spinning or Music Not Playing:**
  - Ensure the winding key has been fully turned clockwise (without over-winding).
  - Check for any obstructions preventing the mobile from rotating freely.
  - Verify that the mobile ring is correctly hooked onto the arm.
- **Music Duration is Short:**
  - The mobile features a mechanical wind-up mechanism with a fixed play duration. This is a design characteristic and not a malfunction.
- **Mobile Feels Loose on Cot:**
  - Re-tighten the clamp that secures the mobile arm to the cot/cotbed rail. Ensure it is firmly attached.

If problems persist, please contact Mamas & Papas customer support.

## 8. SPECIFICATIONS

<b>Brand:</b>	Mamas & Papas
<b>Model Number:</b>	756036300
<b>Special Feature:</b>	Musical
<b>Material Type:</b>	Felt
<b>Product Dimensions (L x W x H):</b>	9.06 x 9.06 x 13.19 inches (23 x 23 x 33.5 cm)
<b>Item Weight:</b>	2 pounds (approx. 907 grams)
<b>Target Gender:</b>	Unisex
<b>Batteries Required:</b>	No

**Age Suitability:**

0 - 5 months approx.

## 9. WARRANTY AND SUPPORT

---

Mamas & Papas products are manufactured to high-quality standards. For information regarding warranty, returns, or technical support, please visit the official Mamas & Papas website or contact their customer service department directly. Please have your model number (756036300) and proof of purchase ready when contacting support.

**Website:** [www.mamasandpapas.com](http://www.mamasandpapas.com)