

REVLON RVST2184

REVLON Smooth Brilliance Ceramic Hair Flat Iron (Model RVST2184) Instruction Manual

1. PRODUCT OVERVIEW

The REVLON Smooth Brilliance Ceramic Hair Flat Iron, Model RVST2184, is designed to quickly and gently smooth hair, providing shiny results with reduced frizz. It features 1.5-inch extra-long, extra-wide plates with advanced Ionic Tourmaline and a 3X Ceramic styling surface. The True-Grip Technology ensures an effortless glide, and the rounded plate design allows for both sleek straight styles and loose waves. This flat iron offers ten LED variable heat settings, reaching up to 455°F, for precise temperature control suitable for all hair types. Additional features include a plate-locking switch for convenient storage, a separate on/off switch, and an automatic shut-off for safety.

- **1.5" XL Plates:** Designed for faster styling, especially on longer or thicker hair.
- **4X Straighter, Smooth, Shiny Results:** Achieves significantly straighter and smoother hair.
- **455°F Professional High Heat:** Provides high heat for effective styling.
- **3X Ceramic Tourmaline Ionic Technology:** Helps reduce damage, enhance shine, and minimize frizz.
- **Auto Shut-Off:** For enhanced safety and peace of mind.



Figure 1: REVLON Smooth Brilliance Ceramic Hair Flat Iron (Model RVST2184).

2. IMPORTANT SAFEGUARDS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury. Please read all instructions carefully before use.

- **Water Hazard:** Keep this appliance away from water. Do not use it near bathtubs, showers, basins, or other vessels containing water.
- **Unplug After Use:** Always unplug the appliance immediately after use and before cleaning.
- **Damaged Cord:** Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged.
- **Heat Surfaces:** Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- **Supervision:** Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- **Intended Use:** Use this appliance only for its intended household use as described in this manual. Do not use

attachments not recommended by the manufacturer.

- **Outdoor Use:** Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- **Storage:** Store the appliance in a cool, dry place when not in use.

For more detailed safety information, refer to the complete product manual included with your purchase.

3. GETTING STARTED (SETUP)

1. **Unpack:** Carefully remove the flat iron from its packaging. Ensure all components are present and undamaged.
2. **Plate-Locking Switch:** Locate the plate-locking switch, typically near the base of the plates. Slide it to the 'unlocked' position to allow the plates to open. This switch is also used to lock the plates together for compact storage.
3. **Plug In:** Plug the appliance into a standard electrical outlet. Ensure your hands are dry before plugging in or unplugging the unit.



Figure 2: Key features of the REVLON Smooth Brilliance Flat Iron.

4. OPERATING INSTRUCTIONS

1. **Prepare Hair:** Ensure your hair is clean, completely dry, and detangled. For best results and heat protection, apply a heat protectant spray evenly through your hair.
2. **Turn On:** Press the ON/OFF button to activate the flat iron. The LED display will illuminate.
3. **Select Temperature:** Use the temperature control buttons to select your desired heat setting. The flat iron features 10 LED variable heat settings, ranging up to 455°F. Start with a lower temperature for fine or damaged hair and increase as needed for thicker or coarser hair. Allow a few moments for the iron to reach the selected temperature.
4. **Section Hair:** Divide your hair into small, manageable sections (approximately 1-2 inches wide). Use clips to hold the unstyled sections out of the way.

5. **Style Hair:** Place a section of hair between the heating plates, close to the roots. Gently clamp the plates together and smoothly glide the flat iron down the length of the hair section, from roots to ends. Do not hold the iron in one place for too long to avoid heat damage. Repeat if necessary, but typically one or two passes are sufficient. The rounded plate design also allows for creating loose waves by rotating the iron as you glide.
6. **Cool Down:** After styling, allow your hair to cool completely before brushing or further styling to set the style.
7. **Turn Off:** Press and hold the ON/OFF button to turn off the appliance. Unplug the flat iron from the electrical outlet.



**3X Ceramic
Tourmaline
Ionic Coating**
Helps fight frizz
and enhances shine



Figure 3: The 10 LED variable heat settings for precise control.



Figure 4: Benefits of the 3X Ceramic Tourmaline Ionic Coating and versatile styling options.

Your browser does not support the video tag.

Video 1: An official overview of Revlon Hair Tools, demonstrating various styling products including flat irons. This video provides a general visual guide to using Revlon styling tools.

5. MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and optimal performance of your flat iron.

- **Cool Down:** Always ensure the flat iron is unplugged and completely cool before cleaning.
- **Cleaning Plates:** Wipe the styling plates with a soft, damp cloth. Do not use abrasive cleaners, harsh detergents, or solvents, as these can damage the ceramic coating.
- **Cleaning Body:** Wipe the exterior of the appliance with a soft, damp cloth.
- **Storage:** After cleaning and ensuring the appliance is dry, engage the plate-locking switch to keep the plates closed. Store the flat iron in a cool, dry place, out of reach of children. Do not wrap the cord around the appliance,

as this can cause damage over time.

6. TROUBLESHOOTING

If you encounter issues with your REVLON Smooth Brilliance Ceramic Hair Flat Iron, refer to the following common solutions:

Problem	Possible Cause	Solution
Appliance does not turn on or heat up.	Not plugged in correctly; Power outlet issue; Appliance malfunction.	Ensure the plug is fully inserted into a working electrical outlet. Check your household circuit breaker. If the issue persists, contact customer support.
Uneven heating or poor styling results.	Hair not properly prepared; Incorrect temperature setting; Plates are dirty.	Ensure hair is clean, dry, and detangled. Adjust the temperature setting according to your hair type. Clean the plates as described in the Maintenance section.
Appliance automatically shuts off during use.	Safety auto shut-off feature activated.	This is a safety feature. Turn the appliance off and then on again. If it continues to shut off frequently, ensure proper ventilation and contact customer support if the problem persists.

If troubleshooting steps do not resolve the issue, please contact customer support.

7. PRODUCT SPECIFICATIONS

- **Model Number:** RVST2184
- **Plate Size:** 1.5 Inch XL Plates
- **Plate Material:** 3X Ceramic Tourmaline Ionic Coated Plates
- **Max Temperature Setting:** 455°F (235°C)
- **Heat Settings:** 10 LED Variable Heat Settings
- **Power Source:** Corded Electric
- **Product Dimensions:** 2.13 x 4.5 x 15.25 inches
- **Item Weight:** 16 ounces (1 pound)
- **Special Features:** True-Grip Floating Plates, Rounded Plate Design, Plate-Locking Switch, Auto Shut-Off, Tangle-Free Swivel Cord

8. WARRANTY AND CUSTOMER SUPPORT

This REVLON product is covered by a manufacturer's warranty. For specific details regarding the warranty period and terms, please refer to the warranty information provided in the complete product manual included with your purchase. The manufacturer warranty description states: "See Product Manual".

For technical assistance, troubleshooting beyond the scope of this manual, or warranty claims, please contact REVLON customer support. Contact information can typically be found on the product packaging, the official REVLON website, or within the full product manual.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question