

## Gimebox H96 Max M2

# Gimebox H96 Max M2 Android 13.0 Smart Box User Manual

Model: H96 Max M2 (S905X2)

Brand: Gimebox

## 1. INTRODUCTION

---

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Gimebox H96 Max M2 Android 13.0 Smart Box. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your user experience.

## 2. PRODUCT OVERVIEW

---

### 2.1 Package Contents

- Gimebox H96 Max M2 Android Smart Box
- Remote Control
- Power Adapter (DC 5V/2A)
- HDMI Cable
- User Manual (this document)

### 2.2 Device Layout

Familiarize yourself with the ports and indicators on your Smart Box.



Figure 1: Top view of the Gimebox H96 Max M2 Android Smart Box, featuring the '8K ULTRA HD' logo and a sleek white design.



Figure 2: Side view of the Gimebox H96 Max M2, illustrating the available connectivity ports such as USB and Ethernet.



Figure 3: The Gimebox H96 Max M2 Smart Box displayed with its accompanying remote control, highlighting the compact design of both units.

## 2.3 Available Ports

- **HDMI Output:** Connects to your TV or display.
- **USB 3.0 Port:** For high-speed data transfer with external devices.
- **USB 2.0 Port:** For connecting peripherals like keyboards, mice, or USB drives.
- **Ethernet (LAN) Port:** For wired network connection.
- **DC Power Input:** Connects to the provided power adapter.

## 3. SETUP GUIDE

---

Follow these steps to set up your Gimebox H96 Max M2 Smart Box:

1. **Connect to TV:** Insert one end of the HDMI cable into the HDMI port on the Smart Box and the other end into an available HDMI input on your television.
2. **Connect to Power:** Plug the DC power adapter into the DC Power Input port on the Smart Box, then plug the adapter into a wall outlet. The device should power on automatically or can be turned on using the remote control.
3. **Connect to Network (Optional):**
  - **Wired Connection:** Connect an Ethernet cable from your router to the Ethernet (LAN) port on the Smart Box.
  - **Wireless Connection:** During the initial setup or via system settings, select your Wi-Fi network and enter the password. The device supports Dual-WiFi (2.4G and 5G).
4. **Initial Setup:** Follow the on-screen instructions to complete the initial setup, including language selection, screen calibration, and Google account login.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Basic Navigation

- Use the arrow keys on the remote control to navigate through menus and select items.
- The "OK" button confirms selections.
- The "Back" button returns to the previous screen.
- The "Home" button returns to the main Android home screen.

### 4.2 Connecting to Wi-Fi

1. From the home screen, navigate to **Settings**.
2. Select **Network & Internet**.
3. Turn on **Wi-Fi** if it's off.
4. Select your desired Wi-Fi network from the list.
5. Enter the Wi-Fi password using the on-screen keyboard and select **Connect**.

### 4.3 Installing Applications

You can install applications from the Google Play Store or by sideloading APK files.

- **Google Play Store:** Open the Play Store app, search for your desired application, and select "Install".
- **Sideloading:** Download the APK file to a USB drive, connect the USB drive to the Smart Box, and use a file manager app to locate and install the APK. Ensure "Unknown sources" installation is enabled in Security settings.

### 4.4 Using Bluetooth

Connect Bluetooth devices such as headphones, game controllers, or keyboards.

1. Go to **Settings > Connected devices > Pair new device**.
2. Put your Bluetooth device into pairing mode.
3. Select your device from the list on the Smart Box to pair.

## 5. MAINTENANCE

---

Proper maintenance ensures the longevity and optimal performance of your Smart Box.

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid liquid cleaners or abrasive materials.
- **Software Updates:** Periodically check for system updates in **Settings > About device > System update** to ensure you have the latest features and security patches.
- **Ventilation:** Ensure the device is placed in a well-ventilated area to prevent overheating. Do not cover ventilation openings.
- **Power Off:** When not in use for extended periods, it is recommended to power off the device and unplug the power adapter.

## 6. TROUBLESHOOTING

---

If you encounter issues with your Gimebox H96 Max M2, refer to the following common problems and solutions:

- **No Power:**
  - Ensure the power adapter is securely connected to both the device and a working power outlet.
  - Verify the power outlet is functional by plugging in another device.
- **No Display on TV:**
  - Check if the HDMI cable is securely connected to both the Smart Box and the TV.
  - Ensure your TV is set to the correct HDMI input source.
  - Try a different HDMI cable or HDMI port on your TV.
- **Wi-Fi Connection Issues:**
  - Restart your router and the Smart Box.
  - Ensure you have entered the correct Wi-Fi password.
  - Move the Smart Box closer to your Wi-Fi router to improve signal strength.
  - Consider using a wired Ethernet connection for stability.
- **Remote Control Not Responding:**
  - Replace the batteries in the remote control.
  - Ensure there are no obstructions between the remote and the Smart Box.
  - If the remote is an IR remote, ensure it is pointed directly at the IR receiver on the Smart Box.
- **System Freezing or Rebooting:**
  - Ensure the device has adequate ventilation and is not overheating.
  - Close unnecessary background applications.
  - Perform a factory reset (**Settings > System > Reset options > Erase all data (factory reset)**).

*Note: This will delete all user data and installed apps.*

## 7. SPECIFICATIONS

| Feature                 | Detail                            |
|-------------------------|-----------------------------------|
| Operating System        | Android 13.0                      |
| CPU                     | RK3528 Quad Core ARM Cortex A53   |
| GPU                     | Penta-Core Mali-450 Up to 750Mhz+ |
| RAM                     | 4GB DDR3                          |
| ROM (Storage)           | 64GB EMMC                         |
| Wi-Fi                   | Dual-Band (2.4GHz & 5GHz)         |
| Bluetooth               | BT 5.0                            |
| Ethernet LAN            | 10/1000M Standard RJ-45           |
| USB Ports               | 1x USB 3.0, 1x USB 2.0            |
| Power Supply            | DC 5V/2A                          |
| Video Output Resolution | Up to 4K (Supports 6K decoding)   |
| Model Number            | S905X2                            |

|                    |                     |
|--------------------|---------------------|
| Product Dimensions | 11 x 11 x 11 inches |
| Item Weight        | 14.1 ounces         |

## 8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided at the time of purchase or contact Gimebox customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

For further assistance, you may visit the Gimebox store on Amazon:[Gimebox Store](#)