

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SoBuy](#) /

› [SoBuy Children's Bookshelf FRG225-W Instruction Manual](#)

## SoBuy FRG225-W

# SoBuy Children's Bookshelf FRG225-W Instruction Manual

Model: FRG225-W | Brand: SoBuy

## INTRODUCTION

Thank you for choosing the SoBuy Children's Bookshelf FRG225-W. This compact and functional storage unit is designed to help organize children's books and toys, promoting an independent reading and tidying habit. Please read this manual carefully before assembly and use to ensure safe and proper operation.

## SAFETY INFORMATION

- This product is intended for use by children aged 3 years and older, under adult supervision.
- Do not exceed the maximum weight capacity of 25 kg (55 lbs). Overloading may cause instability and injury.
- Ensure all screws and fasteners are securely tightened during assembly and periodically check for tightness.
- Keep small parts away from young children during assembly to prevent choking hazards.
- Place the bookshelf on a flat, stable surface to prevent tipping.
- The design features rounded corners for child safety; however, always supervise children during use.

## PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact SoBuy customer service.

Part	Description	Quantity
A	Side Panel (Left)	1
B	Side Panel (Right)	1
C	Bottom Support Bar	1
D	Fabric Pockets (Beige)	4
E	Screws (various sizes)	Set

Part	Description	Quantity
F	Allen Key / Assembly Tool	1

## ASSEMBLY INSTRUCTIONS

Follow these steps carefully for quick and easy assembly. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

### 1. Step 1: Attach the Bottom Support Bar.

Align the bottom support bar (Part C) with the pre-drilled holes on one of the side panels (Part A). Secure it using the appropriate screws (Part E) and the provided assembly tool (Part F). Ensure it is firmly attached.



*Image: Detail of the bookshelf's base, illustrating the connection point for the bottom support bar.*

### 2. Step 2: Attach the Second Side Panel.

Connect the other side panel (Part B) to the opposite end of the bottom support bar (Part C), aligning the holes and securing with screws (Part E). At this stage, the basic frame should be standing.



*Image: Overall structure and dimensions of the bookshelf, providing a visual reference for the frame.*

### 3. Step 3: Install the Fabric Pockets.

The bookshelf features four fabric pockets (Part D). Insert the support rods of each fabric pocket into the designated slots on the side panels. Start from the top pocket and work your way down. Ensure each pocket is securely seated.



*Image: Detailed view of the four fabric pockets, indicating their position and how books are placed.*

### 4. Step 4: Final Check.

Once all fabric pockets are installed, double-check all screws to ensure they are tight. Gently shake the bookshelf to confirm stability. The rounded corners are designed for safety.



*Image: Close-up of a rounded corner, demonstrating the child-safe design.*

## USAGE

---

The SoBuy Children's Bookshelf is designed to encourage independent access to books and toys. Its four fabric pockets allow books to be displayed face-forward, making them easily visible and accessible for young children. This design supports a Montessori-inspired approach to learning and organization.

- Place books and small toys in the fabric pockets.
- Distribute weight evenly to maintain stability.
- The compact size makes it suitable for various rooms, including bedrooms, playrooms, and study areas.



*Image: The assembled bookshelf with books and toys, demonstrating its intended use.*

## **MAINTENANCE AND CARE**

---

To ensure the longevity and appearance of your SoBuy Children's Bookshelf, follow these simple care instructions:

- **Cleaning:** Wipe the wooden frame with a dry, soft cloth. For the fabric pockets, spot clean with a damp cloth and mild soap if necessary, then air dry. Do not use abrasive cleaners or harsh chemicals.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if loose.
- **Placement:** Avoid placing the bookshelf in direct sunlight or near heat sources, as this may cause the wood to warp or fade.

## **TROUBLESHOOTING**

---

If you encounter any issues with your SoBuy Children's Bookshelf, please refer to the following common solutions:

- **Instability:** Ensure the bookshelf is placed on a level surface. Check that all assembly screws are fully tightened.
- **Missing Parts:** Refer to the "Package Contents" section. If parts are missing upon delivery, contact SoBuy customer service immediately.
- **Difficulty Assembling:** Review the "Assembly Instructions" carefully. Ensure you are using the correct screws for each step. If problems persist, contact customer support.

## SPECIFICATIONS

Feature	Detail
Brand	SoBuy
Model Number	FRG225-W (also referred to as SA-FRG125-W)
Color	Beige
Dimensions (L x W x H)	62 x 30 x 71 cm (24.4 x 11.8 x 28 inches)
Item Weight	5.22 kg (11.5 lbs)
Maximum Weight Capacity	25 kg (55 lbs)
Material	Multiplex Wood, Fabric
Number of Pockets	4
Special Features	Space-saving, Rounded Corners, Montessori-inspired design
Assembly Required	Yes

## WARRANTY AND SUPPORT



SoBuy products are manufactured to high-quality standards. For any questions, concerns, or assistance with your product, please contact SoBuy customer service. Please have your model number (FRG225-W) and purchase information ready when contacting support.

For return information, please refer to the retailer's return policy where the product was purchased.

© 2023 SoBuy. All rights reserved.

## Related Documents - FRG225-W

	<a href="#">SoBuy Furniture Safety Warnings and Anti-Tip Guide</a> Essential safety instructions from SoBuy for preventing furniture tip-over accidents and entrapment injuries. This guide is available in multiple languages to ensure user safety.
--	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

 <p>SoBuy</p> 	<p><a href="#"><u>SoBuy FSR154 Storage Cabinet Assembly Instructions</u></a></p> <p>Step-by-step assembly instructions for the SoBuy FSR154 storage cabinet, including a list of parts, tools required, and detailed assembly steps.</p>
 <p>SoBuy</p> 	<p><a href="#"><u>SoBuy FBT115-L Nightstand with 3 Drawers - Assembly Instructions</u></a></p> <p>Comprehensive assembly instructions for the SoBuy FBT115-L nightstand, a 3-drawer bedside cabinet. Includes a detailed parts list, hardware inventory, and step-by-step guidance for building the furniture.</p>
 <p>SoBuy</p>  	<p><a href="#"><u>SoBuy OGS28 Rocking Chair Assembly Instructions and Safety Guide</u></a></p> <p>Comprehensive assembly instructions and safety information for the SoBuy OGS28 rocking chair. Learn how to assemble your chair safely and efficiently.</p>
 <p>SoBuy</p> 	<p><a href="#"><u>SoBuy BZR34-II Tall Cabinet Assembly Instructions</u></a></p> <p>Detailed step-by-step assembly instructions for the SoBuy BZR34-II tall cabinet, including a parts list, tools required, and visual guides for furniture assembly.</p>
<p>Ages 14+</p> <p><b>UDIRC</b> DISCOVERY 2 U818A Plus-W</p>  <p>U818A Plus-W Operations Guide</p>	<p><a href="#"><u>UDIRC U818A Plus-W Discovery 2 Drone Operations Guide</u></a></p> <p>Comprehensive operations guide for the UDIRC U818A Plus-W Discovery 2 drone, covering setup, flight controls, app usage, component installation, spare parts, and troubleshooting. Features a 720P HD WiFi camera and is suitable for users aged 14+.</p>