

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [Infinix](#) /
- › Infinix Hot 6 Pro X608 Smartphone User Manual

Infinix Hot 6 Pro X608

Infinix Hot 6 Pro X608 Smartphone User Manual

Model: Hot 6 Pro X608

1. DEVICE OVERVIEW

The Infinix Hot 6 Pro X608 is a dual SIM smartphone featuring a 6-inch display, 32GB internal storage, and 3GB RAM. It operates on Android 6.0 and supports 4G LTE connectivity. Key features include a fingerprint sensor and a dual rear camera setup.



Image: Front and back view of the Infinix Hot 6 Pro X608 smartphone. The front displays a vibrant screen, while the back shows the dual camera, fingerprint sensor, and Infinix branding.

2. SETUP

2.1 Inserting SIM Cards and SD Card

The Infinix Hot 6 Pro X608 supports dual SIM cards. Follow these steps to insert your SIM and/or microSD card:

1. Locate the SIM/SD card tray on the side of your device.
2. Use the provided SIM ejector tool to gently push into the small hole on the tray until it pops out.
3. Place your Nano-SIM cards into the designated slots, ensuring the gold contacts face downwards. If using a microSD card, place it in its dedicated slot.
4. Carefully push the tray back into the device until it is flush with the side.

2.2 Charging the Battery

Before first use, fully charge the device battery. Use only the charger and cable provided with your device.

1. Connect the USB cable to the charging adapter.
2. Plug the charging adapter into a power outlet.
3. Connect the USB cable to the charging port on your phone. The charging indicator will appear on the screen.

The device features a 4000 mAh battery capacity.

2.3 Powering On/Off

- To power on: Press and hold the Power button until the Infinix logo appears.
- To power off: Press and hold the Power button, then select 'Power off' from the options on the screen.

3. OPERATING INSTRUCTIONS

3.1 Basic Navigation

The device runs on Android 6.0. Navigate using touch gestures:

- **Tap:** Select an item or activate a function.
- **Swipe:** Scroll through screens or lists.
- **Pinch:** Zoom in or out on images and web pages.

3.2 Fingerprint Sensor

The device includes a rear-mounted fingerprint sensor for enhanced security and quick unlocking.

1. Go to *Settings > Security > Fingerprint*.
2. Follow the on-screen instructions to register your fingerprint.
3. Once registered, you can use your fingerprint to unlock the device or authorize purchases.

3.3 Camera Usage

The Infinix Hot 6 Pro X608 features a 13 Megapixel dual rear camera and a 5 Megapixel front camera.

- Open the **Camera** application.
- Tap the shutter button to take a photo.
- Switch between front and rear cameras using the camera toggle icon.

- Explore various shooting modes, including High Dynamic Range (HDR), for optimal photo quality.

3.4 Connectivity

The device supports various connectivity options:

- **Wi-Fi:** Connect to wireless networks for internet access. Go to *Settings > Wi-Fi*.
- **Bluetooth:** Pair with other Bluetooth-enabled devices like headphones or speakers. Go to *Settings > Bluetooth*.
- **USB:** Connect to a computer for file transfer or charging.
- **4G LTE:** Utilize high-speed mobile data networks. Ensure your SIM card supports 4G LTE.

4. MAINTENANCE

4.1 Battery Care

- Avoid exposing the device to extreme temperatures.
- Do not allow the battery to fully discharge frequently.
- Use only original or certified chargers and cables.

4.2 Cleaning the Device

To clean your device:

- Power off the device before cleaning.
- Use a soft, lint-free cloth to wipe the screen and body.
- Avoid using harsh chemicals or abrasive materials.
- Note: This device is **not water resistant**. Avoid contact with liquids.

4.3 Software Updates

Regularly check for software updates to ensure optimal performance and security. Go to *Settings > About phone > System updates*.

5. TROUBLESHOOTING

If you encounter issues with your Infinix Hot 6 Pro X608, try the following steps:

- **Device unresponsive:** Press and hold the Power button for about 10-15 seconds to force a restart.
- **App issues:** Clear the cache and data for the problematic app in *Settings > Apps*. If the issue persists, uninstall and reinstall the app.
- **Network problems:** Ensure your SIM card is properly inserted and that mobile data or Wi-Fi is enabled. Try restarting the device.
- **Slow performance:** Close unnecessary background applications and clear temporary files. Consider performing a factory reset as a last resort (back up your data first).

For further assistance, refer to the official Infinix support website or contact customer service.

6. SPECIFICATIONS

Feature	Specification
Brand Name	Infinix
Model Name	Infinix Hot 6 Pro X608
Operating System	Android 6.0
Installed RAM	3 GB
CPU Model	Snapdragon
Memory Storage Capacity	32 GB
Screen Size	6 inches
Resolution	1079 x 1920
Cellular Technology	LTE
Connectivity Technology	USB, Bluetooth, Wi-Fi
Color	Black
Number of SIM Card Slots	Dual SIM
Form Factor	Slate
Biometric Security Feature	Fingerprint Recognition
Water Resistance Level	Not Water Resistant
Special Features	Dual SIM, 4G LTE, Quad-Core Processor, High Dynamic Range, Fingerprint Recognition
Front Camera Sensor Resolution	5 Megapixels
Rear Camera Sensor Resolution	13 Megapixels
Camera Description	Front
Camera Flash	Built-in
Shooting Modes	High Dynamic Range
Optical Sensor Resolution	13 Megapixels
Number of Rear Cameras	2
Number of Front Cameras	1
Item Weight	398.86 grams
GPS	Yes
Display Type	LCD
Max Display Resolution	1080 Pixels

Feature	Specification
Wireless Communication Technology	LTE Network
Manufacturing Year	2018
Manufacturer	Infinix
Specific Product Uses	General Use, Communication, Multimedia Consumption
Battery Capacity	4000 mAh
Effective Video Resolution	13 Megapixels
Video Capture Resolution	13 Megapixels

7. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product packaging or visit the official Infinix website. For technical support, frequently asked questions, and service center locations, please visit the [Infinix Brand Store](#) or their official support channels.