

[Manuals.plus](#) /

> [Featherlite](#) /

> Featherlite Liberate High Back Desk Arm Chair User Manual

## Featherlite Liberate

# Featherlite Liberate High Back Desk Arm Chair User Manual

Model: Liberate (RLBRHBBPL2M06AA51ZZ)

## INTRODUCTION

This manual provides essential instructions for the assembly, operation, maintenance, and troubleshooting of your Featherlite Liberate High Back Desk Arm Chair. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product.

## SAFETY INFORMATION

**Important:** This chair is designed and intended for seating purposes only. Misuse may result in injury or damage to the product.

- Ensure all components are securely fastened before use.
- Do not stand on the chair.
- Do not exceed the maximum weight capacity of 150 kg.
- Keep hands and fingers clear of moving parts during adjustments.

## PACKAGE CONTENTS

Upon unpacking, verify that all the following components are present:

- 1 x Featherlite Liberate High Back Desk Arm Chair
- 1 x Assembly Instruction Manual (this document)

## SETUP AND ASSEMBLY

The Featherlite Liberate chair requires basic assembly. An instruction manual is included to guide you through the process. It is recommended to assemble the chair on a soft, clean surface to prevent damage.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out.
2. **Attach Wheels to Base:** Insert the casters (wheels) into the holes on the chair base until they click securely into place.
3. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the chair base.
4. **Assemble Seat and Backrest:** Follow the specific instructions provided in the included assembly manual to attach the backrest to the seat mechanism and then to the seat.
5. **Attach Armrests:** Secure the armrests to the seat assembly using the provided hardware.
6. **Connect Seat to Base:** Carefully place the assembled seat onto the gas lift cylinder.
7. **Final Check:** Ensure all screws are tightened and all components are securely connected before using the chair.



Figure 1: Front view of the Featherlite Liberate High Back Desk Arm Chair. This image shows the chair fully assembled, highlighting its mesh backrest, upholstered seat, and adjustable armrests.

## OPERATING INSTRUCTIONS

Your Featherlite Liberate chair offers several adjustment features to customize your seating experience for optimal

comfort and support.

### **1. Seat Height Adjustment**

To adjust the seat height, locate the lever on the right side, beneath the seat. While seated, pull the lever up to lower the seat. To raise the seat, stand up and pull the lever up. Release the lever at the desired height.

### **2. Armrest Height Adjustment**

The armrests are one-way height adjustable. Locate the button or lever on the side of each armrest support. Press and hold the button/lever, then move the armrest up or down to your preferred height. Release the button/lever to lock it in place.

### **3. Recline and Tension Control**

The chair features a recline function with tension control. To recline, locate the lever on the left side, beneath the seat. Pull the lever out to unlock the recline mechanism. Lean back to recline and push the lever in to lock the backrest in an upright position.

The tension control knob, located beneath the seat at the front, allows you to adjust the resistance of the recline. Turn the knob clockwise to increase tension (making it harder to recline) or counter-clockwise to decrease tension (making it easier to recline).



Figure 2: Ergonomic illustration of a user in the Featherlite Liberate chair. This image demonstrates how the chair supports the user's posture and provides a visual reference for proper seating.

## MAINTENANCE

---

Regular maintenance helps preserve the appearance and functionality of your chair.

- **Cleaning:** Wipe clean with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the fabric and mesh.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary.
- **Moving Parts:** Ensure the casters (wheels) are free of debris to allow smooth movement.
- **Fabric Care:** For upholstered fabric, spot clean with a mild detergent solution if needed. Test on an inconspicuous area first.

## TROUBLESHOOTING

---

If you encounter issues with your chair, refer to the following common problems and solutions:

- **Chair Sinks or Does Not Stay Up:** This usually indicates an issue with the gas lift cylinder. Contact customer support for a replacement if the chair is still under warranty.
- **Chair Wobbles:** Ensure all assembly screws are securely tightened. Check if the chair is on an even surface.
- **Casters Not Rolling Smoothly:** Inspect casters for trapped hair or debris and clean them. If damaged, replacements may be needed.
- **Recline Mechanism Not Working:** Check the recline lock lever. Ensure it is disengaged for reclining. If the tension is too high, adjust the tension control knob counter-clockwise.
- **Armrests Not Adjusting:** Ensure the adjustment button/lever is fully pressed or engaged. Check for any obstructions.

## SPECIFICATIONS

Feature	Detail
Brand	Featherlite
Model Name	Liberate
Model Number	RLBRHBBPL2M06AA51ZZ
Color	Black
Primary Material	Mesh (Back), Fabric (Seat)
Frame Material	Alloy Steel
Product Dimensions (D x W x H)	43 cm x 48.5 cm x 107.5 cm
Maximum Weight Capacity	150 kg
Armrest Type	Moulded polyurethane, height adjustable
Assembly Required	Yes (DIY)
Item Weight	19 kg
Recommended Use	Office, Gaming




Figure 3: Dimensional drawing of the Featherlite Liberate chair. This diagram provides precise measurements for height, width, and depth, including adjustable ranges for seat and armrests.

## WARRANTY INFORMATION

The Featherlite Liberate High Back Desk Arm Chair comes with a **1-year warranty** against manufacturing defects. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

The warranty does not cover damage resulting from misuse, abuse, accidents, unauthorized repairs, or normal wear and tear.

## CUSTOMER SUPPORT

For any questions, assistance with assembly, troubleshooting, or warranty claims, please contact Featherlite customer support. Refer to the contact information provided with your purchase documentation or visit the official Featherlite website for support details.

Online Resources: [Featherlite Store on Amazon](#)



© 2023 Featherlite. All rights reserved.