De'Longhi EDG250, NDG250

DeLonghi Nescafé Dolce Gusto Jovia Water Tank User Manual

Models: EDG250, NDG250

Introduction

This manual provides essential information for the proper use, installation, and maintenance of your DeLonghi Nescafé Dolce Gusto Jovia water tank. Please read these instructions carefully before using the product to ensure optimal performance and longevity.

Product Overview



Figure 1: DeLonghi Nescafé Dolce Gusto Jovia Water Tank

This image displays the transparent plastic water tank, designed as a replacement or spare part for DeLonghi Nescafé Dolce Gusto Jovia EDG250 and NDG250 coffee machines. The tank features a maximum fill line indicator and a small grey valve mechanism at one end, which connects to the coffee machine.

Setup

1. **Unpacking:** Carefully remove the water tank from its packaging. Inspect for any signs of damage.
2. **Initial Cleaning:** Before first use, wash the water tank with warm water and a mild dish soap. Rinse thoroughly to remove any soap residue.
3. **Placement:** Ensure your DeLonghi Nescafé Dolce Gusto Jovia coffee machine (models EDG250 or NDG250) is turned off and unplugged. Locate the water tank compartment at the back of the machine.
4. **Installation:** Align the water tank with the designated slot on the coffee machine. Gently push it down until it clicks securely into place. Ensure there is no gap between the tank and the machine body.

Operating Instructions

1. **Filling the Tank:** Remove the water tank from the coffee machine. Open the lid or fill opening. Fill the tank with fresh, cold drinking water up to the "MAX" fill line indicated on the tank. Do not overfill.
2. **Re-inserting the Tank:** Place the filled water tank back into the coffee machine, ensuring it is seated correctly and securely.
3. **Operation:** Once the tank is properly installed and filled, you can proceed with operating your coffee machine as per its specific instructions. The machine will draw water from this tank for beverage preparation.

Important: Always use fresh water for the best coffee taste and to prevent mineral buildup in your machine.

Maintenance

- **Regular Cleaning:** It is recommended to clean the water tank regularly, ideally once a week or more frequently if used daily.
- **Cleaning Procedure:**
  a. Remove the water tank from the coffee machine.
  b. Empty any remaining water.
  c. Wash the tank with warm water and a mild, non-abrasive dish soap. Use a soft brush or sponge to clean the interior.
  d. Rinse thoroughly under running water to ensure all soap residue is removed.
  e. Allow the tank to air dry completely before re-installing it, or wipe it dry with a clean, lint-free cloth.
- **Descaling:** While the water tank itself does not require descaling, regular descaling of your coffee machine is crucial to prevent mineral buildup that can affect the tank's valve mechanism and the machine's performance. Refer to your coffee machine's manual for descaling instructions.
- **Storage:** If the coffee machine will not be used for an extended period, empty and clean the water tank, then store it in a clean, dry place away from direct sunlight.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Water not flowing from tank to machine.	Tank not seated correctly; valve mechanism blocked; machine needs descaling.	Ensure tank is fully pushed down. Check valve for debris and clean if necessary. Descale the coffee machine as per its manual.
Water leakage from tank.	Tank not seated correctly; crack in tank; damaged seal.	Re-seat the tank firmly. Inspect the tank for cracks. If damaged, replace the tank.
Unpleasant taste in coffee.	Stale water in tank; tank needs cleaning.	Empty and refill with fresh water. Clean the water tank thoroughly.

If problems persist, please refer to your coffee machine's main user manual or contact De'Longhi customer support.

Specifications

- **Brand:** De'Longhi
- **Compatible Models:** Nescafé Dolce Gusto Jovia EDG250, NDG250
- **Material:** High-quality transparent plastic
- **Intended Use:** Replacement or spare water reservoir for compatible coffee machines
- **Quantity:** 1 unit

Warranty and Support

For information regarding warranty coverage, product registration, or technical support, please refer to the documentation provided with your original De'Longhi Nescafé Dolce Gusto Jovia coffee machine or visit the official De'Longhi website.
De'Longhi Official Website: www.delonghi.com

© 2024 De'Longhi. All rights reserved.

This manual is for informational purposes only. De'Longhi is not responsible for any damages or injuries resulting from improper use of this product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question