Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MEE audio HP-KJ35-BL-MEE

MEE audio KidJamz 3 Kids Safe Listening Headphones User Manual

Model: HP-KJ35-BL-MEE

Introduction

Welcome to the user manual for your MEE audio KidJamz 3 Kids Safe Listening Headphones. These headphones are designed with children's hearing safety in mind, featuring volume-limiting technology and a durable, comfortable design. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your headphones to ensure a safe and enjoyable listening experience.

Key Features

- **Volume-Limiting Technology:** Proprietary volume limiter keeps sound pressure level below 85dB, protecting young ears. Includes a hidden switch for parents to disable the limiter in noisy environments.
- **Kid-Friendly Design:** Adjustable headband and vinyl earpad cushions provide a comfortable and secure fit for children aged 4-13.
- **Durable Construction:** Engineered with robust plastics, reinforced connectors, and a flexible headband that resists breaking.
- **Built-in Headset:** Integrated microphone and remote button for distance learning, video calls, gaming, and phone calls.
- **Wide Compatibility:** Works with all devices featuring a standard 3.5mm (1/8") headphone/AUX jack, including tablets, phones, gaming devices, and computers.

Setup

Setting up your KidJamz headphones is straightforward. Follow these steps to get started:

1. **Unpack:** Carefully remove the headphones from their packaging.
2. **Connect:** Insert the 3.5mm audio jack firmly into the headphone port of your device (e.g., tablet, smartphone, computer).
3. **Adjust Fit:** Extend or retract the headband to ensure a comfortable and secure fit on the child's head. The earcups should fully cover the ears.
4. **Volume Limiter Switch:** Locate the hidden volume limiter switch on the earcup. By default, it is engaged for safe listening. If you are in a very noisy environment and require higher volume, a parent can use a small tool (like a pen tip) to disengage the switch. Remember to re-engage it for normal use to protect hearing.



Image: MEE audio KidJamz 3 headphones in blue, showcasing the overall design and inline microphone.



Image: A close-up view of the earcup, highlighting the concealed volume limiter switch for parental control.

Operation

Once connected, your KidJamz headphones are ready for use. Here's how to operate them:

- **Listening:** Play audio from your connected device. The volume will be limited to a safe level (85dB) unless the limiter switch is disengaged.
- **Using the Microphone:** The integrated microphone allows for clear communication during online learning, video chats, or phone calls. Ensure your device's audio input is set to the headphone's microphone.
- **Remote Button:** The inline remote button can be used for basic functions such as playing/pausing audio or answering/ending calls, depending on your device's compatibility.
- **Adjusting Headband:** The flexible headband can be adjusted to fit various head sizes, ensuring comfort during extended use.



Image: A child comfortably wearing the MEE audio KidJamz 3 headphones, illustrating their suitability for travel and general use.



Image: The ultra-flexible headband of the KidJamz 3 headphones, demonstrating its ability to bend without breaking.




Image: A view of the headphones highlighting their adjustable size and soft vinyl earpads for a comfortable fit.



Image: A child using the headphones with a tablet, demonstrating wide compatibility with 3.5mm headphone jack devices.

Maintenance

Proper care and maintenance will extend the life of your KidJamz headphones:

- **Cleaning:** Use a soft, dry cloth to wipe down the headphones. For earpads, a slightly damp cloth can be used, but ensure they are completely dry before next use. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the headphones in a clean, dry place away from extreme temperatures and direct sunlight.
- **Cable Care:** The tangle-resistant cable is designed for durability. Avoid excessive pulling or sharp bends near the connectors to prevent damage.
- **Durability:** While built with robust plastics and a flexible headband, avoid intentional forceful bending or twisting beyond normal use to maintain integrity.

Troubleshooting

If you encounter issues with your KidJamz headphones, try the following solutions:

Problem	Possible Cause / Solution
No sound or sound from only one earcup.	Ensure the 3.5mm audio jack is fully inserted into the device. Check the volume level on your connected device. Verify the volume limiter switch on the earcup is in the desired position. Test the headphones with another device to rule out a device issue.
Microphone not working.	Ensure the 3.5mm audio jack is fully inserted. Check your device's audio input settings to ensure the headphone microphone is selected. Some older devices may not fully support inline microphone functionality.
Sound is too quiet (even with volume up).	Confirm the volume limiter switch is in the desired position. If in the safe listening mode, the volume will be capped at 85dB. Check the volume settings on your connected device.

Specifications

Feature	Detail
Model Name	HP-KJ35-BL-MEE
Connectivity Technology	Wired
Headphones Jack	3.5 mm Jack
Sensitivity	85 dB (Volume Limited)
Frequency Response	20 Hz to 20 kHz
Impedance	32 Ohm
Ear Placement	On Ear
Form Factor	Over Ear
Material	Faux Leather, Plastic
Cable Feature	Tangle Free
Item Weight	3.77 ounces (107 Grams)
Product Dimensions	2.76 x 5.91 x 7.87 inches
Age Range (Description)	Kid (4-13 years recommended)
Included Components	Headphones

Warranty and Support

For warranty information and technical support, please refer to the official MEE audio website or contact their customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.
Brand: MEE audio
Manufacturer: MEE audio

© 2024 MEE audio. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07FR6JQ7W

More documents and user manuals: **https://manuals.plus/**