

HP 4CE98AA#ABD

HP Pavilion 600 Wireless Keyboard User Manual

Model: 4CE98AA#ABD

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your HP Pavilion 600 Wireless Keyboard. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.

The HP Pavilion 600 Wireless Keyboard offers a seamless typing experience with its full-size, three-zone layout, including a numeric keypad and full-size arrow keys, designed for enhanced productivity. Its slim and stylish design integrates well into any workspace.

PACKAGE CONTENTS

Verify that all items are present in the package:

- HP Pavilion 600 Wireless Keyboard
- Wireless Nano USB Receiver
- 2 x AAA Batteries
- Quick Start Guide
- Product Notices
- Warranty Card
- R.E.D. Card
- RTF Card

SETUP

1. Battery Installation

1. Locate the battery compartment on the underside of the keyboard.
2. Open the battery compartment cover.
3. Insert the two AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.

2. Connecting the Wireless Receiver

1. Locate an available USB port on your computer.
2. Insert the Wireless Nano USB Receiver into the USB port.
3. Your computer should automatically detect and install the necessary drivers. This process may take a few moments.
4. Once the drivers are installed, the keyboard is ready for use.



Image: The HP Pavilion 600 Wireless Keyboard, showcasing its full layout and the compact USB receiver. The keyboard is black with white key legends, featuring a standard QWERTY layout, a numeric keypad on the right, and function keys along the top.

OPERATING THE KEYBOARD

Keyboard Layout and Functions

The HP Pavilion 600 Wireless Keyboard features a three-zone layout for enhanced productivity:

- **Main Typing Area:** Standard QWERTY layout with alphanumeric keys, modifiers (Shift, Ctrl, Alt), and special characters.
- **Function Keys (F1-F12):** Located at the top row, these keys often have secondary functions (e.g., media control, volume, brightness) accessible by pressing the **Fn** key simultaneously.
- **Navigation Cluster:** Includes Insert, Home, Page Up, Delete, End, Page Down, and full-size arrow keys for easy document navigation.
- **Numeric Keypad:** A dedicated section on the right for efficient data entry and calculations.

Compatible Operating Systems

This keyboard is compatible with the following operating systems:

- Windows 7
- Windows 8
- Windows 10

For optimal performance, ensure your operating system is up to date.

MAINTENANCE

Cleaning the Keyboard

To maintain the cleanliness and functionality of your keyboard:

- Disconnect the USB receiver from your computer before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive cleaning solution.
- Wipe the surface of the keys and the keyboard body gently.
- Avoid spraying liquids directly onto the keyboard.
- For dust and debris between keys, use compressed air.
- Ensure the keyboard is completely dry before reconnecting the receiver.

Battery Replacement

When the keyboard's performance degrades or it stops responding, it may be time to replace the batteries. Follow the battery installation steps outlined in the [Setup](#) section.

Note: Dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard not responding	Low or dead batteries	Replace the AAA batteries.
Keyboard not responding	USB receiver not properly connected	Ensure the USB receiver is firmly plugged into a working USB port. Try a different USB port.
Keyboard not responding	Interference from other wireless devices	Move the keyboard closer to the USB receiver. Remove other wireless devices that may be causing interference.
Keys are sticky or unresponsive	Dirt or debris under keys	Clean the keyboard using compressed air or a soft cloth as described in the Maintenance section.
Incorrect character input (e.g., no 'Ñ' key)	Incorrect keyboard layout selected in operating system	Verify your operating system's keyboard language and layout settings are set to the correct region (e.g., Spanish QWERTY).

SPECIFICATIONS

Model: 4CE98AA#ABD

Connectivity: Wireless (USB Nano Receiver)

Keyboard Layout: QWERTY (specific regional layout may vary)

Number of Zones: 3 (Main, Navigation, Numeric Keypad)

Compatible Operating Systems: Windows 7, Windows 8, Windows 10

Power Source: 2 x AAA Batteries (included)

Dimensions: Approximately 41 x 11.43 x 1.88 cm (16.14 x 4.5 x 0.74 inches)

Weight: Approximately 630 g (1.39 lbs)

Color: Black

WARRANTY AND SUPPORT

Warranty Information

Your HP Pavilion 600 Wireless Keyboard comes with a standard manufacturer's warranty. Please refer to the included Warranty Card for specific terms, conditions, and duration of coverage in your region. Retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, product inquiries, or warranty service, please visit the official HP support website or contact HP customer service in your region. Contact information can typically be found on the HP website or in the product documentation.

HP Support Website: www.hp.com/support

© 2024 HP Inc. All rights reserved.

HP and Pavilion are trademarks of HP Inc., registered in the U.S. and other countries.