

[manuals.plus](#) /› [Princess](#) /› [Princess 201004 Electric Citrus Juicer User Manual](#)**Princess 201004**

Princess 201004 Electric Citrus Juicer

User Manual

1. INTRODUCTION

Thank you for purchasing the Princess 201004 Electric Citrus Juicer. This appliance is designed to efficiently extract juice from various citrus fruits, providing fresh and healthy beverages. With its 1-liter capacity and adjustable pulp control, it offers convenience and versatility for your daily juicing needs. Please read this manual carefully before first use to ensure safe and optimal operation.



Image: The Princess 201004 Electric Citrus Juicer, fully assembled and containing freshly squeezed orange juice.

2. SAFETY INSTRUCTIONS

To prevent injury or damage, always observe basic safety precautions when using electrical appliances. Keep this manual for future reference.

- Ensure the voltage indicated on the appliance matches your local mains voltage before connecting.
- Do not immerse the motor base in water or any other liquid. Clean only with a damp cloth.
- Keep hands and utensils away from moving parts during operation.
- Unplug the juicer from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.

- Use the appliance only for its intended household purpose.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Princess Electric Citrus Juicer:

1. **Transparent Lid:** Protects the cones from dust and prevents accidental pressing.
2. **Large Juicing Cone:** For larger citrus fruits like oranges and grapefruits.
3. **Small Juicing Cone:** For smaller citrus fruits like lemons and limes.
4. **Pulp Filter:** Separates pulp from juice. Features adjustable settings for desired pulp level.
5. **Juice Container (1L):** Collects the extracted juice, with measurement markings.
6. **Motor Base:** Contains the motor and power cord.





Image: An exploded view showing all individual components of the Princess 201004 Electric Citrus Juicer, including the lid, two juicing cones, pulp filter, juice container, and motor base.

4. SETUP

Before first use, wash all removable parts (lid, cones, pulp filter, juice container) in warm soapy water, rinse thoroughly, and dry. The motor base should only be wiped with a damp cloth.

1. Place the motor base on a stable, flat, and dry surface.
2. Place the juice container onto the motor base, ensuring it is seated correctly.
3. Insert the pulp filter into the juice container. Adjust the filter to your desired pulp level by rotating it.
4. Select the appropriate juicing cone (small for lemons/limes, large for oranges/grapefruits) and place it onto the shaft in the center of the pulp filter. The large cone fits over the small cone.
5. Place the transparent lid over the assembled components.
6. Unwind the power cord from the cable storage area under the motor base and plug the juicer into a suitable power outlet.



Image: The underside of the juicer's motor base, illustrating the integrated cable storage for neat organization.

5. OPERATING INSTRUCTIONS

Follow these steps to extract juice from your citrus fruits:

1. Cut the citrus fruit in half.
2. Remove the transparent lid.
3. Place one half of the citrus fruit onto the juicing cone.
4. Press the fruit down firmly onto the cone. The motor will automatically start rotating.
5. Apply gentle pressure and rotate the fruit slightly to ensure maximum juice extraction. The cone will alternate rotation directions (left and right) for optimal results.
6. Once the juice is extracted, lift the fruit from the cone. The motor will stop automatically.
7. Repeat the process with remaining fruit halves.
8. The extracted juice will collect in the 1-liter container below the pulp filter.
9. Once finished, unplug the juicer from the power outlet.



Image: A top-down view of the juicer, highlighting the large juicing cone and the adjustable pulp filter mechanism.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygiene of your juicer.

1. Always unplug the juicer before cleaning.
2. Disassemble all removable parts: transparent lid, juicing cones, pulp filter, and juice container.
3. All removable parts are dishwasher safe. Alternatively, wash them by hand in warm, soapy water. Rinse thoroughly and dry completely before reassembly or storage.
4. The motor base should never be immersed in water. Wipe it clean with a damp cloth, then dry with a soft, dry cloth.
5. Do not use abrasive cleaning agents, scouring pads, or harsh chemicals, as these can damage the surfaces.

6. For stubborn pulp residue in the filter, use a small brush to gently remove it.

7. TROUBLESHOOTING

If you encounter issues with your juicer, refer to the following common problems and solutions:

- **Juicer does not start:**

- Ensure the power cord is securely plugged into a working electrical outlet.
- Verify that the juicing cone is properly seated on the shaft.
- Confirm that you are applying sufficient pressure to the fruit on the cone to activate the motor.

- **Motor runs but no juice is extracted:**

- Ensure the fruit is cut in half and placed correctly on the cone.
- Apply firm, even pressure to the fruit.

- **Excessive pulp in juice:**

- Adjust the pulp filter to a finer setting.

- **Juicer makes unusual noise:**

- Check that all parts are correctly assembled and securely in place.
- Ensure no foreign objects are obstructing the juicing mechanism.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	Princess
Model Number	01.201004.01.001
Power/Wattage	25 watts
Capacity	1 Liters
Material	Plastic
Product Dimensions	21.5 x 19 x 19 cm
Item Weight	850 g
Special Features	Adjustable Pulp Control

9. WARRANTY AND SUPPORT

This Princess 201004 Electric Citrus Juicer comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details.

For technical support, troubleshooting assistance beyond what is provided in this manual, or warranty claims, please contact Princess customer service. Contact information can typically be found on the manufacturer's official website or on the product packaging.

When contacting support, please have your product model number (201004) and proof of purchase readily available.

© 2023 Princess. All rights reserved.