

Harbor Breeze CHQ8BT7098T

Harbor Breeze CHQ8BT7098T Ceiling Fan Remote Instruction Manual

Model: CHQ8BT7098T

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Harbor Breeze CHQ8BT7098T Ceiling Fan Remote. Please read this manual thoroughly before use to ensure proper functionality and to avoid potential issues.

Important Compatibility Note: This remote is not universal. It is designed to work with specific fan receiver models. Before purchasing or attempting to use this remote, verify its compatibility with your existing ceiling fan receiver. This remote unit does not include a reverse function for the fan.

SETUP

1. Battery Installation

The remote requires one 9V battery (not included). To install the battery:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover off.
3. Insert one 9V battery, ensuring the correct polarity (+ and -).
4. Replace the battery compartment cover.

2. Dip Switch Configuration

For the remote to communicate with your ceiling fan receiver, the dip switches inside the remote must match the settings of your existing fan receiver. This is a critical step for proper operation.

1. Open the battery compartment of the new remote control.
2. Locate the series of small switches (dip switches) inside the compartment. There are typically 4 switches, offering 16 possible combinations.
3. Access your ceiling fan's receiver (usually located in the fan's canopy, above the motor housing). Note the position of the dip switches on the receiver.

4. Carefully adjust the dip switches on your new remote control to exactly match the pattern of the dip switches on your fan's receiver. For example, if the receiver's switches are UP-DOWN-UP-DOWN, set the remote's switches to UP-DOWN-UP-DOWN.
5. Once the switches match, replace the battery compartment cover on the remote.

Note: If you do not have access to the original receiver's dip switch settings, you may need to try different combinations on the remote until it pairs with the fan. Patience is required for this process.

OPERATING INSTRUCTIONS

The Harbor Breeze CHQ8BT7098T remote features a simple interface for controlling your ceiling fan and light.



Image: Front view of the Harbor Breeze CHQ8BT7098T Ceiling Fan Remote. It features an LCD screen at the top displaying a light bulb icon and fan speed bars (LOW, MED, HIGH). Below the screen are two oval-shaped buttons: the top button has a light bulb icon, and the bottom button has a fan blade icon.

- **Light Control Button:** The top oval button with the light bulb icon controls the ceiling fan's light.
 - Press once to turn the light ON or OFF.
 - Press and hold to dim or brighten the light (if your fan's light kit supports dimming).
- **Fan Speed Control Button:** The bottom oval button with the fan blade icon controls the fan's speed.

- Press repeatedly to cycle through fan speeds: OFF → LOW → MEDIUM → HIGH → OFF.
- The LCD screen will display the current fan speed (LOW, MED, HIGH) using a bar indicator.

Note: This remote does not support a reverse function for the fan blades.

MAINTENANCE

Battery Replacement

Replace the 9V battery when the remote's performance diminishes or the LCD display becomes faint. Follow the battery installation steps outlined in the "Setup" section.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners or allow moisture to enter the remote.

TROUBLESHOOTING







Problem	Possible Cause	Solution
Remote not responding / Fan not working	<ul style="list-style-type: none">• Dead or low battery.• Incorrect dip switch settings.• Remote out of range or obstructed signal.	<ul style="list-style-type: none">• Replace the 9V battery.• Verify that the remote's dip switches match the fan receiver's settings (refer to "Dip Switch Configuration" section).• Ensure you are within range and there are no obstructions between the remote and the fan.
Light does not turn off completely or dims unexpectedly	<ul style="list-style-type: none">• Incompatibility with fan's light kit.• Receiver issue.	<ul style="list-style-type: none">• Confirm compatibility of your fan's light kit with this remote's dimming function.• If issues persist after checking dip switches, consult a qualified electrician or the fan manufacturer.
Fan speed control is erratic	<ul style="list-style-type: none">• Incorrect dip switch settings.• Interference.	<ul style="list-style-type: none">• Re-check and adjust dip switch settings.• Minimize potential sources of radio frequency interference.

SPECIFICATIONS

- **Model Number:** CHQ8BT7098T
- **Brand:** Harbor Breeze
- **Manufacturer:** Rhine
- **Part Number:** RR7099T
- **Battery Requirement:** 1 x 9V battery (not included)
- **Connectivity Technology:** Infrared (IR)
- **Controller Type:** Button Control
- **Special Feature:** Ergonomic design
- **Compatibility:** Specific fan receivers (not universal)

- **Reverse Function:** Not available

Related Documents - CHQ8BT7098T

 <p>7</p>	<p>Harbor Breeze Twin Breeze II Ceiling Fan L0982-D2 Product Information</p> <p>Product details and customer service information for the Harbor Breeze Twin Breeze II Ceiling Fan, model L0982-D2. Includes fields for serial number and purchase date.</p>
 <p>1</p>	<p>Harbor Breeze Twin Breeze II Ceiling Fan Model L0982 Installation and Operation Manual</p> <p>This document provides comprehensive installation, operation, care, troubleshooting, and warranty information for the Harbor Breeze Twin Breeze II Ceiling Fan, Model L0982. It includes detailed step-by-step instructions, parts lists, and safety warnings.</p>
 <p>1</p>	<p>Harbor Breeze 52\" The Stokes Ceiling Fan Installation and Operation Manual</p> <p>This manual provides detailed instructions for the installation, operation, and maintenance of the Harbor Breeze 52\" The Stokes Ceiling Fan. It includes safety information, package contents, assembly steps, electrical connections, operating instructions, troubleshooting tips, and warranty details.</p>
 <p>1</p>	<p>Harbor Breeze Twin Breeze II Ceiling Fan Installation and Operation Manual</p> <p>Comprehensive user manual for the Harbor Breeze Twin Breeze II Ceiling Fan (Model L0982-CORB). Includes detailed instructions for installation, wiring, operation, safety precautions, troubleshooting, and warranty information.</p>
 <p>1</p>	<p>Harbor Breeze Twin Breeze II Ceiling Fan Installation and Operation Manual</p> <p>Comprehensive installation, operation, care, and troubleshooting guide for the Harbor Breeze Twin Breeze II Ceiling Fan, Model # L0982-CWH. Includes safety warnings, parts list, and warranty information.</p>
 <p>1</p>	<p>Harbor Breeze Aero Ceiling Fan Installation and Operation Manual</p> <p>This manual provides detailed instructions for the installation, operation, and maintenance of the Harbor Breeze Aero Ceiling Fan. It includes safety information, parts lists, troubleshooting tips, and warranty details.</p>

