

Samsung LH32SEJBGGAZX

Samsung LH32SEJBGGAZX Smart TV 32" HD (2018) User Manual

Model: LH32SEJBGGAZX

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Samsung LH32SEJBGGAZX 32-inch HD Smart TV. Please read these instructions thoroughly before operating the device and retain them for future reference. This television features LED display technology, HD resolution, and integrated Smart TV functionalities including Wi-Fi connectivity.



Figure 1.1: Front view of the Samsung LH32SEJBGGAZX Smart TV. The television features a slim black bezel and is shown with its included table stand.

2. SAFETY INFORMATION

Always follow these basic safety precautions to reduce the risk of fire, electric shock, and injury:

- Do not expose this apparatus to rain or moisture.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.

- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel.

3. PACKAGE CONTENTS

Verify that all items are present in your product box:

- Samsung LH32SEJBGGZX 32" HD Smart TV
- Remote Control (2 AA batteries included)
- Power Cable
- Table Stand (with screws)
- User Manual (this document)

4. SETUP

4.1 Attaching the Stand

Carefully place the TV screen-down on a soft, flat surface. Align the stand bases with the corresponding slots on the bottom of the TV. Secure the stands using the provided screws. Ensure the stand is firmly attached before placing the TV upright.

4.2 Connecting Power

Connect the power cable to the TV's power input port, then plug the other end into a wall outlet. The TV will enter standby mode.

4.3 Connecting External Devices

Your TV is equipped with various ports for connecting external devices. Refer to the images below for port locations.



Figure 4.1: Rear view of the Samsung Smart TV, displaying the power input, HDMI ports, USB ports, LAN port, and other audio/video inputs.



Figure 4.2: Detailed view of the TV's connection panel, highlighting two HDMI ports, a LAN port for wired internet, and composite video/audio inputs.

- **HDMI:** Connect Blu-ray players, game consoles, or set-top boxes to the HDMI ports. This model includes 2 HDMI ports.
- **LAN:** For a wired internet connection, connect an Ethernet cable from your router to the LAN port.
- **USB:** Connect USB storage devices to view photos, videos, or listen to music.

4.4 Initial Setup

Upon first power-on, the TV will guide you through the initial setup process. This includes selecting your language, connecting to a Wi-Fi network (or using the wired LAN connection), scanning for channels, and agreeing to terms and conditions for Smart TV features.

5. OPERATING

5.1 Remote Control Functions

The included remote control allows you to navigate the TV's features. Insert the two AA batteries into the remote control, ensuring correct polarity.



Figure 5.1: The standard remote control for the Samsung Smart TV. Key buttons include Power, Volume, Channel, Smart Hub, and directional navigation.

- **Power Button:** Turns the TV on or off.
- **Volume Up/Down:** Adjusts the sound level.
- **Channel Up/Down:** Changes TV channels.
- **Smart Hub Button:** Accesses the Smart Hub for apps and connected devices.
- **Source Button:** Selects input sources (HDMI 1, HDMI 2, TV, etc.).
- **Directional Pad (Up/Down/Left/Right) and Enter:** Navigates menus and selects options.

5.2 Smart TV Features

Press the **Smart Hub** button on your remote to access the Smart Hub. From here, you can launch pre-installed applications like Netflix and YouTube, or download additional apps from the Samsung App Store. Ensure your TV is connected to the internet for full Smart TV functionality.

6. MAINTENANCE

6.1 Cleaning the TV

To clean the screen, gently wipe it with a soft, dry microfiber cloth. For stubborn marks, lightly dampen the cloth with water or a screen-specific cleaning solution. Do not spray liquid directly onto the screen. Clean the TV's body with a soft, dry cloth. Avoid using abrasive cleaners or solvents.

6.2 Software Updates

Your Smart TV may receive software updates to improve performance and add new features. You can usually check for updates through the TV's settings menu (typically under Support > Software Update). It is recommended to keep your TV's software up to date.

7. TROUBLESHOOTING

If you encounter issues with your TV, consult the following common solutions:

- **No Power:** Ensure the power cable is securely connected to both the TV and the wall outlet. Check if the outlet is functional.
- **No Picture/Sound:** Verify that the correct input source is selected (e.g., HDMI 1). Check all cable connections to external devices.
- **No Internet Connection:** For Wi-Fi, ensure the network password is correct and the router is working. For wired LAN, check the Ethernet cable connection. Try restarting your router.
- **Remote Control Not Working:** Replace the batteries. Ensure there are no obstructions between the remote and the TV's IR sensor.
- **Picture Freezes or Apps Crash:** Try restarting the TV by unplugging it from the power outlet for a few minutes, then plugging it back in. If issues persist, a factory reset may be necessary (refer to the TV's on-screen help or Samsung support for instructions).

8. SPECIFICATIONS

Feature	Specification
Model Number	LH32SEJBGGAZX

Display Size	32 Inches
Display Technology	LED
Resolution	720p (HD)
Refresh Rate	60 Hz
Smart Features	Smart TV, Built-in Wi-Fi
Connectivity	Built-in Wi-Fi, 2 HDMI ports, LAN port
Supported Internet Services	Netflix, YouTube
Mounting Type	Table Stand
Model Year	2018
Item Weight	8000 Grams



Figure 8.1: Dimensional diagram of the Samsung 32-inch Smart TV, indicating a screen size of 32 inches and overall physical measurements.

9. WARRANTY AND SUPPORT

9.1 Product Warranty

This Samsung TV comes with a **3-year warranty against manufacturer defects**. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use.

9.2 Customer Support

For further assistance, technical support, or warranty service, please contact Samsung Customer Service. You can find contact information and additional resources on the official Samsung support website:

www.samsung.com/support

