Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nania Type L6

Nania Beline Luxe Booster Seat User Manual

Model: Type L6

Introduction

This manual provides essential information for the safe and proper use of your Nania Beline Luxe Booster Seat. Please read all instructions carefully before installation and use. Keep this manual for future reference.
The Nania Beline Luxe is a certified child car seat designed for Group 1/2/3, suitable for children weighing from 9 kg to 36 kg. It is manufactured in France by a leading European producer of child restraint systems.

Important Safety Information

WARNING: Always use this product under adult supervision.

- Ensure the vehicle is equipped with a three-point static sub-abdominal seat belt with a retractor.
- Never install the car seat with a 2-point abdominal belt.
- Always secure the child properly in the seat harness or with the vehicle's seat belt, depending on the child's weight group.
- Do not modify the car seat in any way.
- In case of an accident, even minor, the car seat should be replaced.

This product is certified by INMETRO (Certification: 006631/2015).

Setup and Installation

Unpacking

Carefully remove all components from the packaging. Verify that all parts are present:

- Nania Beline Luxe Car Seat
- Headrest
- Shoulder pads
- Back and seat reducer cushion
- Crotch protector
- Buckle protective cover

Installation for Group 1 (9 kg to 18 kg)

For children weighing between 9 kg and 18 kg, the car seat must be secured to the vehicle using the vehicle's seat belt, and the child must use the car seat's integrated 5-point safety harness.

1. Place the car seat facing forward on the vehicle's seat.
2. Route the vehicle's 3-point seat belt through the designated guides on the car seat. Ensure the belt is taut and securely fastened.
3. Adjust the car seat's 5-point harness to fit the child. The harness features a shoulder belt adjuster and 3 height adjustment positions.
4. Ensure the child is snug and secure in the harness, with no slack.



Image: Front view of the Nania Beline Luxe Car Seat, showing the adjustable headrest and 5-point harness system. This configuration is used for Group 1 children (9-18 kg).

Installation for Group 2 and 3 (15 kg to 36 kg)

For children weighing between 15 kg and 36 kg, the car seat's internal harness should not be used. The vehicle's 3-point seat belt must be used to secure both the child and the car seat simultaneously.

1. Remove the car seat's internal 5-point harness (refer to the "Maintenance" section for harness removal instructions).
2. Place the car seat facing forward on the vehicle's seat.
3. Seat the child in the car seat.
4. Route the vehicle's 3-point seat belt across the child and through the designated guides on the car seat. Ensure the

lap belt is low across the child's hips and the shoulder belt crosses the middle of the child's shoulder and chest.

5. Ensure the belt is taut and securely fastened, holding both the child and the car seat firmly in place.



Image: Side view of the Nania Beline Luxe Car Seat, illustrating the path for the vehicle's 3-point seat belt when used for Group 2 and 3 children (15-36 kg).

Operating Instructions

Adjusting the Headrest

The headrest can be adjusted to multiple height positions without needing to uninstall the car seat. This ensures optimal comfort and safety as your child grows.

1. Locate the headrest adjustment lever, typically at the top or back of the headrest.
2. Squeeze or pull the lever and simultaneously slide the headrest up or down to the desired height.
3. Release the lever to lock the headrest in position. Ensure it clicks into place.
4. The headrest should be positioned so that the shoulder straps are at or just above the child's shoulders (for Group 1) or the vehicle's shoulder belt rests correctly across the child's shoulder (for Group 2/3).

Adjusting the 5-Point Harness (Group 1 only)

The 5-point harness system includes shoulder pads, a crotch protector, and a buckle protective cover for comfort and safety.

1. **To loosen:** Press the harness release button (usually located near the crotch buckle) and pull the shoulder straps forward.
2. **To tighten:** Pull the adjustment strap located at the front of the seat until the harness is snug against the child's body. You should not be able to pinch any slack in the harness straps at the child's collarbone.
3. **To adjust height:** The shoulder straps have 3 height adjustment positions. Re-thread the straps through the slots in the seat back that are at or just above your child's shoulders.

Note: A user review mentioned a buckle jamming issue. If the buckle becomes difficult to release, ensure no fabric or debris is obstructing the mechanism. If the issue persists, contact customer support.

Maintenance and Care

Cleaning the Fabric Cover

The fabric cover, including the reducer cushion, shoulder pads, and crotch protector, is removable for cleaning. The fabric is self-extinguishing and does not propagate fire.

1. Carefully remove the fabric cover from the car seat frame.
2. Wash the cover according to the care label instructions, typically hand wash or machine wash on a gentle cycle with mild detergent. Do not bleach or tumble dry.
3. Allow the cover to air dry completely before reattaching it to the car seat.

Cleaning the Frame

Wipe the plastic frame and harness straps with a damp cloth and mild soap. Do not use abrasive cleaners or solvents.

Harness Removal (for Group 2/3 use)

When transitioning to Group 2/3 (15 kg to 36 kg), the 5-point harness must be removed.

1. Unbuckle the harness and loosen the straps completely.
2. Locate the anchor points for the shoulder straps and crotch strap at the back and bottom of the seat.
3. Carefully unthread the straps from their slots and remove the entire harness assembly.

4. Store the harness in a safe place for future use, if needed, or for potential re-sale.

Troubleshooting

Problem	Possible Cause	Solution
Harness/Buckle difficult to release or tighten.	Fabric or debris obstructing the buckle mechanism; straps twisted.	Check for obstructions and remove them. Ensure straps are not twisted. If issue persists, contact customer support.
Car seat feels loose after installation.	Vehicle seat belt not taut enough; incorrect belt path.	Re-read installation instructions carefully. Ensure vehicle belt is pulled as tight as possible. Check belt path is correct for your child's weight group.
Headrest not adjusting smoothly.	Mechanism obstructed or dirty.	Check for any obstructions. Clean the adjustment mechanism if visible dirt is present. Do not force the adjustment.

Specifications

- **Model:** Type L6
- **Brand:** Nania
- **Color:** Black
- **Material:** Plastic, Self-extinguishing fabric
- **Product Dimensions:** 45 x 54 x 63 cm (L x W x H)
- **Product Weight:** 4.85 kg
- **Recommended Weight Range:** 9 kg to 36 kg (Group 1/2/3)
- **Harness Type:** 5-point (for Group 1)
- **Harness Height Positions:** 3
- **Headrest Positions:** Multiple adjustable positions
- **Installation Type:** Vehicle 3-point seat belt
- **Orientation:** Forward-facing
- **Certification:** INMETRO 006631/2015
- **Manufacturer:** Team Tex France
- **ASIN:** B07FYZ4BR3
- **EAN:** 3507460112887, 7898965893019

Warranty and Support

For warranty information, please refer to the documentation provided with your purchase or contact the retailer. Nania products are manufactured by Team Tex France.
For technical support or inquiries, please contact Nania customer service or the authorized distributor in your region. Contact details can usually be found on the manufacturer's official website or on the product packaging.
Safety Notice: "Utilizar sob supervisão de um adulto" (Use under adult supervision).

© 2025 Nania. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07FYZ4BR3

More documents and user manuals: **https://manuals.plus/**