

[manuals.plus](#) /› [Rfiver](#) /› [Rfiver Universal Table Top TV Stand Instruction Manual for 27-60 Inch TVs, Model UT4001](#)

Rfiver UT4001

Rfiver Universal Table Top TV Stand Instruction Manual

Model: UT4001 | For 27-60 Inch LCD LED Flat Curved Screen TVs

1. INTRODUCTION

Thank you for choosing the Rfiver Universal Table Top TV Stand. This stand is designed to provide a stable and adjustable base for most 27 to 60-inch LCD, LED, Plasma, and 4K Smart TVs, including both flat and curved screens. It supports TVs weighing up to 88 lbs (40 kg) and is compatible with VESA mounting patterns up to 400x400mm. This manual provides detailed instructions for assembly, operation, and maintenance to ensure safe and optimal use of your TV stand.




Image 1.1: Front view of the Rriver Universal Table Top TV Stand.

2. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Failure to follow these instructions may result in property damage, serious injury, or death.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 88 lbs (40 kg). This stand is designed for TVs between 27 and 60 inches.
- **VESA Compatibility:** Ensure your TV's VESA mounting pattern (distance between mounting holes on the back

of the TV) is within the range of 100x100mm to 400x400mm.

- **Stability:** Always place the TV stand on a flat, level, and stable surface. Do not place heavy objects on the stand's base that could compromise stability.
- **Children and Pets:** Keep children and pets away from the stand during assembly. Ensure the TV is securely mounted to prevent tipping. The stand includes a safety lock design to prevent TV falls.
- **Tools:** Use appropriate tools as specified in the assembly instructions. Do not overtighten screws.
- **Damaged Parts:** Do not use the stand if any parts are damaged or missing. Contact customer support for replacement parts.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. The package includes:

- Main metal support column
- Tempered glass base
- TV mounting bracket (horizontal bar)
- Two vertical TV mounting arms
- Hardware kit (various screws, washers, spacers, and tools for assembly and TV attachment)
- Instruction manual

EASY INSTALLATION WITH LABELED HARDWARE




Image 3.1: Illustration of included components and labeled hardware for easy installation.

4. SETUP AND ASSEMBLY

Assembly is designed to be straightforward with labeled hardware. A Phillips screwdriver is the only additional tool required.

- 1. Attach the Support Column to the Glass Base:** Secure the main metal support column to the tempered glass base using the provided screws and tools. Ensure all connections are tight and stable.
- 2. Assemble the TV Mounting Bracket:** Attach the horizontal TV mounting bracket to the main support column. This bracket allows for height adjustment.
- 3. Attach Vertical Arms to TV:** Identify the correct screws, washers, and spacers from the hardware kit that fit your TV's VESA mounting holes. Attach the two vertical TV mounting arms to the back of your television. Ensure the arms are level and securely fastened.
- 4. Mount TV to Stand:** Carefully lift your TV and hook the vertical mounting arms onto the horizontal bracket of the stand. Ensure the TV is centered and seated correctly.
- 5. Secure TV with Safety Lock:** Engage the safety lock mechanism on the vertical arms to prevent the TV from accidentally lifting off the stand. This feature enhances stability and prevents tilting or falling.
- 6. Cable Management:** Utilize the integrated cable management clips on the support column to organize and conceal TV cables for a tidy appearance.



Image 4.1: Visual guide for the installation process, highlighting labeled hardware.



Image 4.2: Detail of the safety lock, designed to prevent TV tilting or falling.



Image 4.3: Detail of the cable management feature for organizing wires.

5. OPERATING INSTRUCTIONS

Height Adjustment

The Rfiver TV stand features 6 adjustable height settings, allowing you to customize the screen position for optimal viewing. To adjust the height:

1. **Unmount TV:** Carefully unhook the TV from the horizontal mounting bracket. It is recommended to have assistance when handling larger TVs.
2. **Adjust Bracket Position:** Loosen the screws securing the horizontal mounting bracket to the main support column. Slide the bracket up or down to your desired height. The stand offers multiple pre-drilled holes for precise adjustment.
3. **Secure Bracket:** Retighten the screws to firmly secure the horizontal bracket at the new height.
4. **Remount TV:** Carefully re-mount your TV onto the bracket and engage the safety lock.

6 LEVEL HEIGHT ADJUSTABLE



Image 5.1: Illustration of the 6-level height adjustment feature, ranging from 19.9 inches to 25.8 inches.



Image 5.2: Close-up showing the different height settings for the mounting bracket.

6. MAINTENANCE

To ensure the longevity and appearance of your Rfiver TV stand, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the metal and glass surfaces with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals that could damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Non-Slip Pads:** The base includes non-slip pads to prevent scratches and provide stability. Ensure these pads are intact and clean.



Image 6.1: Detail of the non-slip pad on the tempered glass base.

7. TROUBLESHOOTING

If you encounter issues during assembly or use, refer to the following common problems and solutions:

- **TV Wobbles After Assembly:**

Solution: Ensure all screws are securely tightened, especially those connecting the support column to the base and the mounting bracket to the column. Verify the TV is properly seated on the mounting arms and the safety lock is engaged. Ensure the stand is on a flat, stable surface.

- **Screws for TV are Too Short/Long:**

Solution: The hardware kit includes various sizes of screws (M4, M6, M8) and spacers to accommodate different TV models. Refer to your TV's manual for the correct screw size. If the provided screws are still not suitable, you may need to purchase specific screws from a hardware store.

- **TV Does Not Fit the Stand:**

Solution: Double-check your TV's size and VESA mounting pattern. This stand supports TVs from 27-60 inches and VESA patterns from 100x100mm to 400x400mm. If your TV falls outside these specifications, it is not compatible with this stand.

- **Difficulty with Height Adjustment:**

Solution: Ensure the TV is unmounted before attempting to adjust the bracket height. Loosen the screws sufficiently to allow the bracket to slide freely, then retighten firmly once the desired height is achieved.

8. SPECIFICATIONS

Feature	Detail
Brand	Rfiver
Model Number	UT4001
Compatible TV Sizes	27-60 inches

Maximum Load Capacity	88 lbs (40 kg)
VESA Compatibility	100x100mm to 400x400mm
Height Adjustment	6 levels (approx. 19.9 to 25.8 inches)
Material	Metal, Tempered Glass
Product Dimensions (L x W x H)	15.7 x 9.4 x 25.8 inches (approximate maximum height)
Item Weight	8.8 pounds
Color	Black
Mounting Type	Tabletop Mount
Movement Type	Fixed (with height adjustment)
UPC	704139207803

PRODUCT MEASUREMENT




Image 8.1: Detailed product measurements including height, width, and depth.

EASY INSTALLATION WITH LABELED HARDWARE



Image 8.2: Compatibility overview for TV size, load capacity, VESA patterns, and screen types.

9. WARRANTY AND CUSTOMER SUPPORT



For warranty information or if you have any questions, concerns, or require assistance with your Rfiver Universal Table Top TV Stand, please contact Rfiver customer support. Details for contacting support are typically found on the product packaging or the official Rfiver website.

Please retain your proof of purchase for warranty claims.

© 2025 Rfiver. All rights reserved.

Related Documents - UT4001

	<p>RFIVER TF3001U TV Stand Installation Manual</p> <p>Detailed installation guide for the RFIVER TF3001U TV Stand, including parts list, step-by-step assembly instructions, VESA compatibility chart, and safety guidelines. Learn how to safely mount your TV.</p>
	<p>Rfiver Universal Swivel Tabletop TV Stand Assembly Manual</p> <p>Assembly manual for the Rfiver Universal Swivel Tabletop TV Stand, Model UT2001. Provides step-by-step instructions and parts list for safe and proper installation.</p>
	<p>Rfiver TF2002 TV Stand Assembly Instructions and User Guide</p> <p>Comprehensive guide for assembling the Rfiver TF2002 TV stand. Includes parts list, step-by-step instructions, safety warnings, and cable management tips for your floor TV mount.</p>

	<p>RFIVER UT5002 TV Stand Assembly Instructions and User Guide</p> <p>This document provides assembly instructions, parts list, and safety notices for the RFIVER UT5002 TV Stand. Learn how to safely assemble and install your TV stand for optimal viewing.</p>
	<p>RFIVER TF3001U TV Stand Installation Manual</p> <p>Detailed installation guide for the RFIVER TF3001U TV Stand, including parts list, step-by-step assembly instructions, VESA compatibility chart, and safety guidelines. Learn how to safely mount your TV.</p>
	<p>Rfiver Universal Swivel Tabletop TV Stand Assembly Manual</p> <p>Assembly manual for the Rfiver Universal Swivel Tabletop TV Stand, Model UT2001. Provides step-by-step instructions and parts list for safe and proper installation.</p>