Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CalExotics 62008

CalExotics Impulse Intimate Dual Vibrating Wand (Model 62008) Instruction Manual

Introduction

This manual provides detailed instructions for the safe and effective use of your CalExotics Impulse Intimate Dual Vibrating Wand, Model 62008. Please read this manual thoroughly before first use and retain it for future reference. The CalExotics Impulse Intimate Dual Vibrating Wand is designed to enhance pleasure through powerful vibrations and e-stimulation.

Safety Information

- This device is intended for adult use as a non-medical pleasure device only. It is not intended for medical use.
- Discontinue use immediately if you experience any discomfort, pain, or irritation. Consult a healthcare professional if symptoms persist.
- Clean the device thoroughly before and after each use with warm water and a toy cleaner or mild soap.
- Use only water-based lubricants with this device. Silicone-based lubricants may damage the silicone material.
- Keep out of reach of children.
- Do not use in water while e-stimulation is activated.

Package Contents

- CalExotics Impulse Intimate Dual Vibrating Wand
- USB Charging Cable
- Instruction Manual



Image: CalExotics Impulse Intimate Dual Vibrating Wand and its retail packaging.

Product Features

- Powerful dual stimulator with 7 independent functions of vibration, pulsation, and escalation.
- Strategically placed pleasure pads with 5 independent levels of e-stimulation.
- Luxurious silicone with a flexible shaft that moves with you.
- Easy push-button controls with instant off feature and security travel lock.
- USB rechargeable – charging cord included.



Image: Angled view of the device highlighting its ergonomic design and control buttons.

Setup and Charging

Initial Charge

Before first use, fully charge your CalExotics Impulse Intimate Dual Vibrating Wand. Connect the included USB charging cable to the charging port on the device and plug the other end into a USB power source (e.g., computer, USB wall adapter). The LED light will flash while charging and glow solid when fully charged. A complete charge takes approximately 3 hours.



Image: The device connected to its USB charging cable, illustrating the charging process.

Charging Demonstration Video

Your browser does not support the video tag.

Video: Official CalExotics video demonstrating the Impulse Intimate Dual Wand's power on/off, vibration activation, e-stimulation activation, and charging process.

Operating Instructions

Power On/Off

- To turn on: Press and hold the power button for 3 seconds. The LED light will illuminate.
- To turn off completely: Press and hold the power button for 3 seconds.
- Instant off: Press the power button once to turn off all vibrations and e-stimulation instantly.

Activating Vibrations

- With the device powered on, press and hold the middle button for 3 seconds to activate vibrations.
- Continue to press the middle button to cycle through the 7 functions of vibration.
- To deactivate vibrations individually: Press and hold the middle button for 3 seconds.

Activating E-Stimulation

- With the device powered on, press and hold the top button for 3 seconds to activate e-stimulation.
- Continue to press the top button to cycle through the 5 functions of e-stimulation.
- To deactivate e-stimulation individually: Press and hold the top button for 3 seconds.

Operation Demonstration Video

Your browser does not support the video tag.

Video: Official CalExotics video demonstrating the Impulse Intimate Dual Wand's power on/off, vibration activation, e-stimulation activation, and charging process.

Maintenance and Care

Cleaning

Clean your device thoroughly before and after each use. Wash with warm water and a toy cleaner or mild soap. Rinse thoroughly and pat dry with a lint-free cloth. Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone.

Storage

Store the device in a clean, dry place away from direct sunlight and extreme temperatures. Keep it separate from other toys made of different materials to prevent potential damage or reactions.

Troubleshooting

Device not turning on:
Ensure the device is fully charged. Press and hold the power button for 3 seconds to activate.

Vibrations are weak or inconsistent:
The battery may be low. Recharge the device. Ensure the device is clean and free from debris.

E-stimulation not felt or too intense:
Ensure proper contact with the skin. Adjust the e-stimulation level by pressing the top button. Ensure sufficient water-based lubricant is used. Discontinue use if discomfort persists.

Specifications

Item Model Number	62008
Product Dimensions	10.24 x 2.36 x 5.51 inches; 1.26 Pounds
Batteries	1 Lithium Polymer battery required (included)

Material	Silicone, Nickel-Free Alloy
Color	Purple
Manufacturer	CalExotics
Charge Time	Approximately 3 hours
Run Time (High Speed)	Approximately 90 minutes
Run Time (Low Speed)	Approximately 150 minutes




Image: Diagram illustrating the dimensions of the CalExotics Impulse Intimate Dual Vibrating Wand.

Warranty and Support

The CalExotics Impulse Intimate Dual Vibrating Wand comes with a **one-year manufacturer warranty**. For warranty claims or product support, please contact CalExotics directly through their official website or customer service channels. Retain your proof of purchase for warranty validation.

Image: CalExotics brand logo.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07G218FSK

More documents and user manuals: **https://manuals.plus/**