Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 2018080104

YING RAY Replacement Remote Control Instruction Manual

For Soleus Air GREE Air Conditioner Models P-KY80-36, KY-80, SG-PAC-08E3

Introduction

This document provides comprehensive instructions for the YING RAY replacement remote control, designed for specific Soleus Air GREE air conditioner models. This remote control operates with a Fahrenheit temperature display. Please read this manual thoroughly before use to ensure proper operation and to maximize the lifespan of your device.

Product Overview

The YING RAY replacement remote control is a dedicated device for controlling compatible Soleus Air GREE air conditioning units. It is specifically designed to replace original remote controls for models P-KY80-36, KY-80, and SG-PAC-08E3. This remote is not a universal remote control; its functionality is limited to the specified air conditioner models.



Image 1: Front view of the YING RAY replacement remote control. The display shows '74°F OPER AUTO' and buttons for ON/OFF, MODE, temperature adjustment, FAN, SWING, SLEEP, and TIMER are visible.

Setup

Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA 1.5V ordinary batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.

Note: This remote control does not require programming. It is designed to work directly with compatible air conditioner models once batteries are installed.

Operating Instructions

Point the remote control directly towards the air conditioner unit's receiver when operating.

Button Functions:

- **ON/OFF:** Press to turn the air conditioner unit on or off.
- **MODE:** Cycles through available operating modes: AUTO, COOL, DRY, FAN, HEAT. The current mode is displayed on the remote's screen.
- **Temperature Adjustment (+/-):** Use the '+' button to increase the temperature setting and the '-' button to decrease it. The temperature is displayed in Fahrenheit.
- **FAN:** Adjusts the fan speed. Options typically include AUTO, LOW, MEDIUM, HIGH.
- **SWING:** Activates or deactivates the automatic louver swing function, directing airflow.
- **SLEEP:** Engages the sleep mode, which adjusts temperature and fan speed for comfortable sleep and energy saving.
- **TIMER:** Sets the timer for automatic turn-on (T-ON) or turn-off (T-OFF) of the air conditioner. Follow the on-screen prompts to set the desired time.

Display Information:

The remote's LCD screen displays the current temperature setting in Fahrenheit, the operating mode (e.g., AUTO, COOL), fan speed, and any active timer settings (T-ON, T-OFF).

Maintenance

Battery Replacement

Replace batteries when the remote's display becomes dim or the remote fails to operate the air conditioner unit. Always replace both batteries simultaneously with new AAA 1.5V batteries. Do not mix old and new batteries or different types of batteries.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.

Troubleshooting

- **Remote not responding:**
  - Ensure the remote is pointed directly at the air conditioner's receiver.
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - If the remote still does not work, check the battery spring contact. Sometimes, the battery's positive pole may not make proper contact with the spring. Gently pull the battery spring out a little to ensure better contact.
- **Limited range:**
  - Ensure there are no obstructions between the remote and the air conditioner unit.
  - Replace batteries if they are low.

Specifications

- **Brand:** YING RAY

- **Model Name:** 2018080104
- **Compatible Devices:** Soleus Air GREE Air Conditioner Models P-KY80-36, KY-80, SG-PAC-08E3
- **Connectivity Technology:** Infrared
- **Battery Type:** 2 x AAA 1.5V (not included)
- **Maximum Range:** 10 Meters (approximately 33 feet)
- **Display:** Fahrenheit
- **Special Feature:** Ergonomic design
- **Button Quantity:** 12
- **Item Weight:** 0.05 Kilograms

Warranty and Support

For information regarding warranty coverage or technical support, please refer to the seller's policies or contact the seller directly through the platform where the product was purchased. Keep your purchase receipt for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07G39D9GJ

More documents and user manuals: **https://manuals.plus/**