

## Walker 21823

# Walker Quiet-Flow 21823 Direct Fit Exhaust Muffler

## Instruction Manual

### 1. INTRODUCTION

This manual provides essential information for the proper installation and maintenance of your Walker Quiet-Flow 21823 Direct Fit Exhaust Muffler. Designed for specific Mitsubishi Outlander models, this muffler offers a direct-fit replacement solution. Adhering to these instructions will help ensure optimal performance and longevity of the product.



Figure 1: Walker Quiet-Flow 21823 Direct Fit Exhaust Muffler. This image displays the complete muffler assembly, highlighting its shape and connection points.

### 2. COMPATIBILITY

The Walker Quiet-Flow 21823 Direct Fit Exhaust Muffler is compatible with the following vehicle models:

- 2008-2013 Mitsubishi Outlander

Before installation, verify that this part is suitable for your specific vehicle by checking the year, make, model, engine, and trim information. Consult your vehicle's service manual or a qualified automotive professional if you are unsure about compatibility.

### 3. PRODUCT FEATURES

The Walker Quiet-Flow 21823 muffler incorporates several design elements for performance and durability:

- **Corrosion Resistance:** An internal drainage system is integrated to reduce moisture accumulation, which helps inhibit rust formation and extends the muffler's lifespan.




Figure 2: Illustration of the muffler's internal drainage system, designed to resist corrosion by reducing moisture collection.

- **Premium Acoustic Control:** Features OE-style louvered tubes that effectively lower noise levels. OE-style domed heads further contribute to reducing radiated noise, providing a factory-style sound quality.

# PREMIUM ACOUSTIC CONTROL

OE-style louvered tubes lower noise levels while OE-style domed heads helps for premium factory-style sound




Figure 3: Cutaway view of the muffler, illustrating the internal louvered tubes and domed heads engineered for optimal sound dampening.

- **Durable Construction:** Internal partitions and mechanically joined tubes allow for expansion and contraction during temperature fluctuations, minimizing distortion. Spun-locked heads and OE-style spot welds enhance structural stability and contribute to a longer service life.

# BUILT TO LAST

Spun-locked heads and OE-style spot welds help provide structural stability



Figure 4: Detail of the muffler's exterior, highlighting the spun-locked heads and OE-style spot welds that ensure structural integrity.

- **Design Validation:** The muffler has undergone acoustic and flow testing to ensure it meets quality OE-style sound standards.

## 4. INSTALLATION GUIDELINES

---

The Walker Quiet-Flow 21823 is designed as a direct-fit bolt-on replacement. It features OE-style hangers, brackets, and pipe routings to facilitate installation without requiring specialized fabrication or welding.



# EASY TO INSTALL

Direct-fit bolt-on replacement solution with OE-style hangers, pipe routings, and flanges for easy installation that doesn't require specialized fabrication and/or welding



Figure 5: The muffler assembly, illustrating the bolt-on flange and hangers designed for straightforward installation.




Figure 6: A comprehensive diagram of a typical automotive exhaust system, showing the placement of components including manifold converters, oxygen sensor ports, catalytic converters, resonator assemblies, and muffler assemblies.

### General Installation Steps:

1. **Safety First:** Ensure the vehicle is securely lifted and supported. Wear appropriate personal protective equipment, including eye protection and gloves.
2. **Remove Old Muffler:** Carefully detach the existing muffler from the exhaust system. This may involve cutting or unbolting connections and releasing hangers.



Figure 7: An image showing a rusted muffler under a vehicle, indicating a common reason for replacement.

3. **Prepare Connections:** Clean any mating surfaces and apply exhaust sealant if recommended.
4. **Position New Muffler:** Align the new Walker muffler with the existing exhaust pipes and hangers.



Figure 8: A close-up image of a hand installing an exhaust component, demonstrating the precision required during assembly.

5. **Secure Connections:** Use appropriate clamps or bolts to secure the muffler. Ensure all connections are tight to prevent exhaust leaks.



Figure 9: An assortment of exhaust clamps, illustrating the types of fasteners used to secure exhaust system components.

6. **Final Check:** Lower the vehicle and start the engine to check for any exhaust leaks or unusual noises.

For detailed, vehicle-specific installation instructions, refer to your vehicle's service manual or consult a certified mechanic.

## 5. MAINTENANCE

---

The Walker Quiet-Flow 21823 muffler is designed for durability and minimal maintenance. However, regular inspection of your entire exhaust system is recommended to ensure optimal performance and detect potential issues early.

- **Periodic Inspection:** Visually inspect the muffler and exhaust pipes for signs of rust, cracks, loose connections, or damage during routine vehicle maintenance.
- **Check Hangers and Mounts:** Ensure all hangers and mounting points are secure and free from excessive wear. Loose hangers can lead to rattling or premature component failure.
- **Address Leaks Promptly:** Any exhaust leaks should be addressed immediately by a qualified technician to prevent harmful fumes from entering the vehicle cabin and to maintain engine efficiency.

## 6. TROUBLESHOOTING

---

If you experience issues with your exhaust system after installing the Walker Quiet-Flow 21823 muffler, consider the following common troubleshooting points:

- **Excessive Noise or Rattling:** Check all connections for tightness. Ensure hangers are properly seated

and not damaged. Verify that the muffler is not contacting other vehicle components.

- **Exhaust Leaks:** Listen for hissing sounds, especially when the engine is cold. Visually inspect all joints and welds for signs of escaping exhaust gases. Leaks can often be identified by soot marks around the affected area.
- **Vibrations:** Ensure the exhaust system is properly aligned and not under tension. Check for loose or damaged hangers that could transmit vibrations to the vehicle chassis.

For persistent issues or complex problems, it is recommended to consult a professional automotive technician.

## 7. SPECIFICATIONS

| Attribute                      | Detail  |
|--------------------------------|---|
| Brand                          | Walker  |
| Model Number                   | 21823   |
| Material                       | Stainless Steel                               |
| Product Dimensions (L x W x H) | 71.12 x 43.18 x 22.86 cm (28 x 17 x 9 inches) |
| Item Weight                    | 8.01 kg (17.66 lbs)                           |
| Inlet Connection Size          | 2.75 Inches                                   |
| Shape                          | Oval  |
| Exterior Finish                | Machined                                      |
| UPC                            | 086387218238                                  |


## 8. WARRANTY AND SUPPORT

The Walker Quiet-Flow 21823 Exhaust Muffler comes with Walker's limited lifetime warranty. Additionally, it is backed by an exclusive 90-Day Safe and Sound Guarantee.

For detailed information regarding warranty terms, conditions, and to access customer support, please visit the official Walker Exhaust website or contact their customer service department.


**Note:** Warranty coverage typically requires proper installation and adherence to maintenance guidelines. Keep your purchase receipt as proof of purchase.






### [Walker Commercial Vehicle 2014-2015 Master Catalog](#)

Comprehensive catalog from Walker featuring exhaust system components for commercial vehicles, including mufflers, flex pipes, and accessories. Covers heavy-duty, medium-duty trucks, buses, and agricultural applications with model identification and technical specifications.



### [Walker A16 Boom Sprayer Operator's Manual: Safety, Assembly, Operation, Maintenance](#)

Comprehensive operator's manual for the Walker A16 Boom Sprayer, covering safety instructions, assembly procedures, operating guidelines, maintenance tips, troubleshooting, and parts lists. Compatible with various Walker mower decks.




### [Walker Rider Lawnmower Owner's Manual MS36-42 MC36-54](#)

Owner's manual for Walker Rider Lawnmower models MS36-42 (11-HP) and MC36-54 (16-HP), detailing assembly, safety, operation, and maintenance. Includes specifications and troubleshooting.



### [Walker C19 Illustrated Parts Manual](#)

Detailed illustrated parts manual for the Walker C19 riding mower, providing comprehensive lists and diagrams for all components, including chassis, engine, drive systems, and accessories. Essential for maintenance and repair.



### [Walker Illustrated Parts Manual for DM36, DM42, DM42A, DM42B, DM48 Mulching Decks and Carrier Frames](#)

This illustrated parts manual provides detailed information for Walker DM36, DM42, DM42A, DM42B, and DM48 mulching decks and carrier frame assemblies. It includes part numbers, descriptions, diagrams, and assembly instructions to help identify and order replacement components for Walker lawn mowers.



### [Walker T23 Illustrated Parts Manual](#)

Comprehensive illustrated parts manual for the Walker T23 commercial rider mower. Includes detailed diagrams, part numbers, and assembly information for maintenance and repair of all major components, including the Rehlko/Kohler engine.