

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [GOLDEN HOUR](#) /
- › [GOLDEN HOUR Analog Digital Watch User Manual \(Model: TM-GH-108\)](#)

GOLDEN HOUR TM-GH-108

GOLDEN HOUR Analog Digital Watch User Manual (Model: TM-GH-108)

Comprehensive user manual for the GOLDEN HOUR Analog Digital Watch (Model TM-GH-108), covering setup, operation, maintenance, and troubleshooting.

INTRODUCTION

Thank you for choosing the GOLDEN HOUR Analog Digital Watch. This timepiece combines classic analog display with modern digital functionalities, designed for durability and precision. This manual provides detailed instructions to help you set up, operate, and maintain your watch.

SAFETY INFORMATION

- Avoid exposing the watch to extreme temperatures or strong magnetic fields.
- Do not attempt to open the watch case or replace the battery yourself, as this may void the warranty and damage the watch.
- Keep the watch away from harsh chemicals, solvents, and detergents.
- While water resistant, avoid prolonged submersion or hot water exposure (e.g., showering, hot tubs) to prevent damage to seals.

PACKAGE CONTENTS

- GOLDEN HOUR Analog Digital Watch (Model: TM-GH-108)
- Gift Box
- Small Tool for band adjustment
- User Manual (this document)

WATCH OVERVIEW

Familiarize yourself with the various components of your GOLDEN HOUR watch.



Figure 1: Front view of the GOLDEN HOUR Analog Digital Watch (3-tone Silver/Gold/White variant).



Figure 2: Close-up of the watch face, highlighting the analog hands, digital display, and function indicators.



Figure 3: Rear view of the watch, displaying the stainless steel case back and engraved details.

Components:

- **Analog Display:** Traditional hour, minute, and second hands.
- **Digital Display:** Shows time, date, day, alarm, and stopwatch functions.
- **Crown:** Used for setting analog time.
- **Push Buttons:** Control digital functions (Light, Mode, Start, Reset).
- **Stainless Steel Band:** Durable and adjustable.

SETUP

1. Setting Analog Time:

1. Pull the crown (middle button on the right side) out to the first position.
2. Rotate the crown to adjust the hour and minute hands to the desired time.
3. Push the crown back in to its original position to start the analog time.

2. Setting Digital Time and Date:

1. Press the **MODE** button repeatedly until the digital display shows the time setting mode (usually indicated by flashing digits).
2. Use the **START** button to select the digit or setting you wish to adjust (e.g., hours, minutes, 12/24H format, month, date, day).
3. Use the **RESET** button to change the value of the selected digit or setting.
4. Once all settings are correct, press the **MODE** button to exit the setting mode.

3. Band Adjustment:

The watch comes with a small tool for adjusting the stainless steel band. To adjust the band length:

1. Identify the pins on the side of the band links.
2. Use the provided tool to push out the pins in the direction of the arrows (usually found on the inside of the band).
3. Remove the desired number of links.
4. Reassemble the band by inserting the pins back into place. Ensure they are securely fastened.



Figure 4: Product parameters and band adjustment diagram.

OPERATING FUNCTIONS

- **Backlight:** Press the **LIGHT** button (top left) to illuminate the digital display and analog hands for a few seconds.



Figure 5: Watch display with the backlight activated, showing illuminated digital time and analog hands.

- **Alarm:** In timekeeping mode, press **MODE** until "ALARM" appears. Use **START** and **RESET** to set the alarm time. Press **MODE** to activate/deactivate the alarm.
- **Stopwatch:** In timekeeping mode, press **MODE** until "CHRONO" or "STW" appears. Press **START** to begin, **START** again to pause, and **RESET** to clear.
- **Dual Time:** The watch supports dual time display. Refer to the digital time setting instructions to adjust the second time zone if available.
- **Day and Date Display:** The digital display automatically shows the current day and date once set.

MAINTENANCE

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and dry immediately.
- **Water Resistance:** This watch is water resistant to 30 meters (3 ATM). It is suitable for daily use, such as splashes or brief immersion in water. It is **not** suitable for showering, swimming, diving, or prolonged water activities. Avoid operating buttons underwater.
- **Battery Replacement:** When the watch stops or the digital display fades, the battery may need replacement. It is

recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and water resistance. The watch requires one nonstandard battery.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Analog hands not moving	Crown is pulled out; battery depleted.	Push crown back in. If issue persists, replace battery.
Digital display is blank or dim	Battery depleted.	Replace battery.
Incorrect time/date	Time/date not set correctly.	Follow "Setting Digital Time and Date" instructions.
Water inside watch	Exceeded water resistance limits; crown/buttons operated underwater.	Immediately take to a qualified watch technician for inspection and repair.

SPECIFICATIONS

- **Brand:** GOLDEN HOUR
- **Model Number:** TM-GH-108-S-G-W
- **Movement:** Imported Japanese Quartz Movement
- **Case Material:** Alloy
- **Bottom Cover Material:** 304 Steel
- **Case Diameter:** 45.95 mm
- **Case Thickness:** 16.34 mm
- **Band Material:** Stainless Steel
- **Band Width:** 20 mm
- **Band Length:** 170-215 mm (adjustable)
- **Net Weight:** 185g
- **Water Resistance:** 30M / 99 feet / 3 ATM (Splash resistant, not for submersion)
- **Functions:** Alarm, Stopwatch, Backlight, Date, Day, 12/24H Display, Dual Time
- **Battery:** 1 Nonstandard Battery required

WARRANTY AND SUPPORT

Your GOLDEN HOUR watch is covered by a **1-year after-sales service** against any manufacturing defects. Additionally, a 15-day charge back and replacement within 30 days are offered.

For further assistance, troubleshooting, or warranty claims, please contact GOLDEN HOUR customer service through the retailer where the product was purchased or visit the official GOLDEN HOUR store on Amazon: [GOLDEN HOUR Store](#).

PRODUCT VIDEO

Watch this official product video for a visual guide on the GOLDEN HOUR Analog Digital Watch features and design.

Your browser does not support the video tag.

Video: Overview of the GOLDEN HOUR Stainless Steel Digital Analog Men's Watch, showcasing its design and functionalities.



© 2025 GOLDEN HOUR. All rights reserved.