



Manuals.plus /

› Digipartspower /

› Digipartspower AC Adapter Charger for Kentiger HY-603 Stereo Amplifier Player Power Supply User Manual

Digipartspower B07G57TJBQ

Digipartspower AC Adapter Charger for Kentiger HY-603 Stereo Amplifier Player Power Supply User Manual

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Digipartspower AC Adapter Charger, designed specifically for the Kentiger HY-603 Stereo Amplifier Player. Please read this manual thoroughly before use and retain it for future reference.

The AC adapter is engineered to deliver stable and reliable power, featuring multiple protection mechanisms including over current, over voltage, over temperature, and short circuit protection to ensure the safety of your device.

SAFETY INFORMATION

- Ensure the power outlet voltage matches the adapter's input voltage (120 Volts AC).
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to open or repair the adapter. Refer all servicing to qualified personnel.
- Keep the adapter away from children and pets.
- Disconnect the adapter from the power outlet when not in use for extended periods.
- Use only with compatible devices, such as the Kentiger HY-603 Stereo Amplifier Player.

SETUP

Follow these steps to properly set up your AC adapter:

1. **Unpack the Adapter:** Carefully remove the AC adapter from its packaging.
2. **Inspect for Damage:** Before use, visually inspect the adapter and its cable for any signs of damage. Do not use if damaged.

3. **Connect to Device:** Locate the power input port on your Kentiger HY-603 Stereo Amplifier Player. Insert the round connector of the AC adapter firmly into this port.
4. **Connect to Power Outlet:** Plug the AC adapter's power cord into a standard 120V AC wall outlet. Ensure the connection is secure.
5. **Verify Power:** Once connected, your Kentiger HY-603 Stereo Amplifier Player should receive power. Refer to your amplifier's manual for power indicator details.



Image 1: Top-down view of the Digipartspower AC Adapter Charger with its cable. This image shows the compact black rectangular body of the adapter and the attached power cord, neatly coiled.

OPERATING INSTRUCTIONS

The Digipartspower AC Adapter Charger is designed for straightforward operation. Once properly connected, it continuously supplies power to your Kentiger HY-603 Stereo Amplifier Player.

- Ensure all connections are secure before powering on your amplifier.
- The adapter operates automatically to provide the necessary power. No user adjustments are required.
- If your amplifier has a power switch, use it to turn the device on or off.



Image 2: Angled view of the Digipartspower AC Adapter Charger, highlighting the power brick and the attached cable with its round connector.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your AC adapter.

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Cable Care:** Regularly check the power cable for kinks, cuts, or fraying. If any damage is observed, discontinue use immediately.



Image 3: Side view of the Digipartspower AC Adapter Charger, providing a clear look at the power brick and where the cable exits the unit.

TROUBLESHOOTING

If you encounter issues with your AC adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power to device	Adapter not plugged in; loose connection; faulty outlet; damaged adapter.	Ensure adapter is securely plugged into both the device and the wall outlet. Test the outlet with another device. Inspect adapter and cable for damage.
Device powers on intermittently	Loose connection; adapter overheating; incompatible device.	Check all connections. Ensure adapter is in a well-ventilated area. Confirm device compatibility.
Adapter feels hot	Normal operation (slight warmth); excessive load; poor ventilation.	A slight warmth is normal. If excessively hot, disconnect immediately. Ensure adequate ventilation around the adapter. Verify device power requirements do not exceed adapter capacity.

If the problem persists after attempting these solutions, contact customer support.

SPECIFICATIONS

- **Brand:** Digipartspower
- **Model:** B07G57TJBQ
- **Input Voltage:** 120 Volts (AC)
- **Connector Type:** Round
- **Compatible Devices:** Speakers (specifically Kentiger HY-603 Stereo Amplifier Player)
- **Special Feature:** Travel
- **Color:** Black
- **Power Source:** Corded Electric
- **Item Weight:** 3 Ounces
- **Certifications:** CE, FCC, RoHS
- **UPC:** 658776083545

WARRANTY INFORMATION

This Digipartspower AC Adapter Charger comes with a **3-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use.

For warranty claims or further details, please retain your proof of purchase and contact Digipartspower customer support. The return policy allows for refund/replacement within 30 days of purchase, subject to seller terms.

CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to make a warranty claim, please contact Digipartspower customer support through their official channels. You can often find support contact information on the product packaging or the seller's page on the platform where the product was purchased.

For more information about Digipartspower products, visit the official Digipartspower Store.

