

[Manuals.plus](#) /

› [Walker Edison](#) /

› Walker Edison Durango Distressed Solid Wood Dining Table, 72 Inch, Mahogany - Instruction Manual

Walker Edison AZW72DSWMA

Walker Edison Durango Distressed Solid Wood Dining Table

Model: AZW72DSWMA | 72 Inch Mahogany

INTRODUCTION

This manual provides essential instructions for the assembly, operation, maintenance, and care of your Walker Edison Durango Distressed Solid Wood Dining Table. Please read all instructions carefully before beginning assembly and retain this manual for future reference. This dining table is designed for indoor use and comfortably seats 6-8 people.

SAFETY INFORMATION

- Always assemble the table on a soft, clean surface to prevent scratches to the finish.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten hardware as needed.
- Do not exceed the maximum weight recommendation of 200 pounds on the tabletop.
- Keep small parts and packaging materials away from children.
- California Residents: This product may expose you to chemicals known to the State of California to cause cancer or birth defects or other reproductive harm. For more information, visit www.P65Warnings.ca.gov.

PARTS LIST

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Table Top (1)
- Legs (2)
- Hardware Pack (1) - *Includes screws, washers, and any necessary tools for assembly.*

SETUP AND ASSEMBLY

Recommended Tools: Phillips head screwdriver (not included).

Recommended Number of People for Assembly: 2

1. Unpack all components and lay them out on a soft, clean surface to prevent damage.
2. Attach the legs to the underside of the tabletop. Align the pre-drilled holes on the legs with those on the tabletop.

3. Insert the provided screws through the leg brackets and into the tabletop. Hand-tighten all screws initially.
4. Once all screws are in place, fully tighten them using a Phillips head screwdriver. Do not overtighten.
5. Carefully turn the assembled table upright. Ensure it is stable before use.



Figure 1: Fully assembled Walker Edison Durango Dining Table.



Figure 2: Key dimensions of the dining table, including length, width, and height.

USAGE GUIDELINES

Your dining table is designed for everyday use in your home. It provides a stable surface for meals, work, or other activities.

- The table is designed to comfortably seat 6 to 8 individuals.
- Avoid placing excessively hot items directly on the tabletop. Use coasters or placemats to protect the surface.
- Do not stand or sit on the table.
- Distribute weight evenly across the tabletop to maintain stability.



Figure 3: The dining table integrated into a home environment.

MAINTENANCE AND CARE

Proper care will help maintain the appearance and longevity of your dining table.

- **Cleaning:** Wipe the table surface with a dry cloth. For spills, use a slightly damp cloth and immediately dry the area. Avoid harsh chemicals or abrasive cleaners.

- **Protection:** Use placemats, coasters, and table runners to protect the surface from scratches, heat, and moisture.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.
- **Humidity:** Maintain a consistent humidity level in your home to prevent wood from cracking or warping.
- **Distressed Finish:** The distressed finish is intentional and contributes to the table's aesthetic. Minor imperfections are part of this design.

QUESTIONS?

We can help you.



1-801-433-3008
or email **service@walkeredison.com**

Replacement parts now available.
Please contact Walker Edison within 30 days of delivery.

Figure 4: Detail of the distressed solid wood tabletop, showcasing its unique texture and finish.

TROUBLESHOOTING

- **Wobbling Table:** If the table wobbles, check that all assembly screws are securely tightened. Ensure the table is on a level surface. Adjust glides on the bottom of the legs if present.
- **Scratches on Finish:** Minor scratches can sometimes be touched up with a wood repair marker matching the mahogany finish. For deeper scratches, professional repair may be necessary. Prevent scratches by using protective pads under items.
- **Loose Veneer:** If any veneer becomes loose, it can often be re-glued using wood adhesive and clamping the area until dry.

SPECIFICATIONS

Feature	Detail
Brand	Walker Edison
Model Name	Andre
Model Number	AZW72DSWMA
Product Dimensions (D x W x H)	36"D x 72"W x 29.88"H
Item Weight	62 Pounds
Maximum Weight Recommendation	200 Pounds
Color	Mahogany
Top Material Type	Pine, Solid Wood
Frame Material Type	Wood
Base Material	Iron
Seating Capacity	6-8 people
Product Care Instructions	Wipe with Dry Cloth

WARRANTY INFORMATION

This Walker Edison product comes with a**30-day limited manufacturer warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific details regarding coverage and limitations, please contact Walker Edison customer support.

SUPPORT AND CONTACT INFORMATION

For any questions, missing parts, or support needs, please contact Walker Edison customer service:

Phone: 1-801-433-3008

Email: service@walkerredison.com

Replacement parts are available. Please contact Walker Edison within 30 days of delivery for assistance.



Figure 5: Walker Edison customer support contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07G62YLV5>

More documents and user manuals: <https://manuals.plus/>