

## Ultimate Ears 989-000433

# Ultimate Ears Power Up Wireless Charging Dock User Manual

Model: 989-000433

## 1. INTRODUCTION

The Ultimate Ears Power Up Wireless Charging Dock provides a convenient and efficient way to charge your compatible Ultimate Ears portable speakers. Designed for seamless integration, this dock ensures your speaker is always ready for use without the need for direct cable connections to the speaker itself. Simply place your speaker on the dock to initiate charging.

## 2. PACKAGE CONTENTS

- Ultimate Ears Power Up Wireless Charging Dock

*Note: A USB power adapter and charging cable are required and sold separately.*

## 3. COMPATIBILITY

The Ultimate Ears Power Up Wireless Charging Dock is compatible with the following Ultimate Ears speaker models:

- Ultimate Ears BOOM 3
- Ultimate Ears MEGABOOM 3
- Ultimate Ears BLAST
- Ultimate Ears MEGABLAST

## 4. SETUP

1. **Connect Power:** Connect a USB charging cable (not included) to the micro-USB port on the back of the Power Up charging dock. Plug the other end of the cable into a compatible USB power adapter (not included) and then into a wall outlet.
2. **Placement:** Place the Power Up charging dock on a stable, flat surface.

3. **Initial Charge:** Place your compatible Ultimate Ears speaker onto the charging dock. Ensure the speaker is properly seated on the dock's contact points. The speaker should indicate that it is charging (refer to your speaker's manual for specific charging indicators).



Figure 4.1: Front view of the Power Up charging dock with its micro-USB port.






Figure 4.2: An Ultimate Ears speaker placed on the Power Up charging dock.

## 5. OPERATING INSTRUCTIONS

Using the Power Up charging dock is straightforward:

1. **Place Speaker:** Gently place your compatible Ultimate Ears speaker onto the Power Up charging dock, aligning the speaker's charging ring with the dock's contact pins.
2. **Confirm Charging:** The speaker will begin charging automatically. You can continue to use your speaker to play audio while it is docked and charging.
3. **Remove Speaker:** To stop charging or use your speaker portably, simply lift it off the dock.





Figure 5.1: A red Ultimate Ears speaker charging on the dock in a social setting.

## 6. MAINTENANCE

To ensure the longevity and optimal performance of your Power Up charging dock, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the charging dock. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or internal components.
- **Contact Pins:** Periodically inspect the charging contact pins on the dock for any debris or corrosion. Clean gently with a dry cotton swab if necessary.
- **Storage:** When not in use for extended periods, store the charging dock in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Liquids:** Do not expose the charging dock to water or other liquids. If it comes into contact with liquid, disconnect power immediately and allow it to dry completely before reuse.

## 7. TROUBLESHOOTING

If you encounter issues with your Power Up charging dock, refer to the following common solutions:

Problem	Possible Cause	Solution
Speaker is not charging when placed on the dock.	No power to the dock; improper speaker placement; dirty contact pins.	Ensure the USB cable and power adapter are securely connected and receiving power. Re-position the speaker to ensure proper contact with the dock's pins. Clean the contact pins on both the dock and the speaker.

Problem	Possible Cause	Solution
Dock appears to have no power (no indicator lights, if applicable).	Power cable disconnected; faulty power adapter or cable; power outlet issue.	Check all cable connections. Try a different USB power adapter and cable. Test the power outlet with another device.

If the issue persists after attempting these solutions, please contact Ultimate Ears customer support.

## 8. SPECIFICATIONS

Feature	Detail
Product Dimensions	3 x 3 x 0.55 inches
Item Weight	4 ounces
Brand	Ultimate Ears
Model Number	989-000433
Connector Type	Wireless
Compatible Devices	Ultimate Ears BOOM 3, MEGABOOM 3, BLAST, MEGABLAST Speakers
Special Feature	Wireless Charging
Color	White
Amperage	2 Amps
Wattage	10 watts

## 9. SAFETY INFORMATION

- This device complies with FCC regulations.
- Do not attempt to disassemble or modify the charging dock.
- Keep the device away from water, fire, and high temperatures.
- Use only with compatible Ultimate Ears speakers and appropriate power adapters.

## 10. WARRANTY INFORMATION

For detailed warranty information regarding your Ultimate Ears Power Up Wireless Charging Dock, please refer to the official Ultimate Ears website or the warranty documentation included with your purchase. Warranty terms and conditions may vary by region.






## 11. SUPPORT

For further assistance, product information, or to contact customer support, please visit the official Ultimate Ears website or their Amazon store page:

- [Ultimate Ears Amazon Store](#)

© 2025 Ultimate Ears. All rights reserved.

Related Documents - 989-000433

	<p><a href="#">Getting Started with UE MEGABOOM 4 Speaker</a></p> <p>A guide to setting up and using your UE MEGABOOM 4 speaker, including Bluetooth pairing, app features like Party Up and EQ, charging, and volume control.</p>
	<p><a href="#">Connecting and Using Your Ultimate Ears BOOM 3 and MEGABOOM 3 Speakers</a></p> <p>Learn how to connect, pair, and group your Ultimate Ears BOOM 3 and MEGABOOM 3 speakers. Includes troubleshooting tips for connectivity and audio issues.</p>
	<p><a href="#">Ultimate Ears BOOM User Guide: Features, Pairing, and Support</a></p> <p>Comprehensive guide to the Ultimate Ears BOOM speaker, covering getting started, connecting via Bluetooth and NFC, power management, double up features, alarm, speakerphone functionality, and support resources.</p>
	<p><a href="#">Ultimate Ears BOOM 3 &amp; MEGABOOM 3: Quick Start Guide and FAQ</a></p> <p>Learn how to set up, connect, and use your Ultimate Ears BOOM 3 and MEGABOOM 3 wireless speakers. This guide covers pairing, the Magic Button, app features like PartyUp and playlists, charging, and troubleshooting.</p>
	<p><a href="#">Ultimate Ears MEGABOOM Getting Started and FAQ</a></p> <p>A guide to setting up, using, and troubleshooting the Ultimate Ears MEGABOOM portable wireless speaker, including connection instructions, battery information, and common issue resolution.</p>

<div data-bbox="140 107 284 336"><p>Getting Started - UE BOOM 4</p><p>To get started:</p><ol style="list-style-type: none"><li>1. Charge the speaker. Connect the speaker to a power source (USB-C or USB-A) and charge for 2 hours. The speaker will be in pairing mode when the red light is on.</li><li>2. Pair your speaker to your device. Press the power button on the speaker to enter pairing mode. The red light will flash. To pair your speaker to your device, go to the Bluetooth settings on your device and select "UE BOOM 4" from the list of available devices. Once paired, the red light will turn off.</li></ol></div>	<div data-bbox="341 174 882 206"><p><a href="#">Getting Started with Your UE BOOM 4 Speaker</a></p></div> <div data-bbox="341 215 1461 286"><p>A comprehensive guide to setting up and using your Ultimate Ears UE BOOM 4 portable Bluetooth speaker, covering pairing, music control, app features, and more.</p></div>
--	--