

Lavatools KT3

Lavatools KT3 Kitchen Timer & Stopwatch User Manual

Model: KT3 | Brand: Lavatools

INTRODUCTION

The Lavatools KT3 is a versatile digital timer and stopwatch designed for various applications, including cooking, classroom activities, and general time management. It features a large display, quick-set buttons, and multiple placement options for convenience.

PRODUCT FEATURES

- Ultra-large 3-inch display with bold, clear digits for easy readability.
- Quick-set minute and second buttons for efficient operation.
- Loud beeper alarm ensures the timer is heard, even from another room.
- Integrated magnet, kickstand, and hang hole for flexible placement.
- Mute function with a light indicator for use in quiet or crowded environments.

SETUP

Battery Installation

The Lavatools KT3 timer requires one CR2032 battery (included). To install or replace the battery:

1. Locate the circular battery compartment on the back of the timer.
2. Use a coin to turn the battery cover counter-clockwise to unlock and remove it.
3. Insert the CR2032 battery with the positive (+) side facing up.
4. Replace the battery cover and turn it clockwise with a coin to secure it.

Placement Options

The KT3 timer offers multiple ways to position it:

- **Magnetic Attachment:** The back of the timer features strong magnets, allowing it to be securely attached to metal surfaces like refrigerators or ovens.
- **Kickstand:** A built-in kickstand allows the timer to stand upright on flat surfaces such as countertops or desks.

- **Hang Hole:** A small hole at the top of the timer enables it to be hung on a hook or nail.

OPERATING INSTRUCTIONS

Setting the Countdown Timer

1. Ensure the timer display shows 00:00. If not, press the **RESET** button.
2. Press the time increment buttons (**10M**, **5M**, **1M**, **10s**) to set the desired time. These buttons are additive. For example, pressing **10M** twice and **1M** once will set the timer to 21 minutes.
3. Press the **START/STOP** button to begin the countdown.

Pausing and Resuming

While the timer is counting down, press **START/STOP** to pause it. Press **START/STOP** again to resume the countdown.

Resetting the Timer

To clear the current time setting or stop an active timer and return to 00:00, press the **RESET** button.

Mute Function

The timer features a mute switch on the side. Slide the switch to the speaker icon for audible alerts or to the crossed-out speaker icon to mute the alarm. When muted, a light indicator will flash when the timer reaches zero.

Stopwatch Function (Count-Up)

To use the stopwatch function:

1. Ensure the display shows 00:00. If not, press **RESET**.
2. Press the **START/STOP** button. The timer will begin counting upwards from 00:00.
3. Press **START/STOP** again to pause the count. Press **RESET** to clear the stopwatch.

PRODUCT OVERVIEW




Front view of the Lavatools KT3 Kitchen Timer, displaying large digits and clearly labeled quick-set and control buttons.



A closer look at the front of the Lavatools KT3 Kitchen Timer, emphasizing its large digital display and user-friendly quick-set buttons.



The rear side of the Lavatools KT3 Kitchen Timer, illustrating the battery compartment, integrated magnets, and the foldable kickstand.



The Lavatools KT3 Kitchen Timer's front, with an overlay indicating its 3-inch display size for enhanced visibility.



The Lavatools KT3 Kitchen Timer securely mounted on a refrigerator door using its magnetic back, actively displaying a countdown.



The compact Lavatools KT3 Kitchen Timer stored neatly in a kitchen drawer alongside various utensils, demonstrating its space-saving design.



The Lavatools KT3 Kitchen Timer resting on a wooden countertop, showing a clear countdown on its display.



The back of the Lavatools KT3 Kitchen Timer on a wooden countertop, with its kickstand extended and the battery compartment visible.

VISUAL GUIDES

No official seller videos are available for this product at this time.

SPECIFICATIONS

Feature	Detail
Brand	Lavatools
Model Number	KT3
Color	Black

Feature	Detail
Material	Polycarbonate
Item Weight	30 g
Screen Size	3 inches
Power Source	1x CR2032 Battery

MAINTENANCE

Cleaning

To clean the timer, wipe it with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.

Battery Replacement

Replace the CR2032 battery when the display becomes dim or the timer stops functioning. Refer to the 'Battery Installation' section for instructions.

TROUBLESHOOTING

- **Timer not turning on or display is blank:** Check if the CR2032 battery is correctly installed with the positive (+) side facing up. Replace the battery if it is depleted.
- **Alarm is too loud or not audible:** Use the mute switch on the side of the timer to adjust the sound setting. Ensure it is set to the speaker icon for audible alerts or the crossed-out speaker icon for silent operation with a light indicator.
- **Timer not responding to button presses:** Ensure the battery is not low. If the timer was previously counting down, try pressing **START/STOP** to unpause it, then **RESET** to clear.
- **Timer slides when magnetically attached:** Ensure the metal surface is clean and flat. For added stability, consider placing a small piece of non-slip material on the back if frequently pressing buttons while mounted.

WARRANTY AND SUPPORT

The Lavatools KT3 Kitchen Timer & Stopwatch comes with a 3-year limited warranty. For detailed warranty information and support, please visit the manufacturer's official website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07G84DT5D>

More documents and user manuals: <https://manuals.plus/>