VOYOR ES400

VOYOR Electric Razor for Women User Manual

Model: ES400 | Brand: VOYOR

1. Product Overview

The VOYOR Electric Razor for Women ES400 is a versatile 4-in-1 rechargeable shaver designed for wet and dry use. It offers painless hair removal for the body, legs, bikini line, and underarms, featuring IPX7 waterproofing and a facial cleansing brush for comprehensive personal care. Its powerful motor and 3D floating blades ensure a close and smooth shave.



The VOYOR ES400 Electric Razor for Women, showcasing the main unit, charging base, and various interchangeable heads including shaving, trimming, and facial brush attachments.

Key Features

- **Powerful & Effective:** Delivers 10,000 cuts per minute for effective and precise hair removal without pain or irritation.
- **Closest Shaving:** Features 3D floating blades that adjust to body curves for a smooth shave.
- **4-in-1 Versatile Razor:** Includes 3 interchangeable blade heads for full body, leg, bikini line, and underarm shaving, plus a facial cleaning brush.
- **Wet or Dry Use:** IPX7 waterproof design allows for wet shaving with gel/foam in the shower or convenient dry shaving.
- **Long Lasting:** Rechargeable battery provides up to 70 minutes of use per full charge, with universal voltage for travel.



An overview of the VOYOR ES400's key features, highlighting its thin floating head, rounded tooth comb, painless and efficient hair removal, detachable heads, wet/dry capability, IPX7 waterproofing, and advanced cleansing technology.

2. Important Safety Instructions

- The charging standing base is not waterproof; please do not let it get in touch with water nor put it near the bathtub, wash basin, etc.
- Ensure that the cutting head is going against the direction of your hair growth to ensure that all hairs are removed evenly and effectively.
- Do not turn on the product while charging.
- Keep the device clean and dry after use.

3. Package Contents

Your VOYOR ES400 Electric Razor set includes the following components:

- Main Shaver Unit
- Three-in-One Shaving Head
- Precise Shaving Head
- Precise Trimming Head
- Facial Cleansing Brush Head
- Charging Base
- USB Charging Cable
- Cleaning Brush
- User Manual

Your browser does not support the video tag.

An official unboxing video demonstrating the contents of the VOYOR ES400 Electric Razor package, including the main unit, various heads, charging accessories, and cleaning tools.

4. Setup

Charging the Device

Before first use, fully charge the device for approximately 8 hours. The charging indicator light will turn on during charging. You can charge the device using the provided USB charging cable directly or by placing it on the charging standing base.



The VOYOR ES400 shaver on its charging base, illustrating the convenient USB charging design and the various interchangeable heads.

Attaching/Changing Heads

To attach a head, align the head with the main unit and gently push until it clicks into place. To remove, hold the main unit firmly and pull the head straight off. Ensure the device is turned off before changing heads.



The VOYOR ES400 shaver equipped with its four distinct heads, demonstrating its multi-functional capabilities for hair removal and facial cleansing.

5. Operating Instructions

General Usage Tips

The VOYOR ES400 can be used for both wet and dry shaving. For best results, ensure your skin is clean. When shaving, always move the shaver against the direction of hair growth. For longer hair, it is recommended to trim it shorter than 3cm first using the trimming part of the shaving head before using the foil shaver for a closer shave.



A user demonstrating the VOYOR ES400 electric razor for underarm hair removal, highlighting its comfortable S-shaped handle.

Your browser does not support the video tag.

An official video demonstrating the cordless and waterproof features of the VOYOR ES400 Women's Shaver, showing its use for body grooming and trimming.

Three-in-One Shaving Head

This head is ideal for larger areas like legs and arms. It features a 3D floating foil and hypoallergenic stainless steel blades for a close and smooth shave. Hold the device at a 30-degree angle to your skin for trimming, and a 90-degree angle for close shaving of fine hair.



A close-up of the three-in-one blade head, highlighting its floating knife net for skin conformity and a round tooth comb for gentle contact.

Precise Trimming Head


Use this head for precise hair removal on sensitive areas like the bikini line. Its flexible foil shaver glides gently along body curves for comfortable trimming without nicks or irritation.

Your browser does not support the video tag.

An official video demonstrating the VOYOR electric razor's use for intimate grooming, specifically for the bikini area, highlighting its gentle and effective trimming capabilities.

Facial Cleansing Brush Head

Attach the facial cleansing brush head for deep skin cleansing. It features fine and soft bristles that, combined with advanced sonic cleansing technology, effectively remove impurities and makeup from your face and other body parts.



A user applying the VOYOR ES400's facial cleansing brush head to her face, illustrating its function for deep skin cleansing.

6. Maintenance

Care and Cleaning

The VOYOR ES400 is IPX7 waterproof, making it easy to disassemble and clean the functional heads under running water. Use the provided cleaning brush to remove any trapped hairs from the blades. Ensure the device is completely dry before storing or recharging.



The VOYOR ES400 shaver being cleaned under running water, emphasizing its IPX7 waterproof rating for convenient and hygienic maintenance.

7. Troubleshooting

If you encounter any issues with your VOYOR ES400, please refer to the table below for common problems and solutions:

Problem	Possible Cause	Solution
Device not turning on	Low battery; Device is charging; Power button not pressed correctly.	Charge the device fully; Ensure device is unplugged from charger; Press and hold power button firmly.

Problem	Possible Cause	Solution
Not shaving effectively	Hair too long; Incorrect angle; Blades are dull or clogged.	Trim longer hair first; Adjust shaving angle (30° for trimming, 90° for close shave); Clean blades thoroughly; Consider replacing head if dull.
Skin irritation after use	Dry shaving on sensitive skin; Blades not clean; Applying too much pressure.	Use wet with shaving gel/foam; Clean blades regularly; Use light pressure; Apply moisturizer after shaving.

8. Specifications

Feature	Detail
Model Name	ES400
Power Source	Battery Powered (Rechargeable)
Special Features	Rechargeable, Cordless, Wireless, Waterproof (IPX7 body, IPX4 charging cord)
Recommended Uses	Beard, Face, Leg, Body, Underarms, Bikini Line
Battery Type	1 Lithium Ion battery (included)
Battery Capacity	600mAh
Product Dimensions	16.2 x 4 x 5.2 cm
Product Weight	130 gram
Input Voltage	100V-240V, 50/60Hz
Output	4.5V = 100 mA



The VOYOR ES400 shaver highlighting its ergonomic S-shaped handle design and key dimensions for user reference.

9. Warranty and Customer Support

VOYOR products are designed for quality and performance. For any product-related inquiries, technical support, or warranty claims, please contact VOYOR Customer Service. Refer to the product packaging or the official VOYOR website for the most up-to-date contact information.

Contact Email: voyor.service.us@hotmail.com (USA) | voyor.service.eu@hotmail.com (EU)

Our goal is to ensure every customer is satisfied with our products and services.