Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Meridian /
- Meridian M70067NB Pendant Light Instruction Manual

Meridian M70067NB

Meridian M70067NB Pendant Light Instruction Manual

Model: M70067NB

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Meridian M70067NB 1-Light 60 Watt Natural Brass Pendant. Please read this manual thoroughly before beginning installation and retain it for future reference.

IMPORTANT SAFETY INFORMATION

WARNING: Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installation or servicing. Consult a qualified electrician if you are unsure about the installation process.

- Ensure all electrical connections comply with local codes and ordinances, as well as the National Electric Code (NEC).
- This fixture is intended for indoor use only.
- Do not exceed the maximum wattage specified for the bulb.
- Handle glass components with care to prevent breakage.
- Keep flammable materials away from the light fixture.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Pendant Fixture (Natural Brass finish, Clear Glass shade)
- Mounting Hardware (Canopy, Mounting Plate, Screws, Wire Nuts)
- Instruction Manual



Figure 1: Meridian M70067NB Pendant Light. This image displays the complete pendant light fixture, featuring a natural brass finish rod and canopy, with a clear glass globe shade enclosing the bulb socket.

SETUP AND INSTALLATION

Follow these steps to install your pendant light fixture:

- 1. **Turn Off Power:** Locate the circuit breaker or fuse box that supplies power to the installation location and turn off the power.
- 2. **Prepare Mounting:** Attach the mounting plate to the junction box in the ceiling using the provided screws. Ensure it is securely fastened.
- 3. Wire Connections:
 - o Connect the fixture's **black** wire to the household's **black** (hot) wire.
 - Connect the fixture's white wire to the household's white (neutral) wire.

- Connect the fixture's ground wire (bare copper or green) to the household's ground wire and to the mounting plate's ground screw.
- Secure all connections with wire nuts and electrical tape.
- 4. **Mount Canopy:** Carefully push the canopy up to the ceiling, aligning the mounting holes with the screws on the mounting plate. Secure the canopy with the decorative nuts or screws provided.
- 5. **Install Glass Shade:** Carefully attach the clear glass shade to the fixture body. Ensure it is seated properly and secured according to the fixture design (e.g., by threading a ring or using retention clips).
- 6. Install Bulb: Screw in one incandescent bulb (not included) into the socket. Do not exceed 60 watts.
- 7. Restore Power: Turn the power back on at the circuit breaker or fuse box.



Figure 2: Side view of the Meridian M70067NB Pendant Light. This image highlights the elongated rod and the spherical clear glass shade, providing a different perspective of the fixture's design.

OPERATING INSTRUCTIONS

Once installed and power is restored, the Meridian M70067NB Pendant Light operates via a standard wall switch (not included). There is no integrated switch on the fixture itself.

- To Turn On: Flip the wall switch connected to the fixture to the "ON" position.
- To Turn Off: Flip the wall switch connected to the fixture to the "OFF" position.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your pendant light.

• Cleaning:

- Always disconnect power before cleaning.
- Wipe the natural brass finish with a soft, dry cloth. Do not use abrasive cleaners or polishes, as they
 may damage the finish.
- Clean the glass shade with a soft, damp cloth and a mild glass cleaner. Dry thoroughly.

. Bulb Replacement:

- Turn off power at the circuit breaker before replacing the bulb.
- Allow the bulb to cool completely before touching it.
- Unscrew the old bulb and screw in a new incandescent bulb. Ensure the replacement bulb does not

exceed 60 watts.



Figure 3: Close-up view of the clear glass shade and bulb socket of the Meridian M70067NB Pendant Light. This image provides a detailed look at the glass quality and the internal components.

TROUBLESHOOTING

If you encounter issues with your pendant light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	 Power is off at the breaker. Loose wire connection. Defective bulb. 	 Check and reset the circuit breaker. Turn off power, check all wire connections. Replace the bulb with a new one.
Light flickers.	 Loose bulb. Loose wire connection. Incorrect bulb type/wattage. 	 Tighten the bulb. Turn off power, check all wire connections. Ensure bulb is incandescent and does not exceed 60 watts.
Glass shade is loose.	Shade not properly secured.	Turn off power, re-secure the glass shade according to installation steps.

SPECIFICATIONS

Model Number	M70067NB
Brand	Meridian
Finish	Natural Brass
Shade Material	Glass (Clear)
Number of Lights	1
Max Wattage	60 Watts
Lamp Type	Incandescent
Power Source	Corded Electric
Mounting Type	Ceiling Mount
Product Dimensions	8 x 8 x 8.75 inches
Item Weight	8.1 Pounds
UPC	842325103642

WARRANTY AND SUPPORT


This Meridian M70067NB Pendant Light is covered by a manufacturer's warranty. For specific warranty details, claims, or technical support, please contact the manufacturer, Savoy House, directly or refer to their official website.

Manufacturer: Savoy House

Please have your model number (M70067NB) and proof of purchase available when contacting support.

© 2023 Meridian. All rights reserved.

Related Documents - M70067NB



Meridian M7014MBKNB Pendant Light Installation Guide

Step-by-step installation instructions for the Meridian M7014MBKNB Vintage 1 Light Pendant Ceiling Light, including parts identification and assembly guidance.



Meridian M90069BNB Wall Sconce Installation Guide

Detailed installation instructions for the Meridian M90069BNB wall sconce. This guide covers component identification and step-by-step assembly for the black and natural brass fixture.



Meridian 271 Digital Theatre Controller User Guide

Comprehensive user guide for the Meridian 271 Digital Theatre Controller, detailing its features, specifications, setup, and operation for advanced home theatre systems.




Meridian M80052PN/M80053NB Wall Light Installation Guide

Official installation instructions for the Meridian M80052PN and M80053NB wall light fixture. This guide provides a detailed textual description of the diagram and step-by-step assembly instructions for attaching the fabric shade, tube, and socket.



Meridian M90072BN/M90072MBK Wall Sconce Installation Guide

Installation instructions for the Meridian M90072BN and M90072MBK wall sconce, detailing assembly steps and components.



Meridian M60062BN/MBK/NB/ORB/PN Light Fixture Installation Guide

Comprehensive installation instructions for the Meridian M60062BN/MBK/NB/ORB/PN light fixture. This guide provides a step-by-step process for assembling and installing the light, including details on parts like the socket, glass shade, tube, cap, and ball screw.