

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [iTouchless](#) /
- › [iTouchless 13 Gallon Sensor Kitchen Trash Can User Manual](#)

iTouchless ITOS13B-1

iTouchless 13 Gallon Sensor Kitchen Trash Can

Model: ITOS13B-1

User Manual

INTRODUCTION

Thank you for choosing the iTouchless 13 Gallon Sensor Kitchen Trash Can. This automatic trash can is designed for convenience and hygiene, featuring a touchless motion sensor lid, an AbsorbX Odor Filter, and durable stainless steel construction. This manual provides essential information for the proper setup, operation, and maintenance of your new trash can. Please read it thoroughly before use.



Figure 1: iTouchless 13 Gallon Sensor Kitchen Trash Can

WHAT'S IN THE BOX

- 1 x Trash Can Body
- 1 x Sensor Lid
- 1 x Retainer Ring
- 1 x AbsorbX Odor Filter
- 1 x Filter Gate
- 1 x User Manual (this document)

SETUP

1. Battery Installation

Your iTouchless trash can requires 4 D-size batteries (not included) for operation.

1. Locate the battery compartment on the underside of the sensor lid.
2. Open the battery compartment cover.
3. Insert 4 D-size batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

Note: An optional AC Adapter (sold separately) can be used for continuous power. Refer to the AC Adapter's instructions for installation.

2. AbsorbX Odor Filter Installation

The included AbsorbX Odor Filter helps neutralize garbage smells.

1. Open the filter gate located on the underside of the sensor lid.
2. Insert the AbsorbX Odor Filter into the filter gate.
3. Close the filter gate securely.



Figure 2: Installation of AbsorbX Odor Filter

3. Trash Bag Installation

Use standard 13-gallon trash bags.

1. Lift the retainer ring from the top of the trash can body.
2. Place the trash bag inside the can, wrapping the top edge of the bag over the retainer ring.
3. Lower the retainer ring with the bag into the trash can, ensuring the bag is securely held and hidden from view.

4. Placement

Position the trash can in your desired location. Its oval shape is designed to fit snugly against walls or in corners, optimizing space. Ensure there is clear space above the sensor for proper lid operation.



Figure 3: Optimal Placement for Space-Saving Design

OPERATING INSTRUCTIONS

1. Touchless Operation (Motion Sensor)

The primary method of operation is touchless.

- Simply wave your hand or an object within 6 inches (15 cm) above the sensor eye on the lid.
- The lid will open automatically.
- Once you are finished, the lid will close automatically after a few seconds of inactivity.



Figure 4: Automatic Lid Opening via Motion Sensor



Figure 5: Hands-Free Disposal

2. Manual Operation

For extended open time or manual control, use the buttons on the lid.

- Press the **OPEN** button to keep the lid open indefinitely.

- Press the **CLOSE** button to close the lid manually.
- The sensor features VisioSense technology, which signals the lid to remain open for longer clean-ups, and Reflex Technology, which prevents the lid from closing on your hand.

3. Video Demonstration

Currently, there are no official seller videos available for direct embedding in this manual. For visual demonstrations, please refer to the product page or the manufacturer's website.

MAINTENANCE

1. Cleaning

The stainless steel body is fingerprint-proof and rust-resistant, making it easy to clean.

- Wipe the exterior with a damp cloth and mild detergent.
- Avoid using abrasive cleaners or harsh chemicals, as these may damage the finish.
- Ensure the sensor area on the lid remains clean and free of obstructions for optimal performance.

2. Odor Filter Replacement

The AbsorbX Odor Filter should be replaced periodically to maintain effective odor control.

- Replace the filter every 3 months, or sooner if odors persist.
- You can sign up for free text message reminders from iTouchless to know when it's time to replace your filter.
- Replacement filters are available for purchase from the manufacturer's website or authorized retailers.



Figure 6: AbsorbX Odor Filter System for Odor Elimination

3. Battery Replacement

When the lid's operation becomes slow or inconsistent, it's time to replace the batteries.

- Follow the battery installation steps outlined in the Setup section.
- The energy-efficient design allows batteries to last up to 1.5 years.

TROUBLESHOOTING

If you encounter any issues with your iTouchless trash can, please refer to the official Troubleshooting Guide for detailed solutions.

Common Issues:

- **Lid not opening/closing:** Check battery level, ensure sensor is clean and unobstructed, or try manual open/close buttons.
- **Persistent odors:** Replace the AbsorbX Odor Filter.
- **Lid closing too quickly:** Ensure no objects are near the sensor after disposal.

For a comprehensive guide, download the official Troubleshooting Guide (PDF)[here](#).

SPECIFICATIONS

Feature	Detail
Brand	iTouchless
Model Number	ITOS13B-1
Capacity	13 Gallons
Product Dimensions	16 x 11.4 x 25.3 inches
Weight	10.8 Pounds
Material	Stainless Steel (with ABS plastic lid)
Color	Light Silver
Opening Mechanism	Motion-Sensor, Manual Buttons
Power Options	4 D-size batteries (not included) or AC Adapter (sold separately)
Special Features	AbsorbX Odor Filter, Fingerprint-Proof, Rust-Resistant, Space-Saving Oval Shape, Quiet Close, VisioSense, Reflux Technology

WARRANTY AND SUPPORT






iTouchless is committed to ensuring your satisfaction. For any questions, feedback, or warranty inquiries, please reach out to our dedicated U.S.-based Customer Service Team.

- **Customer Support:** Refer to the manufacturer's website for the most current contact information.
- **Official User Manual (PDF):** For additional details and diagrams, you can download the full User Manual (PDF) [here](#).
- **Warranty Information:** Specific warranty terms and conditions are available on the iTouchless official website. Please retain your proof of purchase.

© 2025 iTouchless. All rights reserved.

For more products and information, visit the [iTouchless Store on Amazon](#).

Related Documents - ITOS13B-1

	<p>iTouchless 13 Gallon AutoStep Stainless Steel Trash Can User Manual</p> <p>Comprehensive user manual for the iTouchless 13 Gallon AutoStep Stainless Steel Trash Can (models ITA13SB, ITA13SR, ITA13SW). Learn about its features including the automatic sensor lid, odor control system, battery and AC power options, proper operation, care and maintenance, troubleshooting, and warranty information.</p>
	<p>iTouchless 13 Gallon Stainless Steel Sensor Trash Can User Manual</p> <p>User manual for the iTouchless 13 Gallon Stainless Steel Sensor Trash Can (Model DZT13P). Learn about its features, operation, troubleshooting, and warranty.</p>
	<p>iTouchless Sensor Trash Can User Manual MT02SS MT02SW MT04SS MT04SW</p> <p>User manual for iTouchless MT02SS, MT02SW, MT04SS, MT04SW sensor trash cans. Covers features, setup, operation, maintenance, troubleshooting, and warranty information.</p>
	<p>iTouchless WS13RSL / WS18RSL Wings Open Lid Sensor Trash Can User Manual</p> <p>User manual for the iTouchless WS13RSL and WS18RSL 13/18 Gallon Wings Open Lid Sensor Trash Can, detailing features, operation, troubleshooting, and warranty.</p>
	<p>iTouchless Prime 13.2 Gallon Sensor Trash Can User Manual</p> <p>User manual for the iTouchless Prime 13.2 Gallon Plastic Sensor Kitchen Trash Can (models SP13BB, SP13GG, SP13WW). Includes setup, operation, maintenance, troubleshooting, and warranty information.</p>



[iTouchless Touchless Trash Can DZT13 Plus User Manual](#)

User manual for the iTouchless Touchless Trash Can, model DZT13 Plus, detailing setup, operation, filter replacement, troubleshooting, and warranty information.