

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Schleich](#) /

› [Schleich Horse Club Lisa and Storm Blanket and Halter Playset Instruction Manual \(Model 42461\)](#)

Schleich 42461

Schleich Horse Club Lisa and Storm Blanket and Halter Playset Instruction Manual

Model: 42461

INTRODUCTION

This instruction manual provides essential information for the Schleich Horse Club Lisa and Storm Blanket and Halter Playset, model 42461. This set is designed to enhance imaginative play with Schleich horse figures, allowing children aged 5-12 to accessorize their horse, Storm, with a blanket and halter. Schleich toys are crafted to encourage learning through play.





Image: The Schleich Horse Club Lisa and Storm Blanket and Halter Playset, showing the blue blanket with a '12' emblem and the matching halter.

WHAT'S IN THE BOX

The Schleich Horse Club Lisa and Storm Blanket and Halter Playset includes the following components:

- 1x Horse Blanket (blue with '12' emblem)
- 1x Horse Halter (matching blue)



Image: The Schleich Horse Club Lisa and Storm Blanket and Halter Playset as it appears in its retail packaging.

SETUP INSTRUCTIONS

To prepare the blanket and halter for play, follow these steps:

1. **Unpack Components:** Carefully remove the horse blanket and halter from their packaging.
2. **Prepare Horse Figure:** Ensure you have a compatible Schleich horse figure ready. The blanket and halter are designed to fit most standard Schleich horse models, particularly those from the Horse Club series like Storm.
3. **Attach Halter:** Gently place the halter over the horse's head, positioning the straps around the nose and behind the ears. Ensure a snug but not overly tight fit.
4. **Attach Blanket:** Drape the blanket over the horse's back. Secure the blanket using the snap button closures located on the underside or sides of the blanket. For younger children, adult assistance may be required to fasten the snap buttons.



Image: The Horse Club girls, including Lisa with her horse Storm, demonstrating the context of the playset.

OPERATING INSTRUCTIONS

Once the blanket and halter are attached, the playset is ready for imaginative play.

- **Role-Playing:** Use the accessories to create various scenarios for your Schleich horse figures, such as preparing for a show, a trail ride, or simply caring for the horse in a stable setting.
- **Interchangeability:** The blanket and halter can be removed and re-attached to different compatible Schleich horse figures, allowing for varied play experiences.
- **Creative Storytelling:** Encourage children to develop stories and adventures involving Lisa, Storm, and other Horse Club characters, fostering creativity and narrative skills.

MAINTENANCE AND CARE

To ensure the longevity of your Schleich Horse Club accessories, follow these care guidelines:

- **Cleaning:** Wipe the blanket and halter with a damp cloth to remove dust or dirt. Avoid harsh chemicals or abrasive cleaners, as these may damage the material or paint.
- **Storage:** Store the accessories in a clean, dry place away from direct sunlight and extreme temperatures to prevent fading or material degradation.
- **Handling:** Handle the halter and blanket gently, especially when attaching or removing them from figures, to prevent tearing or damage to the fasteners.

TROUBLESHOOTING

If you encounter any issues with your playset, consider the following:

- **Difficulty with Fasteners:** The snap buttons on the blanket may be stiff initially or challenging for very young

children to operate. Adult assistance is recommended if needed.

- **Halter Durability:** The halter is designed for play but can be delicate. Avoid excessive force when attaching or removing it to prevent breakage. If the halter breaks, it may not be repairable.
- **Fit on Other Horses:** While designed to fit most Schleich horses, some variations in horse figure molds may result in a looser or tighter fit.

SPECIFICATIONS

Product Name	Schleich Horse Club Lisa and Storm Blanket and Halter Playset
Model Number	42461
Brand	Schleich
Material	Plastic
Product Dimensions	5.51 x 3.54 x 5.51 inches
Item Weight	0.56 ounces
Recommended Age	Ages 5-12 years (Note: Manufacturer's specification of "5-12 months" is likely a typo, given the product type and title)

SAFETY INFORMATION

Please observe the following safety guidelines:

- **Age Recommendation:** This product is suitable for children aged 3 years and older.
- **Small Parts:** The playset contains small parts which may pose a choking hazard for children under 3 years. Adult supervision is recommended.
- **Material Safety:** All materials used are tested and comply with international safety standards for toys.

WARRANTY AND SUPPORT

For information regarding warranty, product support, or replacement parts, please visit the official Schleich website or contact their customer service department. Keep your purchase receipt for any warranty claims.

[Visit Schleich Official Website](#)

