

EWA A109mini

EWA A109mini Bluetooth Speaker Instruction Manual

Model: A109mini

Brand: EWA

1. INTRODUCTION

Thank you for purchasing the EWA A109mini Bluetooth Speaker. This ultra-compact and lightweight speaker is designed to deliver high-quality audio with deep bass, featuring a durable metal body and versatile connectivity options including Bluetooth and TF card support. Please read this manual carefully to ensure proper use and optimal performance of your device.

1.1 Package Contents

- EWA A109mini Bluetooth Speaker x 1
- USB Charging Cable x 1
- Instruction Manual x 1

2. PRODUCT OVERVIEW

2.1 Physical Features and Dimensions

The EWA A109mini speaker boasts an ultra-compact design, making it highly portable. Its robust stainless steel body ensures durability while providing a sophisticated appearance.



Image: The EWA A109mini speaker is shown resting on a person's palm, demonstrating its remarkably small and portable size.



Image: A hand holds the EWA A109mini speaker, showcasing its ergonomic design and compact form factor against a textured stone wall.

小さいサイズ、大きなサウンド

サイズはおチョコのように小さいのに、信じられない
パワフルなサウンドを楽しめる



Image: A technical diagram illustrating the precise dimensions of the EWA A109mini speaker, measuring 46.5mm in width and 39.2mm in height.

2.2 Controls and Ports

The speaker features intuitive controls integrated into its design, along with essential ports for charging and media playback.



Image: A detailed diagram outlining the various control functions of the EWA A109mini speaker, including power on/off, playback control, track navigation, and selfie mode activation.

- **Long Press:** Power On/Off
- **Click:** Play/Pause
- **Rotate Left:** Previous Track
- **Rotate Right:** Next Track
- **Double Click:** Switch to Selfie Mode

The speaker also includes a charging interface and a MicroSD card slot for expanded music playback options.



Image: The bottom view of the EWA A109mini speaker, displaying its model number (A109mini), battery capacity (500mAh), and various regulatory compliance marks.

3. SPECIFICATIONS

Feature	Detail
Mounting Type	Tabletop Mount
Speaker Type	Woofer
Special Features	Bluetooth, Portable, Wireless
Recommended Uses	For Smartphones or Tablets
Compatible Devices	Smartphone
Color	Gray

Feature	Detail
Product Dimensions (L x W x H)	47mm x 47mm x 39mm
Product Weight	0.19 Kilograms
Waterproof	No
Power Source	Battery, Power Cord
Battery	1 Product-specific battery (included)
Manufacturer Reference	109 mini
Battery Type	Lithium Ion
Speaker Max Output	3 Watts
Frequency Response	0.01 Millihertz
Connectivity Technology	Bluetooth
Audio Output Mode	Surround

4. SETUP

4.1 Charging the Speaker

Before first use, fully charge the speaker. Use the provided USB charging cable.

1. Connect the small end of the USB charging cable to the charging port on the speaker.
2. Connect the larger end of the USB cable to a standard USB power adapter (not included) or a computer's USB port.
3. The built-in 500mA lithium battery typically takes about 2 hours to fully charge.
4. A full charge guarantees approximately 4 hours of playback time.

4.2 Initial Bluetooth Pairing

Pair your EWA A109mini speaker with your Bluetooth-enabled device (smartphone, tablet, etc.) to enjoy wireless audio.

1. Long press the control button on the speaker to power it on. The speaker will enter Bluetooth pairing mode, indicated by a flashing LED light.
2. On your device, enable Bluetooth and search for available devices.
3. Select "EWA A109mini" (or similar name) from the list of found devices.
4. The speaker should connect to your device within approximately 1 second. A confirmation tone or steady LED light may indicate a successful connection.
5. The communication range is approximately 10 meters (33 feet).

5. OPERATING INSTRUCTIONS

5.1 Bluetooth Playback

Once paired, you can stream audio wirelessly from your device to the speaker.

- Ensure the speaker is powered on and connected to your device.
- Start playing music or audio on your connected device. The sound will be output through the EWA A109mini speaker.

5.2 TF Card Playback

The speaker supports music playback directly from a TF (MicroSD) card.

1. Insert a TF card with your desired music files into the MicroSD card slot on the speaker.
2. The speaker should automatically detect the TF card and begin playing music.

5.3 Basic Controls

Use the integrated control button for various functions:

- **Click:** To play or pause the current track.
- **Rotate Left:** To skip to the previous track.
- **Rotate Right:** To skip to the next track.
- **Double Click:** To switch to selfie mode (if supported by your device and application).

6. MAINTENANCE

To ensure the longevity and optimal performance of your EWA A109mini speaker, follow these maintenance guidelines:

- Keep the speaker dry. Do not expose it to water or excessive moisture, as it is not waterproof.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid extreme temperatures. Do not store the speaker in very hot or cold environments.
- Protect from impacts. While durable, excessive force or dropping from significant heights can damage internal components.

7. TROUBLESHOOTING

If you encounter any issues with your EWA A109mini speaker, please refer to the following common problems and solutions:

7.1 No Power

- Ensure the speaker is fully charged. Connect it to a power source and allow it to charge for at least 30 minutes before attempting to power on again.
- Verify that the charging cable and power adapter are working correctly.

7.2 Cannot Connect via Bluetooth

- Make sure the speaker is in pairing mode (LED flashing). If not, long press the control button to restart it.
- Ensure Bluetooth is enabled on your device and it is within the 10-meter communication range.
- Try forgetting the device from your phone's Bluetooth settings and re-pairing.
- Restart both the speaker and your Bluetooth device.

7.3 No Sound

- Check the volume levels on both the speaker and your connected device.
- Ensure the speaker is properly connected via Bluetooth or that the TF card is inserted correctly and contains playable audio files.
- If using a TF card, ensure the audio files are in a compatible format.

7.4 Poor Sound Quality

- Move the speaker closer to your Bluetooth device to improve signal strength.
- Avoid obstacles between the speaker and your device that might interfere with the Bluetooth signal.
- Ensure the audio source file is of good quality.





8. WARRANTY AND SUPPORT



Your EWA A109mini Bluetooth Speaker comes with a 12-month warranty from the date of purchase.

- The order number from your purchase will serve as your warranty certificate. Please retain it for future reference.
- For any product inquiries, technical support, or warranty claims, please contact our customer support team.
- We are committed to providing reliable customer support to ensure your satisfaction.

© 2023 EWA. All rights reserved.

Related Documents - A109mini

	<p>EWA A109mini User Manual: Portable Bluetooth Speaker Guide</p> <p>Comprehensive user manual for the EWA A109mini portable wireless Bluetooth speaker, covering setup, controls, specifications, and warranty information.</p>
	<p>EWA A119 Mini Bluetooth Speaker User Manual</p> <p>User manual for the EWA A119 Mini Bluetooth Speaker, covering setup, TWS pairing, indicator status, specifications, important notices, and warranty information.</p>
	<p>EWA A17 Mini Karaoke Machine User Manual</p> <p>User manual for the EWA A17 Mini Karaoke Machine, detailing packaging contents, button interfaces, connection instructions, LED indicator guide, specifications, troubleshooting, notices, and FCC compliance.</p>
	<p>EWA A106Pro Wireless Speaker User Manual</p> <p>User manual for the EWA A106Pro wireless speaker, covering setup, connection, charging, commands, LED indicator guide, reset button, specifications, and important care instructions.</p>

	<p>EWA A106Max Portable Bluetooth Speaker User Manual & Quick Start Guide</p> <p>Comprehensive user manual for the EWA A106Max portable Bluetooth speaker. Learn about packaging, setup, button functions, Bluetooth connection, specifications, indicator lights, important notices, and warranty information from J.Y.M. Electronics Co., Ltd.</p>
	<p>EWA A119X Wireless Speaker User Manual</p> <p>User manual for the EWA A119X Wireless Speaker, covering packaging, quick start guide, TWS pairing, connection, specifications, indicator status, important notices, warranty information, manufacturer details, and FCC compliance. Includes detailed textual descriptions of diagrams and icons.</p>

Documents - EWA – A109mini

[\[pdf\]](#) Guide

Ewa A109mini Portable Wireless Bluetooth Speaker Powerful Sound with Bass Radiator Small TF Card and Selfie Support Mini for Travel Home Blue Amazon fr Electronics61mjpl9Aq5Lm media amazon images I 61mjpl9Aq5L |||

A109mini Manuel d utilisation Emballage Boutons et interface Maintenir enfonc : Marche/Arrt Veuillez vous assurer que toutes les pices Appuyer : Pause/ Lecture ci-dessous sont l intrieur lorsque la Cadran gauche une fois / Long : Piste bote est ouverte. prcdente / Vol.- -- EWA Audio A109m...
lang:fr **score:34** filesize: 106.64 K page_count: 1 document date: 2023-06-29

[\[pdf\]](#) User Manual

Verpackung Bitte vergewissern Sie sich dass alle folgenden Teile Öffnen die drahtlose Einrichtung auf Ihrem Smartgerät suchen und klicken EWA Audio A109mini um den Lautsprecher zu verbinden 61CqZYXoeiL m media amazon images I |||
A109mini Benutzerhandbuch Verpackung Taste und Schnittstelle Schnellstart - Anleitung Verbindung Bitte vergewissern Sie sich, dass alle folgenden Teile enthalten sind, wenn Sie den Karton ffnen. -- EWA Audio **A109mini** -- USB-Ladekabel -- Benutzerhandbuch Halten: Ein/Ausschalten Drcken: Pause/ W...
lang:de **score:33** filesize: 106.47 K page_count: 1 document date: 2023-06-25

[EWA A109mini User Manual: Portable Bluetooth Speaker Guide](#)

Comprehensive user manual for the EWA A109mini portable wireless Bluetooth speaker, covering setup, controls, specifications, and warranty information.
lang:de **score:18** filesize: 1.33 M page_count: 1 document date: 2023-06-21