

[Manuals.plus](#) /

> [Vont](#) /

> Vont Motion Sensor Light (Model VNT-MSL1) User Manual

Vont VNT-MSL1

Vont Motion Sensor Light (Model VNT-MSL1) User Manual

Brand: Vont

Model: VNT-MSL1

1. INTRODUCTION

Welcome to your Vont Motion Sensor Light user manual. This guide provides comprehensive instructions for setting up, operating, and maintaining your new motion-activated lights. Designed for convenience and energy efficiency, these lights are ideal for various indoor locations such as staircases, hallways, bathrooms, bedrooms, kitchens, and cabinets.

2. WHAT'S IN THE BOX

- 3x Wireless Motion Sensor Lights
- 3x Double-Sided Adhesive Tapes
- 3x Attached Magnets

3. KEY FEATURES

- **Easy Installation:** No tools or wiring required. Mounts instantly with super strong double-sided adhesive pads or built-in magnets.
- **Fully Automatic:** Equipped with smart state-of-the-art sensors, the light activates when both movement and darkness are detected.
- **Energy Efficient:** Automatically powers off after 15-30 seconds of no detected movement, conserving battery life.
- **Optimal Illumination:** Long-life LEDs provide sufficient lighting to guide you in dark areas.
- **Battery Operated:** Each light is powered by 3 AAA batteries (not included).

4. SETUP

4.1 Battery Installation

Each Vont Motion Sensor Light requires 3 AAA batteries (not included). Follow these steps to install them:

1. Gently twist the back cover of the light counter-clockwise to open the battery compartment.
2. Insert 3 AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. Replace the back cover and twist clockwise until it clicks securely into place.



Only turns on in the dark



Automatic motion sensor




Auto-off after about 15 seconds

Image: The back of the Vont Motion Sensor Light showing the battery compartment and the included double-sided adhesive sticker.

4.2 Mounting the Light

The Vont Motion Sensor Light offers versatile mounting options:

- **Magnetic Mounting:** The light features a built-in magnet. Simply attach it to any suitable metallic surface.
- **Adhesive Mounting:** For non-metallic surfaces, peel off the protective film from one of the included double-sided adhesive pads. Firmly press the adhesive pad onto the back of the light, then press the light onto your desired clean, dry surface.



Attaches anywhere in seconds without any tools

Image: Examples of Vont Motion Sensor Lights installed in different areas, demonstrating their versatility.


Your browser does not support the video tag.

Video: An official product video demonstrating the Vont Motion Sensor Lights, including installation and various uses.

5. OPERATING INSTRUCTIONS

The Vont Motion Sensor Light operates automatically based on light and motion detection:

- **Light Sensor:** The light will only activate in dark conditions. It will not turn on if there is sufficient ambient light in the area.
- **Motion Sensor:** When motion is detected within the sensor's range in a dark environment, the light will automatically turn on.
- **Automatic Shut-off:** The light will automatically turn off after approximately 15-30 seconds of no detected motion, helping to conserve battery power.



MAKE EVERY STEP SAFER

Illumination without switches means you're good to go even when your hands are full.

Image: A visual representation of the light's intelligent features, including light detection, motion activation, and automatic shut-off.

6. MAINTENANCE

6.1 Battery Replacement

When the light begins to dim or fails to activate consistently, it is an indication that the batteries need to be replaced. Follow the battery installation steps outlined in Section 4.1 to replace all three AAA batteries.

6.2 Cleaning

To clean the surface of your Vont Motion Sensor Light, gently wipe it with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the device in water, as this may damage the product.

7. TROUBLESHOOTING

7.1 Light Not Turning On

- **Check Batteries:** Ensure that the batteries are inserted correctly with the proper polarity and are not depleted. Replace all three AAA batteries if necessary.
- **Ambient Light:** The light is designed to only activate in dark conditions. Test the light in a completely dark environment to confirm its functionality.
- **Motion Detection:** Verify that there is sufficient motion within the sensor's detection range. The sensor may not detect very slow or distant movements.

7.2 Light Stays On

- **Continuous Motion:** The light will remain on as long as it detects continuous motion within its range. Ensure there are no constant movements (e.g., from pets, drafts, or nearby objects) that might be triggering the sensor.
- **Sensor Obstruction:** Check if the motion sensor is obstructed or if any object is interfering with its ability to detect motion accurately.

8. SPECIFICATIONS

Brand	Vont
Model Number	VNT-MSL1
Light Source Type	LED
Power Source	Battery Powered (3 AAA batteries)
Switch Type	Motion Sensor
Product Dimensions	3.15"D x 3.15"W x 0.8"H
Item Weight	1.6 ounces
Material	Polystyrene
Color	Cool White
Indoor/Outdoor Usage	Indoor
Water Resistance Level	Not Water Resistant

9. WARRANTY & SUPPORT

9.1 Warranty Information

Vont offers a lifetime warranty for defects of any type. This warranty covers manufacturing defects and ensures the longevity of your product.

9.2 Customer Support

For warranty claims, technical assistance, or any other inquiries, please visit the official Vont website or contact their customer service directly. You can find more information and products at the [Vont Brand Store](#).