

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

### Manuals.plus /

- › [Lenovo](#) /
- › [Lenovo ThinkPad X240 12.5in Laptop User Manual](#)

## Lenovo ThinkPad X240

# Lenovo ThinkPad X240 12.5in Laptop User Manual

Model: ThinkPad X240

## 1. PRODUCT OVERVIEW

---

The Lenovo ThinkPad X240 is a compact and portable 12.5-inch laptop designed for productivity. It features an Intel Core i5-4300U processor, 8GB of RAM, and a 128GB Solid State Drive (SSD) for efficient performance. This device comes pre-installed with Windows 10 Pro 64-bit operating system.

### Key Features:

- Intel Core i5-4300U Processor (1.9 GHz)
- 8GB DDR3 RAM
- 128GB SSD Storage
- 12.5-inch Display (1366 x 768 resolution)
- Integrated Webcam
- Windows 10 Pro 64-bit




Figure 1.1: Front view of the Lenovo ThinkPad X240 laptop, showcasing the display and keyboard.

## 2. INITIAL SETUP

---

Follow these steps to set up your Lenovo ThinkPad X240 laptop for the first time.

### 2.1 Unpacking and Connecting Power

1. Carefully remove the laptop and any included accessories from the packaging.
2. Connect the power adapter to the laptop's power input port.
3. Plug the power adapter into a functional electrical outlet.



Figure 2.1: Side view of the ThinkPad X240, illustrating the location of various ports including the power input.

## 2.2 First Power On and Windows Setup

1. Open the laptop lid and press the power button, typically located above the keyboard or on the side.
2. The laptop will boot up and guide you through the initial Windows 10 Pro setup process. Follow the on-screen prompts to configure language, region, network connection, and user account settings.
3. Once setup is complete, your desktop will appear, and the laptop is ready for use.

## 3. OPERATING INSTRUCTIONS

---

This section provides guidance on basic operation of your ThinkPad X240.

### 3.1 Power Management

- **Power On:** Press the power button.
- **Shut Down:** Click the Start button, then Power > Shut down.
- **Restart:** Click the Start button, then Power > Restart.
- **Sleep:** Click the Start button, then Power > Sleep, or close the laptop lid.

### 3.2 Keyboard and Input Devices

The ThinkPad X240 features a full-sized keyboard, a TrackPoint pointing device, and a multi-touch touchpad.

- **Keyboard:** Standard QWERTY layout with function keys (Fn) for system controls.
- **TrackPoint:** Use the red pointing stick in the center of the keyboard to move the cursor. The corresponding buttons below the spacebar act as left, middle, and right-click.

- **Touchpad:** The large surface below the keyboard supports multi-touch gestures for navigation.



Figure 3.1: Top-down view of the ThinkPad X240 keyboard, showing the TrackPoint and touchpad.

### 3.3 Connecting External Devices

The laptop includes various ports for connecting peripherals:

- **USB Ports:** For connecting USB devices such as external drives, mice, or keyboards.
- **VGA Port:** For connecting an external monitor or projector.
- **Ethernet Port:** For wired network connection.
- **Audio Jack:** For headphones or external speakers.



Figure 3.2: Rear view of the ThinkPad X240, highlighting the available connectivity ports.

### 3.4 Wireless Connectivity

To connect to a Wi-Fi network:

1. Click the Wi-Fi icon in the system tray (bottom right of the screen).
2. Select your desired network from the list.
3. Enter the network security key if prompted, then click 'Connect'.

## 4. MAINTENANCE

---

Proper maintenance ensures the longevity and optimal performance of your laptop.

### 4.1 Cleaning the Laptop

- **Screen:** Use a soft, lint-free cloth lightly dampened with water or a screen cleaner. Avoid harsh chemicals.
- **Chassis and Keyboard:** Use a soft, dry cloth. For stubborn dirt, a slightly damp cloth with mild soap solution can be used, ensuring no liquid enters openings. Compressed air can remove dust from keyboard crevices.

### 4.2 Software Updates

Regularly update your Windows operating system and drivers to ensure security and performance.

- Go to Start > Settings > Update & Security > Windows Update.
- Check for updates and install any available.

### 4.3 Battery Care

To maximize battery life:

- Avoid extreme temperatures.
- Do not fully discharge the battery frequently.
- Adjust power settings in Windows to optimize battery usage.

## 5. TROUBLESHOOTING

---

This section addresses common issues you might encounter with your ThinkPad X240.

### 5.1 Common Issues and Solutions

- **Laptop does not power on:**
  - Ensure the power adapter is securely connected to both the laptop and a working power outlet.
  - Verify the power outlet is functional by testing with another device.
  - If using battery, ensure it is charged.
- **Screen is blank:**
  - Check if the laptop is powered on.
  - Press Fn + F7 (or the key with a display icon) to toggle display output.
  - If an external monitor is connected, ensure it is powered on and correctly configured.
- **Wi-Fi connection issues:**
  - Ensure Wi-Fi is enabled (check the Wi-Fi icon in the system tray).
  - Restart your router and modem.
  - Forget the network and reconnect.
  - Update wireless drivers via Device Manager.
- **Slow performance:**
  - Close unnecessary applications.
  - Check for and install Windows updates.
  - Run a disk cleanup and defragmentation (for HDD, not typically needed for SSD).
  - Scan for malware or viruses.

### 5.2 Windows 10 Troubleshooting Tools

Windows 10 includes built-in troubleshooters:

- Go to Start > Settings > Update & Security > Troubleshoot.
- Select the relevant troubleshooter (e.g., Internet Connections, Power, Keyboard) and follow the instructions.

## 6. SPECIFICATIONS

---

Detailed technical specifications for the Lenovo ThinkPad X240.

Feature	Specification
Brand	Lenovo

Feature	Specification
Model Name	Thinkpad X240
Screen Size	12.5 Inches
Screen Resolution	1366 x 768 pixels
Processor	Intel Core i5-4300U (1.9 GHz)
RAM	8 GB DDR3
Hard Drive	128 GB SSD
Graphics Coprocessor	Intel Integrated Graphics
Operating System	Windows 10 Pro
Wireless Type	801.11ac
Item Weight	3 pounds
Product Dimensions	8.2 x 12 x 0.8 inches
Color	Black
Batteries	1 Lithium Ion battery (included)

## 7. WARRANTY AND SUPPORT

---

This Lenovo ThinkPad X240 is a renewed product. Warranty and support terms are typically provided by the seller or the Amazon Renewed program.

### 7.1 Amazon Renewed Guarantee

Products purchased through Amazon Renewed are backed by the Amazon Renewed Guarantee. This typically provides a replacement or refund within 90 days of receipt if the product does not work as expected. Please refer to the specific terms and conditions of the Amazon Renewed program at the time of purchase for detailed warranty information.

### 7.2 Technical Support

For technical assistance, please contact the seller directly through your Amazon order history. They can provide specific support related to your renewed device. For general Windows 10 support, refer to Microsoft's official support resources.